Translation from the original manual: IO-805UFN-PL-20230828



USER'S MANUAL

CE

Filtering device UFO-A-N and UFO-A-N/R

EN



The user's manual is valid for the following device models:

Catalog No.	Product name
805U20	UFO-A-5000-N
805U21	UFO-A-10000-N
805U22	UFO-A-15000-N
805U23	UFO-A-20000-N
805U24	UFO-A-5000-N/R
805U25	UFO-A-10000-N/R
805U26	UFO-A-15000-N/R
805U27	UFO-A-20000-N/R

IO-805UFN-EN-20231115

User's manual - title: "Filtering devices UFO-A-N and UFO-A-N/R"

The structure and form of the instructions take into account the principles included: PN-EN 82079-1, PN-EN ISO 20607, PN-EN ISO 7010, MD 2006/42/WE and other harmonized standards.



Just reliably

Manufacturer's name and address:

KLIMAWENT S.A. Poland Chwaszczyńska 194 street, 81-571 Gdynia phone: +48 58 629 64 80 fax: +48 58 629 64 19 e-mail: klimawent@klimawent.com.pl Website: www.klimawent.com.pl

Copyright © by **KLIMAWENT S.A.** Gdynia 2023-11-15

CONTENTS

1.	INTRODUCTION	5
	1.1. INFORMATION ABOUT THE MANUAL	5
	1.2. STRUCTURE AND INFORMATION RULES OF THE MANUAL	5
	1.3. NAME AND ADDRESS OF THE MANUFACTURER	6
2.	MANUFACTURER'S DECLARATION	7
3	DEVICE DESCRIPTION	9
0.	3.1. APPLICATION	9
	32 STRUCTURE	9
	3.2.1. DESCRIPTION	
	3.2.2. CONTROL UNIT (ELECTRICAL SWITCHBOARD)	
	3.2.2.1. CONTROL PANEL	14
	3.2.2.2. INVERTER	14
	3.2.2.3. DIFFERENTIAL PRESSURE TRANSMITTER	14
	3.3. SPECIFICATION	15
	3.3.1. TECHNICAL DATA	15
	3.3.2. FLOW CHARACTERISTICS	16
	3.4. PRINCIPLE OF OPERATION	17
4.	SAFETY OF USE	19
	4.1. MANUFACTURER'S DISCLAIMER	19
	4.2. SAFETY RULES AND APPLICATION RESTRICTIONS	19
	4.3. REQUIRED PERSONAL PROTECTION	21
	4.4. WARNINGS	22
	4.5. RESIDUAL RISK INFORMATION	23
5.	TRANSPORT AND STORAGE	27
	5.1. TRANSPORT	27
	5.2. STORAGE	27
6.	ASSEMBLY, INSTALLATION AND COMMISSIONING	29
	6.1. WORK AREA AND COMMUNICATION SPACE	29
	6.2. ASSEMBLY	30
	6.2.1. GENERAL GUIDELINES	30
	6.2.2. ASSEMBLY PROCEDURE	30
	6.3. INSTALLING	35
	6.3.1. ELECTRICAL CONNECTION	36
	6.3.2. COMPRESSED AIR CONNECTION	38
	6.3.3. CONNECTION TO THE VENTILATION INSTALLATION	
	6.4. COMMISSIONING / CHECKING / TESTING	
	6.4.1 ELECTRIC MOTOR CHECK	
	64.2 FARTHING AND FOUIPPING CONTROL	
	6.4.3 CONTROL OF THE ROTATION DIRECTION OF THE FAN IMPELLER	
	6.4.4. INSPECTION OF THE FILTER REGENERATION SYSTEM ELEMENTS	
	6.4.4.1. PULSE VALVES	43
	6.4.4.2. COMPRESSED AIR TANK	43
	6.4.5. VIBRATION CONTROL	43
	6.5. ADDITIONAL EQUIPMENT	44
	6.5.1. FILTER SPRAY SYSTEM	44
7.	OPERATION USE	45
	7.1. TERMS OF USE	45
	7.2. OPERATION	47
	7.2.1. SWITCHGEAR AND CONTROLLER	47
	7.2.1.1. CONTROL PANEL	47
	7.2.1.2. TURNING THE MAIN POWER ON	48
	7.2.1.3. TURNING FAN ON	48
	7.2.1.4. TURNING FAN OFF	48
	7.2.1.5. TURNING THE MAIN POWER OFF	48

	7.2.1.6.	CONTROLLER	49
	7.2.1.7.	FACTORY SETTING VALUES	49
	7.2.1.8.	ELECTRICAL APPARATUS – BASIC VERSION	50
	7.2.1.9.	ELECTRICAL APPARATUS - INVERTER VERSION	51
	7.2.2. PRES	SURE FREQUENCY CONTROL	52
	7.2.2.1.	OPERATION WITH CONSTANT VACUUM	
	7.2.2.2.	TRANSDUCER SETTINGS	
	7223	INVERTER SETTINGS	54
	723 REPI		
	7.2.3. KELLE		
	7.2.4. TILTE		
	7.2.3. EIVIET		
	7.2.0. ALAP		
	7.2.0.1.	ENGINE FAILURE - STANDARD SWITCHGEAR	
	7.2.6.2.	ENGINE FAILURE - SWITCHGEAR WITH INVERTER	
	7.2.6.3.		
	7.2.6.4.		
	7.2.7. EMER	RGENCY STOP	
	7.2.8. RETU	JRN TO NORMAL OPERATION AFTER THE PROBLEM SOLVED	58
	7.2.9. UNPL	ANNED STOPPING AND RESTARTING	58
	7.3. PERSON	IAL PROTECTION MEASURES	58
8.	MAINTENANCE A	ND REPAIR MANUAL	59
	8.1. GENERA	AL GUIDELINES	
	8.2. MAINTE	NANCE SCHEDULE	
	8.2.1. CART	RIDGE FILTER MAINTENANCE	60
	822 MAIN	ITENANCE OF THE DUST CONTAINER	60
	823 MAIN	ITENANCE OF THE COMPRESSED AIR TANK	60
	824 MAIN	ITENANCE OF PUI SE VAI VES	60
	825 FAN		61
	8.3 SERVICE	F AND REPAIR	61
	8.4 MEASUE	RING VIBRATIONS OF THE FAN	62
	841 DIRE	CTION AND PLACE OF MEASURING VIBRATIONS	62
	8.4.2 VIBR		
	8.5 SPARE		
	0.0.	/	
9.	WORK DISRUPTIC	ONS, CAUSES, REMEDIES	64
10.	DISMANTLIN	IG, DECOMMISSIONING AND DISPOSAL	66
	10.1. DISASSI	EMBLY AND DECOMMISSIONING	66
	10.2. DISPOS	AL, SCRAPPING AND RECYCLING	66
11			67
•••			
12.	DRAWINGS /	AND SKETCHES	68
	12.1. DRAWIN	G of UFO-A-5000-N(/R)	68
	12.2. DRAWIN	G of UFO-A-10000-N(/R)	70
	12.3. DRAWIN	G of UFO-A-15000-N(/R)	72
	12.4. DRAWIN	G of UFO-A-20000-N(/R)	74
	12.5. SKETCH	of THE SWITCHBOARD UFO-A-N and UFO-A-N/R	76
	12.5.1. SWI	TCHBOARD of UFO-A-N	76
	12.5.2. SWI	TCHBOARD of UFO-A-N/R	79
13.	ELECTRICAL	DIAGRAMS	
	13.1 DIAGRA	M of UEO-A-5000-N	82
	13.2. DIAGRA	M of UFO-A-5000-N/R	86
	13.3. DIAGRA	M of UFO-A-10000-N	89
	13.4. DIAGRA	M of UFO-A-10000-N/R	93
	13.5. DIAGRA	M of UFO-A-15000-N	96
		M of UEO-A-15000-N/R	100
		M of UEO-A-20000-N	102
		M of UEO-A-20000-N/R	107
14.	START-UP P	ROTOCOL	

KLIMAWENT PL

1. INTRODUCTION

1.1. INFORMATION ABOUT THE MANUAL

These operating instructions are intended for the user of **UFO-A-N(/R)**. The purpose of this manual is to provide the user with instructions on the intended use, assembly, installation, start-up, and use of the device, as well as hazards and possible disruptions in operation, but also disassembly, shutdown and disposal.

INFORM	INFORMATION					
i	Due to the constant improvement of its products, the manufacturer reserves the right to make design changes aimed at increasing the usability and safety of use.					
! UWAGA	! UWAGA					
	The user is obliged to comply with the provisions of this manual and the relevant manuals, i.e. the operating manual of the electric motor. This manual DOES NOT contain the operating instructions for the electric motor.					
	CAUTION!					

PLEASE READ THIS MANUAL BEFORE USING THE DEVICE!

KEEP THE USER'S MANUAL FOR THE FUTURE!

1.2. STRUCTURE AND INFORMATION RULES OF THE MANUAL

This manual contains 4 types of articulated messages containing an informational signal combining a word and a symbol in a graphic form depending on the level and probability of the risk, i.e.:

IP	NFORMATION				
			Danger Level: VERY LOW or NONE		
	i		Content, memo, and explanation showing the typical state and appearance, typical action, and		
			behaviour. The content describes important information of general importance that must be		

implemented by those who read the operating manual.

! CAUTION



Danger level: LOW

Warning content that indicates an elevated level of user attention. The explanation in the text presents a risk that may damage the device but is not destructive, immobilizing or has a minor impact on the user.

! WARNING



Danger level: HIGH

Warning content indicating a high level of user attention. The explanation in the content presents risks that may damage or destroy the equipment or may cause injury to the user.

! DANGER



Threat Level: very high

Warning content indicates a very high level of user attention. The explanation in the content depicts a risk that may cause damage to the device or others in the vicinity or may cause serious injury or death. Repair work must be carried out immediately once the risk is perceived. All activities leading to an increase in risk are prohibited!

KLIMAWENT Just reliably

PL

1.3. NAME AND ADDRESS OF THE MANUFACTURER

Any requests for information or repair work or questions regarding the technical aspects of this document should be addressed to:

KLIMAWENT S.A. Chwaszczyńska 194 street 81-571 Gdynia POLAND Phone: +48 58 629 64 80 Fax: +48 58 629 64 19 e-mail: <u>klimawent@klimawent.com.pl</u>

KLIMAWENT PL

The **UFO-A-N(/R)** device has been designed and made with due diligence with the participation of the internal quality management system ISO 9001 and takes into account the current state of knowledge and technological level, and above all ensures safety rules during use.

Producer KLIMAWENT S.A. declares that the products: Filtering device types UFO-A-5000-N(/R), UFO-A-10000-N(/R), UFO-A-15000-N(/R) and UFO-A-20000-N(/R) with a Y-Δ power supply or a power supply via a frequency converter meet the requirements of the following European directives and harmonised standards and other specifications:

- Directive 2006/42/EC (MD) of the European Parliament and of the Council of 17 May 2006 on machinery, amending Directive 95/16 / EC (recast) (Journal of Laws UE L157 of 09.06.2006, p. 24),
- **Regulation of the (Polish) Minister of Economy** of October 21, 2008, on requirements for machines (Journal of Laws No. 199 of 2008, item 1228),
- Directive 2014/35/EU (LVD) Directive of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits (Journal of Laws UE L96 of March 29, 2014),
- **Directive 2009/125/EC (ErP)** Directive of the European Parliament and of the Council of October 21, 2009, establishing general principles for setting ecodesign requirements for energy-related products (Journal of Laws L285 of October 31, 2009),
- Commission Regulation (EU) No 327/2011 of 30 March 2011 implementing Directive 2009/125 / EC of the European Parliament and of the Council with regard to ecodesign requirements for fans powered by an electric motor with a power consumption of 125 W to 500 kW (Journal of Laws L90 of April 6, 2011).

Additionally, the manufacturer declares compliance with harmonized standards and national standards (or their fragments):

- EN ISO 12100:2012 Safety of machinery General principles of design Risk assessment and risk reduction;
- EN 1005-2+A1:2010 Bezpieczeństwo maszyn Możliwości fizyczne człowieka Część 2: Ręczne przemieszczanie maszyn i ich części;
- EN 13849-1:2023-09 Safety of machinery Safety-related parts of control systems Part 1: General principles for design;
- EN IEC 60204-1:2018-12 Safety of machinery Electrical equipment of machines Part 1: General requirements;
- EN IEC 60947-1:2021-07 Low voltage switchgear and control devices Part 1: General provisions;
- **EN 61310-1:2008** Safety of machinery Indication, marking and actuation Requirements for visual, acoustic and tactile signals;
- EN 61310-2:2008 Safety of machinery Indication, marking and actuation Part 2: Requirements for marking;
- **EN 614-1+A1:2009** Safety of machinery Ergonomic design principles Part 1: Terminology and general principles;
- PN-EN IEC 61439-1:2021-10 Low-voltage switchgear and controlgear assemblies Part 1: General rules;

PL

	DEK EC&I	LARACJA ZG EU DECLARATIO	ODNOŚCI WE DN OF CONFORM	E UE MITY
	Data wystawienia / Date	of issue: dd.mm.yyyy	Nr / No.: XXXXXXXX	
1.	Producent:	KLIMAWENT S.A. 81-571	Gdynia, ul. Chwaszczyńska 194,	Polska
2.	Manufacturer: Opis produktu:	Urządzenie filtrowentylacyj	ne	
	Product name:	Filtering unit		
3.	Model: Model:	UFO-A-5000-N; UFO UFO-A-15000-N; UFO	UFO-A-5000-N; UFO-A-5000-N/R; UFO-A-10000-N; UFO-A-10000-N/R; UFO-A-15000-N; UFO-A-15000-N/R; UFO-A-20000-N; UFO-A-20000-N/R	
4.	Nr produktu: <i>Product number:</i>	80: 80:	5U20; 805U21; 805U22; 8 5U24; 805U25; 805U26; 8	05U23 05U27
5.	Nr seryjny: Serial number:	хххххх		
6.	Rok produkcji: Year of production:	xxxx		
7.	Niniejsza deklaracja zgodi This declaration of confe	ności wydana zostaje na wyłącz prmity is issued under the sol	zną odpowiedzialność producen le responsibility of the manufa	ta. cturer.
8.	Wymieniony powyżej wyro	5b spełnia wymagania następuj	iących dyrektyw europejskich:	irectives
		MD 2006/42/WE 2 LVD 2014/35/UE 2 ERP 2009/125/WE 2	006/42/EC 014/35/EU 009/125/EC	
9.	Odniesienia do norm zhar w stosunku do których de References to the harmo that have been applied a	monizowanych oraz norm krajo klarowana jest zgodność: onized standards and the nati and against which conformity PN-EN ISO-12100:2012	owych (lub ich fragmentów), któr ional standards (or parts there is declared: EN ISO-12100:2012	re zastosowano, of)
		PN-EN 1005-2+A1:2010 E PN-EN 13849-1:2016-02 E PN-EN IEC 60204-1:2018-12 E PN-EN IEC 60947-1:2021-07 E PN-EN 61310-1:2009 E PN-EN 61310-2:2010 E PN-EN 613-1:2021-10 E	EN 1005-2:20034A1:2008 EN 13849-1:2016 EN IEC 60204-1:2018 EN IEC 60947-1:2021 EN 61310-1:2008 EN 61310-2:2008 EN 614-1+A1:2009 EN IEC 61439-1:2021	
10. 11.	Osoba upoważniona do p A person authorized to s Niniejsza deklaracja zgodu This declaration of confe	rzechowywania i przygotowania store and prepare technical d ności jest podstawą do oznakow ormity js the basis for markin	a dokumentacji technicznej: locumentation: wania wyrobu znakiem: a the product with the mark:	Teodor Świrbutowic: KLIMAWENT S.A.
10.	Osoba upoważniona do p A person authorized to s Niniejsza deklaracja zgodu This declaration of confe Deklaracja zgodności w o przeprowadzony proce ta odnosi się wyłącznie d została wprowadzona do składowych dodanych p lub przeprowadzonych pr	rzechowywania i przygotowania store and prepare technical d ności jest podstawą do oznakow prmity is the basis for marking vystawiona została w oparciu s oceny zgodności. Deklaracja o urządzenia w stanie, w jakim o obrotu i nie obejmuje części rzez użytkownika końcowego zez niego późniejszych działań	a dokumentacji technicznej: focumentation: wania wyrobu znakiem: g the product with the mark: The declaration of conform conformity assessment relates only to the device placed on the market and added by the end-use performed b	Teodor Świrbutowicz KLIMAWENT S.A. C E nity was issued based on process. This declaration in the state in which it w does not cover compone or or subsequent actions by the end user.
10.	Osoba upoważniona do p A person authorized to s Niniejsza deklaracja zgodu This declaration of confo Deklaracja zgodności w o przeprowadzony proce ta odnosi się wyłącznie d została wprowadzona do składowych dodanych p lub przeprowadzonych pr	rzechowywania i przygotowania store and prepare technical d ności jest podstawą do oznakow ormity is the basis for marking vystawiona została w oparciu s oceny zgodności. Deklaracja o urządzenia w stanie, w jakim o obrotu i nie obejmuje części rzez użytkownika końcowego zez niego późniejszych działań	a dokumentacji technicznej: focumentation: wania wyrobu znakiem: g the product with the mark: The declaration of conform conformity assessment relates only to the device placed on the market and added by the end-use performed b Gdynia, 2022-05-20	Teodor Świrbutowicz KLIMAWENT S.A. C G nity was issued based on process. This declaration in the state in which it w does not cover compone er or subsequent actions by the end user.
10.	Osoba upoważniona do p A person authorized to s Niniejsza deklaracja zgodu This declaration of confo Deklaracja zgodności w o przeprowadzony proce ta odnosi się wyłącznie d została wprowadzona do składowych dodanych p lub przeprowadzonych pr	rzechowywania i przygotowania store and prepare technical d ności jest podstawą do oznakow ormity is the basis for marking vystawiona została w oparciu s oceny zgodności. Deklaracja o urządzenia w stanie, w jakim o obrotu i nie obejmuje części przez użytkownika końcowego zez niego późniejszych działań W Signed	a dokumentacji technicznej: focumentation: wania wyrobu znakiem: g the product with the mark: The declaration of conform conformity assessment relates only to the device placed on the market and added by the end-use performed b Gdynia, 2022-05-20 Vimieniu producenta podpisali: on behalf of the manufacture	Teodor Świrbutowic: KLIMAWENT S.A. CC mity was issued based on process. This declaration in the state in which it w does not cover compone er or subsequent actions by the end user.
10.	Osoba upoważniona do p A person authorized to s Niniejsza deklaracja zgodu This declaration of confe Deklaracja zgodności w o przeprowadzony proce ta odnosi się wyłącznie d została wprowadzona de składowych dodanych p lub przeprowadzonych pr	rzechowywania i przygotowania store and prepare technical d ności jest podstawą do oznakow ormity is the basis for marking vystawiona została w oparciu s oceny zgodności. Deklaracja o urządzenia w stanie, w jakim o obrotu i nie obejmuje części vrzez użytkownika końcowego zez niego późniejszych działań W Signed Michał Kulczyńskj	a dokumentacji technicznej: focumentation: wania wyrobu znakiem: g the product with the mark: The declaration of conform conformity assessment relates only to the device placed on the market and added by the end-use performed b Gdynia, 2022-05-20 Vimieniu producenta podpisali: on behalf of the manufacture	Teodor Świrbutowicz KLIMAWENT S.A. C mity was issued based on process. This declaration in the state in which it w does not cover compone or or subsequent actions by the end user.
10.	Osoba upoważniona do p A person authorized to s Niniejsza deklaracja zgodu This declaration of confe Deklaracja zgodności w o przeprowadzony proce ta odnosi się wyłącznie d została wprowadzona do składowych dodanych p lub przeprowadzonych pr	rzechowywania i przygotowania store and prepare technical d ności jest podstawą do oznakow ormity is the basis for marking vystawiona została w oparciu s oceny zgodności. Deklaracja o urządzenia w stanie, w jakim o obrotu i nie obejmuje części przez użytkownika końcowego zez niego późniejszych działań Michał Kulczyński	a dokumentacji technicznej: focumentation: wania wyrobu znakiem: g the product with the mark: The declaration of conform conformity assessment relates only to the device placed on the market and added by the end-use performed b Gdynia, 2022-05-20 V imieniu producenta podpisali: on behalf of the manufacture	Teodor Świrbutowicz KLIMAWENT S.A. C E nity was issued based on process. This declaration in the state in which it w does not cover compone er or subsequent actions by the end user.

KLIMAWENT

EN

3.1. APPLICATION

Filtering device **UFO-A-N(/R)** is designed for cleaning dusty air from pollutants generated during production processes, when removing dry dust (without moisture, sticky, corrosive or explosive pollutants), grinding non-sparking materials, during dusty processes in the chemical, pharmaceutical, food, plastics and other industries.

The device is designed to work indoors or outdoors but is suitably sheltered from the effects of atmospheric conditions, including rainfall. Additionally, the fan motor should be protected from direct sunlight or other heat radiation that may cause heating of the motor body or the device housing.

The **UFO-A-N(/R)** device is designed to operate an installation consisting of stationary extraction, for example, suction arms connected to a bus connecting them to the unit's inlet ports, and general ventilation combined with air filtration, for example, for **PUSH-PULL** operation.

The device is designed for the filtration of smoke and dust. It has 1 filtration stage in the form of cartridge filters made of polyester fabric. During operation, the filters trap the dust on the outer surface, from where they are periodically removed automatically using pulses of compressed air, allowing the device to run without stopping.

INFORMATION



At the customer's request, the device can be equipped with filters adapted to specific working conditions.

! DANGER

Possible damage to the device, fire or explosion!



It is **FORBIDDEN** to use the device for transporting air containing sticky or caustic contaminants that may adversely affect the device!



It is **FORBIDDEN** to use the device for transporting a mixture of air and flammable substances in the form of gases, vapours, mists or dust, which create **an explosive atmosphere** with the air!

3.2. STRUCTURE

3.2.1. DESCRIPTION

Filtering device **UFO-A-N(/R)** consists of 3 modules as standard – see Picture 1 on page 11, i.e. a fan with an expansion chamber at the top of the device (module A), a support frame with a chute and a dust container (module D) and a filter module (module B + C). The structure is self-supporting and equipped with appropriate handles for transport with the use of lifting devices.

The filtration module is equipped with **1 stage of filtration**, i.e. cartridge filters and an automatic cleaning system, which allows the device to be used in a continuous cycle without the need to stop. The number and size of filter modules depend on the device model, i.e. UFO-A-5000-N(/R) and UFO-A-10000-N(/R) have 1 module; UFO-A-15000-N(/R), UFO-A-20000-N(/R) – 2 modules – see below – Picture 2, Picture 3, Picture 4 and Picture 5.

Description of the modules (see Picture 1 on page 11):

A. A fan in an aluminium casing with an elbow and a silencer, which includes a flanged electric motor with a radial impeller mounted directly on its shaft, balanced to class G6.3.

KLIMAWENT Just reliably

- B. **Filter chamber**¹, which contains the **cartridge filters**. At the front of this chamber, there are hinged doors for inspection and filter replacement.
- C. **Regeneration chamber**¹ is separated from the filter chamber, which contains the outlets of cartridge filters, Venturi nozzles and nozzles of the filter regeneration system. On the back and side of this chamber are mounted removable inspection covers.
- D. Support frame with a chute and a detachable dust container with a capacity of 72 dm³.

In addition, it is possible to section off:

- A. **Inspection covers** on the side and rear of the filter chambers for checking the condition of the compressed air system and the interior of the "clean" section of the chamber.
- B. Compressed air installation (1 set for each filtration chamber), which includes:
 - a. Compressed air tank, designed to work with working pressure in the range from 0.6 to 0.8 MPa and a capacity of 30.1 N L²,
 - b. Electromagnetic pulse valves ³ for generating pulses of compressed air,
 - c. Noise silencers mounted on impulse valves.
- C. A control unit (electrical switchgear) that controls the operation of the fan and the filter regeneration system.

INFORMATION



The electrical switchgear for units with $Y-\Delta$ starting, i.e. UFO-A-N, is installed on the device in place of the blanked suction connection but is permitted to be installed outside the device.

! CAUTION



In the case of devices **with inverter control**, i.e. **UFO A-N/R** switchgear, **DO NOT** install it on the device. The electrical apparatus in this design is sensitive to the vibrations caused by the device and may be damaged!

- A. In the case of the UFO-A-N device with the inlet on the right (distinguishing mark RH), the electrical switchboard is on the left and the inlet connector on the right, while it is the other way round for the unit with the inlet on the left (distinguishing mark LH). A cover cap is installed in place of the unused air inlet. In the case of the UFO-A-N/R device, the switchboard must be installed away from the unit in a convenient location for use
- B. If the electric switchboard is located outside the device, it is recommended to connect the electric motor with the switchgear through a service switch disconnecting the power supply during maintenance. This switch should be placed next to the fan within the reach of maintenance personnel.
- C. The fan motor has a weather protection cover as **standard**.
- D. Filtering device UFO-A-N(/R) is delivered without air intake silencers.

¹ NOTE: UFO-A-5000-N(/R), UFO-A-10000-N(/R) has <u>1 chamber</u>; UFO-A-15000-N(/R) and UFO-A-20000-N(/R) - <u>2 chambers</u>;

² The compressed air tank is not subject to operational supervision of the Technical Inspection Authority UDT (V×P=241 < 300bar×dm3)

³ CAUTION: In the case of the UFO-A-5000-N(/R) device, the compressed air tank is equipped with only 1 impulse valve. The other port is blanked off.

- Just reliably **KLIMAWENT EN**
- E. As standard, a silencer is installed at the outlet of the device as shown in the pictures see below Picture 2, Picture 3, Picture 4 and Picture 5.



Picture 1 A typical arrangement of the UFO-A-N(/R) device



Picture 2 Functional description of the UFO-A-5000-N(/R) device with the inlet on the right side

EN **KLIMAWENT** Just reliably



Picture 3 Functional description of the UFO-A-10000-N(/R) device with the inlet on the right side



Picture 4 Functional description of the UFO-A-15000-N(/R) device with the inlet on the right side





Picture 5 Functional description of the UFO-A-20000-N(/R) device with the inlet on the right side

EXPLANATION TO Picture 2; Picture 3; Picture 4; Picture 5:

Fan, 2 – Duct silencer, 3 – Expansion chamber, 4 – Regeneration chamber inspection cover,
 Regeneration chamber inspection cover, 6 – Filter chamber inspection door, 7 – Support frame,
 8 – Dust container, 9 – Compressed air tank, 10 – Manometer,
 11 – Compressed air connection Ø12 mm, 12 – Inlet connection Ø500 mm,

13 – Supporting beam, **14** – Hanger

KLIMAWENT Just reliably

3.2.2. CONTROL UNIT (ELECTRICAL SWITCHBOARD)

The control unit consists of two basic components (see Picture 6):

- A. Control panel mounted on the cover of the electrical switchboard,
- B. **The electrical apparatus** built inside the switchgear serves as a power supply to the device and the controller,
- C. A frequency converter (inverter)⁴ controlling the fan motor,
- D. Differential pressure sensor ⁴ mounted on the ventilation system.

3.2.2.1. CONTROL PANEL

The control panel consists of traffic lights and buttons such as signal lamps and illuminated buttons. Their function is to switch on the power supply, start the fan and signal the operating states of the device and alarm in the event of a failure. The switchboard and the apparatus are described in pt. 7.2.1- SWITCH AND CONTROLLER on page 47.



Picture 6 Appearance of the control panel

H1 – Lamp signalling the appearance of power in the system; S1 – Mode switch;
S2.1 – Fan stop button; S2.2 – Fan start button; S2.H2 – Green light indicating fan operation;
H3 – Red light indicating engine alarm; H4 – Red light indicating a controller alarm



3.2.2.2. INVERTER

The inverter (UFO-A-N/R only) controls the motor, its starting and stopping and regulates the speed. To fulfil the motor speed control function, a differential pressure transmitter measuring the pressure in the ventilation system must be connected to the inverter.

3.2.2.3. DIFFERENTIAL PRESSURE TRANSMITTER

The differential pressure transmitter (**UFO-A-N/R** only) is used to measure the differential pressure in the ventilation system to maintain a constant negative pressure by frequency control of the fan motor.

⁴ Fittings supplied for **UFO-A-N/R** devices only.

3.3. **SPECIFICATION**

3.3.1. TECHNICAL DATA

Table 1 Technical data of UFO-A-N

Catalogu	Je no.	805U20 UFO-A-5000-N	805U21 UFO-A-10000-N	805U22 UFO-A-15000-N	805U23 UFO-A-20000-N
Туре		805U24 UFO-A-5000-N/R	805U25 UFO-A-10000-N/R	805U26 UFO-A-15000-N/R	805U27 UFO-A-20000-N/R
Nominal	capacity	5000 m3/h	10 000 m3/h	15 000 m3/h	20 000 m3/h
Maximu	m capacity	9200 m3/h	14300 m3/h	18100 m3/h	22700 m3/h
Working	capacity	4 000-6 000 m3/h	8 000-12 000 m3/h	12 000-16 000 m3/h	16 000-21 000 m3/h
Max. vad	cuum	4100 Pa	4500 Pa	5000 Pa	5250 Pa
Net weig	ght	575 kg	765 kg	1015 kg	1125 kg
Sound p	pressure level ⁵ , ⁶	72 dB(A) ^{5,6}	76 dB(A) ^{5,6}	78 dB(A) ^{5,6}	80 dB(A) ^{5,6}
Device of	operating temperature		from –20°C	C to +40°C	
Max. du	st load		3 g/	m3	
Electric	ity supply				
Electric	motor power	5,5 kW	11 kW	18,5 kW	22,0 kW
Supply v	voltage and frequency ⁷		3×400 VA0	C \ 50 Hz ⁷	
Synchro	nous speed		3000	rpm	
Compre	essed air supply				
Nominal	consumption ⁸	2,8 Nm3/h ⁸ (7,8 litres/min)	5,6 Nm3/h ⁸ (15,3 litres/min)	8,4 Nm3/h ⁸ (23,3 litres/min)	11,2 Nm3/h ⁸ (31 litres/min)
Compre	ssed air pressure		from 0,6 to	0,8 MPa ⁹	
Quality of	conditions ¹⁰		Oil-Solids-Wa	ter: 6:4:4 ¹⁰	
Equipn	nent	•			
	Filter designation		POH30	6638U	
ters	Catalogue No.	800F18			
efil	Filter material and surface ¹¹	Hydrophobic coating ¹¹ \ 30 m2/1 per filtrer			
'idg	Type of contamination ¹¹	Smoke / Fine dust / Fine chips ¹¹			
Cart	Number of filters in the device	2	4	6	8
	Dimensions [diameter × height]	Ø380×660 mm			
ed	Capacity		30,1	dm3	
ess ank	Dimensions [diameter × height]		Ø219	×860	
Compr air t	Working temperature and pressure	from –20°C to +80°C / 0,5 – 8 bar			
e ve	Control type	Electric; opened with an electromagnetic co		n electromagnetic coil	
val	Diameter and type of flow		Ø1,5", an	geled 90°	
Ilse	Control voltage		24V/50-60 Hz	(±10%) 19VA	
Ρſ	Working temperature and pressure	from –20°C to +80°C / max 0,8 MPa			

⁵ CAUTION: Sound pressure measurement made at a distance of 1 m from the unit at nominal flow rate.

⁶ CAUTION: The device is a source of impulse noise during the operation of the automatic cartridge filter cleaning system.

⁷ CAUTION: It is possible to adjust the rotational speed of the motor with the use of a frequency converter.. ⁸ CAUTION: Air consumption for factory set regeneration parameters.

⁹ The compressed air tank is not subject to operational supervision of the Technical Inspection Authority UDT (V×P=241 < 300bar×dm3)

¹⁰ ISO 8573-1:2010 class 6:4:4 - see point. 6.3.2 - COMPRESSED AIR CONNECTION. 38.

¹¹ CAUTION: At the customer's request, the filtration method can be adapted to specific working conditions.





Digram 1 Summary diagram of the efficiency of UFO-A-N(/R) filtering devices

1 – UFO-A-5000-N(/R); 2 – UFO-A-10000-N(/R); 3 – UFO-A-15000-N(/R); 4 – UFO-A-20000-N(/R)

EN

The purpose of the **UFO-A-N(/R)** device is to clean the conveyed air from dust contamination with the use of cartridge filters with a hydrophobic coating¹².

The **UFO-A-N(/R)** device, depending on the model, has from 1 to 2 filtration chambers, which are equipped with 1 suction connector with a diameter of Ø500 mm – see Picture 38 to Picture 45 on page 75 – located on the right or left side of the casing, to which a ventilation system must be connected. Air sucked in through this connection enters the filter chamber, where contaminants in the air precipitate on the surface of **the filters** and the cleaned air continues to flow into the ventilation system – see Picture 7.



Picture 7 Air-flow path

Some of the pollutants fall into the tank and the rest adhere to the external surface of the filters as a result of suction (negative pressure) by the flowing air. Adjacent impurities increase the flow resistance during the operation of the device, so to counteract this phenomenon and reduce the flow resistance, **pulses of compressed air** are generated during the operation of the device, shot through special nozzles (so-called Venturi nozzles) to the filters from the "clean" side, which cleans them from dust – see. Picture 8 on page 18. The removed dust drops off and accumulates at the bottom of the device in a container. Dust in the container must be systematically removed so as not to cause repeated entrainment of the dust from the container.

¹² At the customer's request, the filter material can be adapted to the specific operating conditions of the device.



Picture 8 View of the inside of the chamber and Venturi nozzles

The filter regeneration process takes place automatically and at specific intervals during the operation of the device, thanks to which the device can work without stopping.

In the case of a high dust load or after a longer period of operation, it is possible to increase the flow resistance and decrease the efficiency of the device, regardless of the operation of the filter regeneration system. This is normal. When a significant drop in efficiency is found, the filters should be removed from the device and cleaned manually or mechanically using a device designed for this purpose.



Picture 9 View of the inside of the filters' chamber

! CAUTION



The design and principle of operation of the device allow for continuous operation but require the operator to systematically check the amount of dust accumulated the condition of the cartridge filters, and, above all, the systematic emptying of the accumulated dust from the container.



To ensure an effective filtration process, it is required to ensure a stable connection of compressed air with the filter cleaning system, and the conditions and minimum parameters of the compressed air are presented in point 3.3.1 – TECHNICAL DATA on page 15.

KLIMAWENT

EN



4.1. MANUFACTURER'S DISCLAIMER

! CAUTION



Producer **KLIMAWENT S.A.** conducted a risk analysis only for the **UFO-A-N(/R)**, device, but it does not take into account the impact of additional risks arising from use and application at the installation site.

Unauthorized modifications to the device and installation of additional elements that are not part of the device or additional equipment are **FORBIDDEN** and may affect the safe use of the device!

4.2. SAFETY RULES AND APPLICATION RESTRICTIONS

! CAUTION



READ these instructions before putting the device into operation! Keep for future reference in a place accessible to all users.



PROTECT the device against mechanical damage.



PROTECT all markings, descriptions, nameplates and, in particular, warnings against seizure, damage causing illegibility or tearing off.



The device is intended for **PROFESSIONAL USE**. Before starting work, familiarize yourself with the procedures and principles of operating the device. Service may only be performed by **TRAINED** and **QUALIFIED** personnel.

! WARNING

Possibility of damaging the device, hurting or serious injury!



The manufacturer is not responsible for personal injuries resulting from **IMPROPER USE**. During all operations carried out on the equipment (assembly, maintenance, cleaning, etc.), operators must be equipped with appropriate personal protective equipment (PPE) to prevent or minimise injuries which cannot be prevented by other means.



Before assembling the device, check the load-bearing capacity of the structural elements to which it will be attached. **IMPROPER**, **CARELESS** or **UNSTABLE MOUNTING** of the device may damage it and also pose a real **THREAT** to people in the surrounding area.



DO NOT start up the device until you have checked the continuity and connection of the **PE** conductor.



Unauthorized modifications to the device and installation of additional elements that are not part of the device or additional equipment are **FORBIDDEN!**

EN

! WARN	! WARNING			
Possible	a damage to the device and disruptions in operation.			
	The temperature of filtered air CANNOT exceed +60°C.			
	The ambient temperature during operation MUST be between –20°C and +40°C. The fan motor should not be exposed to direct sunlight or other heat radiation that could cause significant heating of the motor body.			
	Ambient relative humidity MUST NOT exceed 95% without condensation.			
	The atmospheric pressure MUST be between 800 hPa and 1100 hPa .			
	The altitude above sea level CAN NOT exceed 1000 m.			
	The dust limit of the filtered air MUST NOT exceed 3 g/m3 .			
	The device CAN NOT be used for the filtration of moist or sticky dust adhering to the surface of the filters, significantly reducing the filtration efficiency.			
	The device MUST be permanently connected to the compressed air network to ensure the uninterrupted operation of the automatic filter cleaning system. Compressed air MUST be prepared by appropriate filtering and reducing unit with a pressure ranging from 0.6 to 0,8 MPa and meeting the purity conditions specified in point 6.3.2 – COMPRESSED AIR CONNECTION on page 38.			
	The device CAN work continuously under certain conditions – see 3.4 – PRINCIPLE OF OPERATION on page 17.			
	The device MUST NOT work in an environment that may cause an accelerated rate of corrosion.			
	When the device is powered by a frequency converter (inverter) (UFO-A-N/R execution), the maximum speed of the motor MUST NOT be greater than the nominal speed of the fan motor. In addition, the frequency variation up and down should be limited so that the frequency is between 15 Hz and 50 Hz . This limit MUST NOT be exceeded by any unauthorized modification of the fan control system.			
! DANG	ER			
Possible	a damage to the device, fire or explosion!			
	It is FORBIDDEN to use the device for transporting air containing sticky or caustic contaminants that may adversely affect the device!			



It is **PROHIBITED** to use devices for cleaning the air of carcinogenic, radioactive dust or contaminated with pathogens and other dangerous substances posing a high risk to human health and life.

Just reliably

! DANGER

Possible damage to the device, fire or explosion!



It is **FORBIDDEN** to use the device for transporting a mixture of air and flammable substances in the form of gases, vapours, mists or dust, which create an **explosive atmosphere** with the air!

4.3. REQUIRED PERSONAL PROTECTION

RECOMMENDED PERSONAL PROTECTION

	Use head protection
	The warning indicates that personnel must use a protective helmet. Always wear head protection
	when operating the equipment or during maintenance. The device has protruding housing
	elements and adjusting elements that can be injured when it is tilted.
	Use hearing protection
	The warning indicates that ear protection must be worn when operating the device. During operation, the device generates noise that may harm people nearby.
	Use eye protection
	A warning indicates that it must be used by security personnel.
	Protective measures must always be used during operation.
	Use foot protection
	A warning indicates that it must be used by security personnel.
	Protective measures must always be used during operation and maintenance.
ſſŊ	Use hand protection
1115	A warning indicates that it must be used by security personnel.
	Protective measures must always be used during operation and maintenance.
	Use protective clothing
	A warning indicates that it must be used by security personnel.
	Protective measures must always be used during operation and maintenance.
	Use face protection
	A warning indicates that it must be used by security personnel.
	Protective measures must always be taken during operation and maintenance.
	Use dust masks
	A warning indicates that it must be used by security personnel.
	Protective measures must always be used during operation and maintenance.
	Respiratory protection required
	A warning indicates that it must be used by security personnel.
9330	Protective measures must always be used during operation and maintenance.
	The requirement to disconnect the device from the mains
	A warning indicates that the appliance must be disconnected from the power supply
	for maintenance, fault finding and similar operations involving the opening of covers

and access to hazardous parts, especially the fan impeller

EN 🚺 KLIMAWENT Just reliably

4.4. WARNINGS

RECOMMENDED MARKINGS ON OR NEAR THE DEVICE



CAUTION: Danger due to sudden noise!

During the regeneration of filters with compressed air, air blows from the nozzles regenerating the filters, which generates **impulse noise**!

The warning indicates that ear protection must be worn when operating the device.



CAUTION: Danger due to noise!

The warning indicates that ear protection must be worn when operating the device. The device generates noise during operation and may adversely affect people in the vicinity.



CAUTION: Danger due to dusty atmosphere!

The device itself is not a source of dust emission and has a sealed housing, but due to the purpose of the device for air purification, dust from the filtration process accumulates inside, on the surfaces of the filters and the chute and in the tank. Each time the device is opened, or the dust container is emptied, the user comes into contact with potentially harmful process dust.

KLIMAWENT S.A. performed a **Risk Assessment** carried out following **EN ISO 12100**. This assessment shows the **residual risk** for the above device (machine) and is illustrated in this chapter. The person who will design the system, together with the company/person who will integrate the above device into the machine/end system, must carry out another residual risk analysis and ensure that the entire installation is safe and complies with **Directive 2006/42/EC**.

The table below presents information on the **residual risk** and the rules of conduct during use in each phase of the device's life

ATTENTION: THE DEVICE IS SAFE AS THE PROVISIONS SHOWN IN THE TABLE BELOW FOLLOW THE DEVICE.

	THREATS AND SAFETY RULE				
No.	Phase	Threats	Procedure		
1.	Unpacking	Impact, abrasion, overturning	Use personal protective equipment to protect against accidental abrasions, cuts and injuries, in particular anti-cut gloves, protective clothing and work shoes. Pay attention to protruding parts when walking and working next to the device.		
2.	Transporting, lifting and moving	ting, rubbing, overturning ng the load, sliding the load	 Lifting, carrying or transporting elements (modules) of the device is allowed only with the use of fastening elements installed on the device and intended for transport – see point. 5.1 – TRANSPORT on p. 27 and 5.2 – STORAGE on p. 27. in the case of a support frame with a chute – a transport beam with lugs serving as a support for forklifts; in the case of filtration chambers and chambers with a fan – transport lugs mounted on the edges of the chambers, are used to fasten crane hooks. 		
3.			Keep hands, hands and other parts of the body away from ropes, lanyards or chains, lifting hooks while lifting, handling, and preventing them from being crushed and sheared as a result of tension in the ropes due to the weight of the load.		
4.	Storage	Impact, abrasion, overturning	Use personal protective equipment to protect against accidental abrasion, cuts and injuries on protruding elements. Follow the rules described in point 5.2 – STORAGE on page 27, to protect the device structure against damage, leakage, crushing or destruction.		
5.	Assembly	Impact, scratch, cut	 When handling cargo, operators must be equipped with personal protective equipment: helmets, helmets, anti-cut gloves, protective clothing, work boots. 		
6.			During assembly, keep hands and arms and other parts of the body away from ropes, cables, chains, lifting hooks, and slots, to prevent crushing, and cutting due to the tension of ropes under the weight of the load.		
7.	Installation	Impact, fall	The user must prepare a base suitable for the size and weight of the machine, and the surface must be level to prevent deformations that may affect the frame and the machine housing – see point. 6.3 – INSTALLING on page 35 and 6.1 – WORK AREA AND COMMUNICATION SPACE on page. 29		
8.			Make sure that the electric circuit is disconnected from the electricity supply.		

Table 2 Safety rules and information on residual risks

EN

No.	Phase	Threats	Procedure	
9.			Electric shock,	The design and execution of the electrical connection of the machine to the power supply must be carried out by a qualified electrician (see section 6.3.1 – ELECTRICAL CONNECTION on p. 36) and the electric motor operating manual.
10.		Concussion	It is necessary to ensure the correctness of the equipotential bonding, and check if the earthing connection with the main earthing bar is made – see section 6.4 – COMMISSIONING / CHECKING / TESTING on page 41.	
11.		Injection, burst, high air pressure	The device must have a permanent connection to a compressed air network that provides stable pressure for the automatic cleaning of the filters in the device. The condition, pressure and quality of the compressed air must be constantly monitored. The design and execution of connection of the device to such a network must be performed by qualified personnel, following the principles of implementation of this type of installation. Regularly check the tightness of the tightening of the pneumatic elements. No air blows are allowed – they should be removed immediately, and in the event of damage to an element that prevents removal of the fault, disconnect the device from the compressed air system, empty the compressed air tanks and replace the defective element.	
12.	Commissioning / Start-up / Operation	Discomfort, noise-induced stress	We recommend isolating the machine from the ground and the ventilation ducts of the suction and discharge part with elastic shock-absorbing elements and the use of duct silencers at the fan outlet. Do not place the device near corners, near walls or on enclosed metal structures due to the possibility of causing vibrations and resonances. The device is a source of impulse noise generated by the automatic system of filter cleaning with compressed air. Place appropriate warnings about the impulse noise generated by the device - see section 4.4 – WARNINGS on page 22.	
13.			Noise, discomfort, fatigue	The user or the employer must comply with the regulations on protection against the daily exposure of operators to noise generated in the workplace (required by applicable European and national standards) and require the use of personal protective equipment (ear muffs, earplugs, etc.) depending on the overall sound pressure level in individual workplaces and the level of daily personal exposure of workers – see point 4.3 – REQUIRED PERSONAL PROTECTION on pages 21 and 3.3.1– TECHNICAL DATA on p 15. Place appropriate warnings indicating the impulse noise generated by the equipment - see section 4.4 – WARNINGS on page 22.
14.			All electrical equipment must be designed concerning the electric current consumption times and peaks of the installation and must be performed by qualified personnel.	
15.		Electric shock/burns caused by the motor	Make sure that the electric current consumed by the fan does not exceed the value stated on the motor nameplate.	
16.	•		Avoid consecutive engine starts that lead to constant overloads of the starting system that overheat electrical components. Allow the electric motor to cool down before restarting.	
17.			The construction of the device is designed to work with frequency converters (inverters). Make sure that the maximum engine speed is not greater than the rated speed of the electric motor. In addition, you should limit the frequency variation from the bottom and top of the frequency value so that $f = (15 - 50) Hz$, where f is the inverter output frequency and the larger value (f = 50Hz) is the rated frequency of the electric network.	
18.		Burns	The company/person installing the machine in the ventilation system must provide adequate ventilation for the electric motor if adequate heat transfer cannot be guaranteed for the motor, such as during idle periods, when the motor is at high temperatures or when used with frequency converters. The	

THREATS AND SAFETY RULE

	THREATS AND SAFETY RULE			
No.	Phase	Threats	Procedure	
			lack of an adequate additional cooling system for the electric motor will adversely affect its properties and may cause its failure.	
19.			Do not touch the engine during and after long-term operation. Allow the motor casing and adjacent surfaces to cool down.	
20.		Excessive vibration	Provide scheduled maintenance to prevent technical failures that may occur over time as a result of excessive vibration.	
21.			Excessive vibrations should be avoided, as they may cause deformation or cracks in the rotor structure, seizure of the bearings, increased noise levels, loosening of bolts and nuts of important connections, and ultimately lead to the destruction of the rotating elements and create a situation threatening the safety of operators and people in the vicinity. Where possible, the use of bearing vibration and temperature monitoring systems is recommended.	
22.			It is recommended to monitor the fan vibrations with the use of a vibration sensor or to carry out the inspection every 4000 hours of work and vibration measurement to avoid exceeding Vrms = 11.8 mm/s – see point 8.4 – MEASURING VIBRATIONS OF THE FAN on p. 62.	
23.		Overspeed, Overtemperature, Destruction	The device is designed for operation with frequency converters (inverter) within the limits $f = (15 - 50) Hz$, where f is the inverter output frequency and the upper frequency $f = 50Hz$ is the rated mains frequency. This limit must not be exceeded by unauthorised modifications to the fan control system. The device must be operated under the conditions for which it was designed, in particular, to avoid excessive speed and temperature. Changing the parameters may lead to irreparable damage to the device and consequently endanger people.	
24.		Poisoning, suffocation	Both the end user and the installer must take into account the risks of pumping air mixtures other than those permitted in this manual. Indicate with appropriate signs all types of dangers related to the situations resulting from non-compliance with the provisions concerning the permitted use of the device.	
25.		Slip, fall	Keep the minimum gaps of the device from walls or partitions during installation, otherwise, it may cause hazards and inconvenience in confined spaces during operation or maintenance – see pt. 6.3 – INSTALLATION on page. 35.	
26.			Properly light the area surrounding the machine.	
27.			Keep the minimum gaps of the device from walls or partitions during installation, otherwise, it may cause hazards and inconvenience in confined spaces during operation or maintenance – see pt. 6.1 – WORK AREA AND COMMUNICATION SPACE on p. 29.	
28.		Tain fall alim	Properly illuminate the area surrounding the device.	
29.	Maintenance, Cleaning, Troubleshooting, Disassembly	i rip, fail, slip	Operators must be equipped with appropriate personal protective equipment to prevent slipping: footwear and protective clothing.	
30.			It is necessary to ensure the correctness of the earthing connection with the main earthing bar – see point 6.4.2 – EARTHING AND EQUIPPING CONTROL on page 41.	
31.		Injection, burst, high air pressure	The device must have a permanent connection to the compressed air network, ensuring a stable pressure, and enabling automatic cleaning of the filters in the device. Regularly check the tightness of the tightening of the pneumatic elements. No air blows are allowed – they should be removed immediately, and in the event of damage to an element that prevents removal of the fault, disconnect the	

NO.	Phase	Ihreats	Procedure				
			device from the compressed air system, empty the compressed air tanks and replace the defective element.				
32.			Before any maintenance work, switch off and disconnect the power supply to the device. Wait until all mechanisms have come to a complete stop. In the event of maintenance of the fan's interior, it is recommended to disconnect the power supply using the service switch located on the fan housing. This prevents the fan from being accidentally started by another person.				
33.		Cut, entanglement, collision, electric shock, Burns	During maintenance of the rotor or the inside of the fan, even if the electrical supply has been disconnected, the impeller may rotate due to natural or induced air currents flowing through the device, as it is connected to the ventilation system. As a result, there can be a serious risk of cuts and/or entanglement. For this reason, it is necessary to mechanically block the moving parts of the fan. Operators must be equipped with appropriate personal protective equipment such as cut-off gloves and protective clothing.				
34.			Be careful not to cut yourself with sharp parts or any manufacturing waste when removing the safety nets.				
35.			 It is strictly forbidden to: maintenance of the device during its operation, removing covers and covers during device operation, maintenance of the device without disconnecting the power supply. 				
36.		Cut / Collision / Poisoning / Choking / Cancer	 Operators must be equipped with appropriate personal protective equipment: (Certified) footwear, (Certified) clothing, helmets, helmets, anti-cut gloves, protective dust masks, additional protections required by the safety data sheet of the pumped mixture and other regulations in force in the country of installation. 				
37.		Burn	Do not touch the engine after a long-term operation. Allow the electric motor housing and adjacent surfaces to cool down. Additionally, wait until the temperature inside and outside reaches a value that is not hazardous to touch. Operators must be equipped with appropriate personal protective equipment such as gloves and protective clothing.				

THREATS AND SAFETY RULE

KLIMAWENT

EN

5.1. TRANSPORT

- A. Due to the dimensions of the device, the device is disassembled during transport and divided into several parts, enabling transport. Each of these parts is protected against weather conditions.
- B. The temperature during transport should be between -30°C and +40°C.
- C. Do not allow moisture to enter or flood the device. The device must be tightly protected against the influence of weather conditions.

During vertical transport, follow the guidelines for safe transport with the use of lifting equipment. Carry out a trial lifting of the load to a height of 0.5 m and check the correctness of the load securing. In addition, it is forbidden to stay under the load during transport.

Only certified slings should be used for vertical transport. Suspend the load on a 4-rope sling ended with hooks using an intermediate traverse that stabilizes the device and relieves the device's hangers from oblique forces – see Picture 15 and Picture 16 on page 32. In addition, the hooks should be fastened with hangers with holes of Ø30 mm, maintaining a safe opening angle between slings max 120 degrees. Use the directional rope to guide the load at height. It is allowed to guide the cargo manually to the structure with which it is to be connected. Keep hands and other parts of the body away from ropes, lanyards chains and hooks while lifting or guiding to prevent them from being crushed or sheared due to tension in the ropes due to the weight of the load.

5.2. STORAGE

- A. The device should be stored folded or unfolded. Protect against the influence of moisture and penetration of dust as well as external weather conditions and above all protect against direct sunlight or other heat source or radiation.
- B. The storage place should be dry, dust-free, at a temperature from -30°C to +40°C, and the device must be empty and protected against the ingress of moisture. Relative humidity must not exceed 95%, noncondensing.
- C. The device must be protected against any shocks that could compromise its integrity.
- D. The device must be protected against the influence of oxidizing or corrosive substances that can adversely affect the sealing materials and the device in general.
- E. It is unacceptable to load the device with forces that could deform or destroy the housing of the device.
- F. The electric motor and the fan impeller must not stay stationary for a long time, both during storage and when the system in which the device will be placed is still under construction or at a standstill. During these periods, the condition of the impeller and fan should be checked periodically by turning the impeller to avoid damage to the motor bearings, especially oxidation of the bearing tracks.

! CAUTION



Producer **KLIMAWENT S.A.** is not responsible for damage to mechanisms as a result of long-term inactivity.



EN



6.1. WORK AREA AND COMMUNICATION SPACE

The device must be placed in places protected from unfavourable weather conditions and free from corrosive factors.

For the sake of the safety and convenience of communication and ergonomic operation of the device, it is necessary to provide a free area around the machine to prevent the risk of accidents.

Below are diagrams showing the minimum distances from the device, which should be kept when installing the device. The surrounding areas should also be left free to allow for safe maintenance work. In addition, there must be space above the motor to allow adequate ventilation and heat exchange by the electric motor. **The access of cooling air to the electric motor housing must not be obstructed**.



Picture 10 Workspace – Side view

Picture 11 Workspace – Top view

29 / 114

	A [m]	B [m]	H [m]	R [m] ¹³	S [m] ¹⁴	T [mm]
UFO-A-5000-N(/R)	3,3	3,0	2,6	0,75 (1,0)	Min 1,25	Min 50
UFO-A-10000-N(/R)			3,3			
UFO-A-15000-N(/R)			4,1			
UFO-A-20000-N(/R)			4,6			

¹³ **CAUTION:** Passages between machines and other devices or walls intended only for the operation of these devices should be at least 0.75 m wide, and if there is two-way traffic in these passages, their width should be at least 1 m.

¹⁴ **CAUTION:** Dimension on the cartridge filter access door side. If movement around the machine is required while opening the door, it is recommended to increase this value by another 1 m.

KLIMAWENT Just reliably

6.2. ASSEMBLY

6.2.1. GENERAL GUIDELINES

During transport to the installation site, the device is divided into several parts. All modules should be connected by a flange connection with a gasket and screwed together. These connections should be made carefully to ensure tightness. It is not allowed to omit any of the bolted joints, which may cause joint leakage, but also result in deformation, damage or instability of the structure and, as a result, a catastrophe.

To assemble the unit, at least 2 hexagon socket wrenches, size 13 (14) are required. When bolting, a specific bolting sequence is not required, but it is required to bolt in a uniform manner that prevents deformation of the flange connection. All connections should be tightened using force, bearing in mind the crush of the gasket and the distortion of the flanges. Do not use high-torque electric, pneumatic or similar screwdrivers! After screwing the device together, check the tightness of the connection during a test run.

6.2.2. ASSEMBLY PROCEDURE

Depending on the model, the device can be divided into 2 or 3 parts for transport.

The device should be assembled at the workplace, observing the necessary safety measures, following the guidelines presented in point 6.1 – WORK AREA AND COMMUNICATION SPACE" on page 29 and in pt. 4.5 – RESIDUAL RISK INFORMATION – Table 2 "Safety rules and information on residual risks" on page 23.

Depending on the division of the device, install by selecting the appropriate steps from the list below, and skip the rest.

ASSEMBLY PROCEDURE

- A. Place the device supporting frame in the place of installation. A transport beam is used for transport, mounted between the legs of the support frame. The frame should be transported using forklifts.
- B. Level the carrying frame. Attach to the ground using the mounting holes in the legs see below Picture 12. The size and spacing of the mounting holes: Ø18 to □1195×1195 mm ¹⁵.



Picture 12 Support frame

- C. Apply the gasket on the frame surface as shown above see Picture 12. Create a square from the gasket evenly spaced from the outer edge of the load-bearing frame, covering the mounting holes in the frame with a strip width of at least 25 mm. Check the quality and condition of the prepared gasket.
- D. Place the first filter chamber on the support frame. Use hangers mounted in the corners of the chamber

 see Picture 20 on Page 33. Pay attention to the smoothness of the adjacent surfaces and the condition
 of the sealing. Fix the elements with the M8 screws attached to the device.

! WARNING

When screwing together the chambers of the device on the outer flange, make sure to connect the chambers also inside, in the place of the filtration partition - see Picture 20!

- E. When suspending modules, follow the guidelines for the correct suspension of loads with elastic slings – see point. 5.1 – TRANSPORT on page 27. Use appropriate intermediate beams such as crossbeams to protect the body structure from distortion or loss of stability. Diameter and spacing of hanger points: Ø30 by □1210×1345 mm – see Picture 17, Picture 18 and Picture 19 on page. 33.
- F. The methods of hanging the filter modules shown in Picture 13 and Picture 14 are not allowed! Recommended methods are shown in Picture 15 and Picture 16 on page 32.

¹⁵ Nominal dimension of the leg spacing. The design of the frame allows manipulation within small limits.

EN KLIMAWENT Just reliably

- G. Put the next modules in the same way, respecting the conditions of transporting loads specified in point
 E described wyżej on page 31. Fasten the modules with the M8 screws attached to the device.
- H. Connect all modules with equipotential bonding. For this purpose, use the bolts to connect the modules by placing them under the head of the bolt and the eyelet of the equalizing wire. Check the conductivity of equipotential bonding.







Picture 14





Picture 16



Picture 20 Filter chamber



Picture 21



34 / 114

Just reliably

EN

6.3. INSTALLING

The user must prepare a surface suitable for the size and weight of the machine, and the surface must be level to prevent deformation that may affect the support frame and the machine housing.

The size of the area provided for the ergonomic and safe operation of the device is shown in point. 6.1 – WORK AREA AND COMMUNICATION SPACE – see wyżej – Picture 10 and Picture 11 on page 29.

The device should be connected to:

- the electric power supply (see section 6.3.1 ELECTRICAL CONNECTION on page 36),
- the compressed air network (see section 6.3.3 COMPRESSED AIR CONNECTION on page 38),
- the filtered process ventilation system (see section 6.3.3 CONNECTION TO THE VENTILATION INSTALLATION on page 39) and
- install the differential **pressure transducer** in case of control of the device with frequency control of the motor see section 6.3.4 INSTALLATION OF DIFFERENTIAL PRESSURE TRANSMITTER on page 39.

All installation activities must be performed by qualified personnel with confirmed authorizations after familiarizing themselves with the requirements – see section. 4.2 – SAFETY RULES AND APPLICATION RESTRICTIONS – on page 19.

! CAUTION



It is necessary to ensure the correctness of the connections to equalize the potentials of all parts of the ventilation system, to check if these connections have been made correctly and to make the earthing connection between the device and the main earthing bar – see section 6.4.2 – EARTHING AND EQUIPPING CONTROL on page 41.



The device **MUST** be permanently connected to the compressed air network to ensure the uninterrupted operation of the automatic filter cleaning system. Compressed air **MUST** be prepared by appropriate filtering and reducing unit with a pressure ranging from **0.6** to **0.8 MPa** and meeting the purity conditions specified in point 6.3.2 – COMPRESSED AIR CONNECTION on page 38.

! DANGER



The user **MUST** ensure that adequate safety measures are taken in the ventilation system where the equipment is to be installed regarding **IGNITION** or **EXPLOSION DANGER** if required.

KLIMAWENT Just reliably

6.3.1. ELECTRICAL CONNECTION

- A. The device requires the connection of an electric power supply that meets, above all, the minimum requirements for the electric motor of the fan drive, i.e. the voltage variation in the network must be within ±5%. The design and execution of the electrical connection with the power supply must be performed by a qualified electrician following the diagrams in point 13 ELECTRICAL DIAGRAMS on page 82 and the instruction manual for the electric motor.
- B. The device MUST be powered by the ZE-UFO-A-N or ZE-UFO-A-N/R electrical switchboard and properly connected to the device see section 13 ELECTRICAL DIAGRAMS on page 82. No modifications of any kind are allowed without the approval of the manufacturer KLIMAWENT S.A.

! WARNING



In the case of **inverter**-controlled devices, the electrical assembly **ZE-UFO A-N/R MUST NOT** be installed on the device. The electrical apparatus in this design is sensitive to vibrations caused by the device and may be damaged!

- C. The device **MUST** be supplied with electricity adapted to the power consumption of the device see technical data in point 3.3.1. TECHNICAL DATA on page 15.
- D. The device **MUST** be connected to the main equipotential bar. Threaded studs are provided in the legs of the supporting frame for this purpose.
- E. The device MUST be powered from a TN-S network, that is, from three phases L1, L2, L3 along with a neutral conductor N and a protective conductor PE. The power supply must be connected to the terminals of the X1 strip marked L1, L2, L3, N, PE accordingly see the electrical diagrams in section. 13 ELECTRICAL DIAGRAMS on page 82.
- F. If after connecting the power supply and setting the main switch in the ON position, the diode H1 "POWER" does not light up, pay attention to the indications of the CKF monitoring relay. The diode on the CKF relay may be on or blinking continuously. If it flashes, it means that the device is not connected properly. This may be due to the wrong phase sequence, a missing phase, or a too-low supply voltage. In this case, check that the voltage values are correct, that the voltage is on all three phases, or reverse the phase sequence. When properly connected, the diode on the CKF relay will be lit continuously, and the white lamp H1 "POWER" on the switchgear door will light.
- G. It is recommended to connect the fan's electric motor to the electric switchboard through the service switch following the wiring diagram see point. 13 ELECTRICAL DIAGRAMS on page 82 by placing it on the unit near the fan. The designation of the terminals on the motor must correspond to the same marked terminals in the service switch and the switchgear, i.e.: the terminal on the U1 motor must be connected to the U1 terminal in the switchgear; terminal V1 on the motor with terminal V1 in the switchboard etc.
- H. The electric motor is adapted to work with frequency converters (inverters) in the frequency range from 15 Hz to 50 Hz. This limit MUST NOT be exceeded by any unauthorized modification of the fan control system.
- I. It is recommended to use a **service switch** that disconnects power from the fan during maintenance works. This switch should be placed next to the fan within the reach of maintenance personnel.
Just reliably

! CAUTION



The user is obliged to follow the conditions written in this manual and the related instructions, i.e. the manual for the electric motor.

This manual does **NOT** include the electric motor manual.

INFORMATION



For manuals on the inverter, see APPENDIX A of this manual.

For manuals on the controller, see APPENDIX B of this manual.

! WARNING



DO NOT start the unit before ensuring that the continuity and connection of the **PE** protective conductor have been checked.

KLIMAWENT Just reliably

6.3.2. COMPRESSED AIR CONNECTION

A. The device should be connected to the compressed air network ensuring uninterrupted operation of the automatic filter cleaning system. Compressed air must be prepared by appropriate filtering and reducing unit with a pressure ranging from 0.6 to 0.8 MPa and ensure appropriate cleanliness classes for individual pollutants, i.e. following ISO 8573-1, air supplied to the filter cleaning system with compressed air should meet the minimum requirements set out in the table below:

The type of contaminants	Purity class according to ISO 8573-1: 2010
Oil	6
Solid particulates	4
Humidity and liquid water	4

- B. The design and construction of the connection of the device must be performed by qualified personnel following the description of the design of this type of device.
- C. The device, depending on the model, has 1 to 2 compressed air tanks with a capacity of 30.1 L each operating at a limit pressure of 8 bar (0.8 MPa). For the filter regeneration system, the pressure should be provided in the range of 0.6 to 0.8 MPa. Each tank is equipped with a pressure gauge for monitoring the pressure in the system, Ø1.5" impulse valves on the bleeder stubs, a drain valve at the bottom of the tank and a Ø12 mm quick coupling connector with a check valve see below Picture 23 and Picture 24. The hose with the quick-connect stub should be slid onto the stub and the tightness of the connection checked. The compressed air tank is not subject to UDT operational supervision, as the condition V×P = 241bar×dm3 < 300bar×dm3 is met; V capacity in dm3; P overpressure in bars.</p>
- D. Compressed air consumption in the filter regeneration process in the case of factory settings of the filter regeneration parameters is specified in point 3.3.1– TECHNICAL DATA see Table 1 on page 15.





- A. The device should be connected to the filtered process ventilation system through appropriate flexible connectors ensuring isolation of the system structure against vibrations
- B. Connect all parts of the ventilation system and the device with equalizing pipes to ensure the flow and equalization of electrostatic charges. For this purpose, suitable threaded pins are located near the stubs.
- C. Before starting the device, make sure that the ventilation system has the appropriate safety measures concerning the risk of explosion if required.



6.3.4. INSTALLATION OF DIFFERENTIAL PRESSURE TRANSMITTER

Automation with an inverter and the function of maintaining a constant negative pressure in the ventilation duct cannot be mounted directly on the device and must be mounted in the room on the ventilation system.

The pressure transmitter should be installed so that the **lower pressure stub** (marked with a "-" sign) measures the pressure in the ventilation duct upstream of the device (vacuum), while the **higher pressure stub** (marked with a "+" sign) measures the atmospheric pressure.





Picture 25 Differential pressure transmitter







YES

NO

Picture 26



Picture 27

KLIMAWENT

EN

6.4. COMMISSIONING / CHECKING / TESTING

6.4.1. ELECTRIC MOTOR CHECK

- A. Before starting the electric motor:
 - check the condition of the motor winding insulation and temperature sensor circuits, if the measured insulation resistance is too low, the winding should be dried; Insulation resistance measurement should also be performed in the event of a longer stoppage of the motor,
 - ✓ check if there is a free flow of cooling air to the ventilator,
 - check the electrical installation, operation of the switch, meters and other auxiliary and protection devices,
 - check the tightness of all fastening screws, the security of the cable connection and all elements affecting the degree of motor protection,
 - ✓ check the quality of earthing and neutralization,
 - \checkmark check that the device is ready for commissioning and conduct a trial run.
- B. During the test run of the device, check:
 - ✓ value of the supply voltage,
 - ✓ current value,
 - ✓ motor rotation direction,
 - ✓ correct engine cooling,
 - \checkmark there are no excessive vibrations or other abnormalities in the engine operation,
 - ✓ degree of heating of individual engine components, such as bearing shields, bearings, frame,
 - ✓ correct operation of starting devices, safety control devices,
 - electrical parameters achieved by the motor.

INFORMATION



The user is obliged to comply with the provisions contained in the non-smaller manual and the relevant manuals, i.e. the operating manual of the electric motor.

This manual **DOES NOT** contain the operating instructions for the electric motor.

INFORMATION



Electric motors powered by frequency converters make a characteristic "chirping" sound and this is normal. This is not a malfunction of the electric motor!

6.4.2. EARTHING AND EQUIPPING CONTROL

Before starting the device, check the condition and correctness of all electrical connections and equipotential bonding on the device. It is recommended to check the conduction of these connections regularly. In addition, check and systematically control the conductivity between the farthest elements and the connection of the device to the structure to which it is attached.

KLIMAWENT Just reliably

6.4.3. CONTROL OF THE ROTATION DIRECTION OF THE FAN IMPELLER

Check the direction of rotation of the fan impeller (check the direction of rotation of the fan ventilating the electric motor) before starting the device in the ventilation system. It should match the arrow on the fan housing or as shown below – see Picture 28 on page 42.

The control system protects to a very high degree against the possibility of incorrect rotation of the fan impeller, however, if the impeller rotates in the wrong direction despite the correct connection and start-up, immediately contact the manufacturer **KLIMAWENT S.A.** – additionally see point 6.3.1 – ELECTRICAL CONNECTION on page 36.





Picture 28 Correct direction of rotation of the impeller. View from above.

6.4.4. INSPECTION OF THE FILTER REGENERATION SYSTEM ELEMENTS

Before switching the device on to work in the dust extraction system, check the correctness of the selection of the capacity of the compressed air installation connected with the filter regeneration system – see the requirements in point 3.3.1 – TECHNICAL DATA – Table 1 – "Compressed air supply: nominal consumption, pressure and quality conditions" on page 15. System capacity and pressure should be at least as specified in this table.

Compressed air parameters should be controlled throughout the lifetime of the device, not allowing the pressure limit to be exceeded, which could lead to the destruction of pneumatic elements not intended for operation with increased pressure.

In the event of damage to the equipment of the device, contact the manufacturer of KLIMAWENT S.A.

WARNING Possible damage to the device, burns or serious injuries as a result of bursting elements of the pneumatic system! **REGULARLY CHECK** the tightness of connections of pneumatic elements. **REGULARLY CHECK** the tightness of connections of pneumatic elements. **RECTIFY** any leaks immediately and in the event of damage to a component that prevents recovery, **DISCONNECT** the device from the compressed air system, **EMPTY** the compressed air tanks and **REPLACE** the defective component.

6.4.4.1. PULSE VALVES

Pulse valves are designed to work with filtered air with a working pressure not exceeding **8 bar (0,8 MPa)**. Exceeding the pressure may destroy the valve.

The impulse valve during operation, i.e. when opened and closed, bleeds air through an opening located on the side of the valve. This is normal. To eliminate the whistle and noise, a throttle valve acting as a silencer is installed in this place. This silencer should not be permanently disassembled. It should be regularly cleaned and unblocked in case of clogging.

The impulse valve is controlled by a solenoid switch mounted on its top. The switch is powered with 24 V. All impulse valves are connected to the electrical switchboard, which controls their opening in the right order. Regularly check the condition of the connection between electrical sockets and impulse valve plugs.

6.4.4.2. COMPRESSED AIR TANK

Compressed air tanks require the control of the amount of condensate accumulated inside and their systematic emptying. In the event of excessive condensation inside the tank, check the filtration of the compressed air connected to the filter cleaning system – see the conditions specified in point 6.3.2 – COMPRESSED AIR CONNECTION on page 38. Additionally, check pneumatic connections for tightness. Level the leakage by tightening (sealing) or replacing damaged elements with new ones.

6.4.5. VIBRATION CONTROL

All rotors manufactured by **KLIMAWENT S.A.** are balanced following ISO 1940-1 with a balancing degree of G6.3.

During the final acceptance of the device, a fan test is carried out with appropriate control of the vibration level on a fully assembled machine. **KLIMAWENT S.A.** applies the guidelines for the assessment of vibrations provided in the standards PN-ISO 14695:2008 and ISO 14694:2003. Fans built into the **UFO-A-N** type device manufactured by **KLIMAWENT S.A.** belong to fans in category BV-3 and as such do not exceed the residual unbalance during commissioning tests, measured as vibration velocity Vrms = 2.8 mm/s when rigidly mounted or Vrms = 3.5 mm/s – flexibly.

The manufacturer is not responsible for the level of vibrations in the device (fan) in the place of final assembly, because the measured vibration values are influenced by the device levelling and the strength and flexibility of the supporting structure, therefore it should be taken into account when assessing vibrations *"in situ"*.

Avoid excessive vibrations in the fan, as they may result in deformation or cracking of the impeller structure, seizure of bearings, increased noise level, loosening of bolts and nuts of important connections, and ultimately lead to the destruction of rotating elements and create a situation threatening the safety of operators or persons in its vicinity.

It is recommended to constantly monitor the fan vibration with a sensor or to carry out vibration measurements during fan inspections every **4,000 operating hours** or in the event of increased noise, vibration and other symptoms indicating a possible defect – see 8.4 – MEASURING VIBRATIONS OF THE FAN on page 62.

The value of the measured vibrations expressed as velocity Vrms should not exceed Vrms = 6.3 mm/s, the value of Vrms = 11.8 mm/s is considered alarming, and the value of Vrms = 12.5 mm/s qualifies for an immediate stop of the device.



6.5. ADDITIONAL EQUIPMENT



6.5.1. FILTER SPRAY SYSTEM

The **UN-1** sputtering system (spray chamber) is used to sputter the cartridge filters with CaCO3 synthetic calcium carbonate. This process protects the filters by extending their working time by creating a protective layer that protects the filter material against sticking sticky substances. In addition, it increases the safety of operation in dedusting systems installed in many industries.

Туре	Part No.	Remarks
UN-1	840U20	Spraying chamber with synthetic calcium carbonate CaCO3 (chalk)



7.1	. TERMS OF USE
! WARN	ING
Possible	damage to the device and disruptions in operation.
	The temperature of filtered air CANNOT exceed +60°C.
	The ambient temperature during the operation of the device MUST be between -20°C and +40°C . The fan motor should not be exposed to direct sunlight or other thermal radiation that could significantly heat its body.
	Ambient relative humidity MUST NOT exceed 95% without condensation.
	The atmospheric pressure MUST be between 800 hPa and 1100 hPa .
	The altitude above sea level CAN NOT exceed 1000 m.
	The dust limit of the filtered air MUST NOT exceed 3 g/m³ .
	The device CAN NOT be used for the filtration of moist or sticky dust adhering to the surface of the filters, significantly reducing the filtration efficiency.
	The device MUST be continuously connected to a compressed air network that ensures uninterrupted operation of the automatic filter cleaning system. The compressed air MUST be prepared by a suitable filter-reduction unit with a pressure in the range of 0.6 to 0.8 MPa and meeting the purity conditions specified in point. 6.3.2 – COMPRESSED AIR CONNECTION on page. 38.
	The device CAN work continuously under certain conditions – see 3.4 – PRINCIPLE OF OPERATION on page. 17.
	The device MUST NOT work in an environment that may cause an accelerated rate of corrosion.
	When the device is powered by a frequency converter (inverter) (design UFO-A-N/R), the maximum motor speed MUST NOT be greater than the nominal speed of the fan motor. In addition, the frequency variation from below and above must be limited so that the frequency is between 15 Hz and 50 Hz. This limit MUST NOT be exceeded by any unauthorized modification of the fan control system.
	Do NOT start the device before ensuring that the continuity and connection of the PE protective conductor have been checked.

! DANGER				
Possible	damage to the device, fire or explosion!			
	It is FORBIDDEN to use the device to transport air containing sticky or caustic contaminants that may adversely affect the device!			
	It is PROHIBITED to use devices for cleaning the air of carcinogenic, radioactive dust or contaminated with pathogens and other dangerous substances posing a high risk to human health and life.			
	It is FORBIDDEN to use the device for transporting a mixture of air and flammable substances in the form of gases, vapours, mists or dust, which create an explosive atmosphere with the air!			

KLIMAWENT

EN

7.2. OPERATION

7.2.1. SWITCHGEAR AND CONTROLLER

The device can be controlled (powered) through an electrical switchgear with a Y- Δ starting system for UFO-A-N devices, or using a frequency converter (inverter) for devices of the type UFO-A-N/R. In both cases, the control panel of the switchgear is the same – see below Picture 29.

On the cover of the electrical switchboard, there is a control panel with a membrane keyboard for controlling and manipulating the operation of the device, and inside there is a controller and electrical devices.

! WARNING



The device can be controlled from the panel on the electrical switchboard (LOCAL) or from another (**REMOTE**) by connecting to **terminals 17** and **18** in the switchgear of the **NO** relay signal.

7.2.1.1. CONTROL PANEL

The **control panel** consists of light signalling elements and membrane buttons, such as:

- A. signal lamp H1 (white lamp) "POWER", which signals the switching on of the control voltage continuous light,
- B. signal light S2.H2 (green light) "FAN" indicates the fan operation status continuous light,
- C. signal lamp H3 (red lamp) "ALARM FAN" which signals the alarm of the fan,
- D. signal light H4 (red light) "ALARM CONTROLLER" which signals the alarm of the controller,
- E. red button S2.1 "STOP", which stops the fan motor,
- F. green button S2.2 "START", which starts the fan motor.



Picture 29 Control panel appearance

H1 – Lamp signalling the appearance of power in the system; S1 – Mode switch;
S2.1 – Fan stop button; S2.2 - Fan start button; S2.H2 – Green light indicating fan operation;
H3 – Red light indicating engine alarm; H4 – Red light indicating a controller alarm

KLIMAWENT Just reliably

7.2.1.2. TURNING THE MAIN POWER ON

Before starting the device, make sure that the inspection doors and the inspection covers of the device are closed and secured. **WK limit switches** are installed in the inspection doors of the filtration chambers, which switch off the device, preventing accidental activation.

A. To turn on the power, set the main switch Q1 on the side of the switchgear to the ON position – see below Picture 30 and Picture 31. The voltage will appear in the power circuit, then the controller will initialize and the white light H1 located on the control panel will illuminate – see above Picture 29 on page 47 wyżej.

7.2.1.3. TURNING FAN ON

A. Press the S2.2 "START" button on the control panel. The fan operation is indicated by the green light
 S2.H2. See Picture 29 on page 47 above.

! CAUTION



CHECK the efficiency of the compressed air system connected to the device. **ENSURE** the minimum specified in point 6.3.2 – COMPRESSED AIR CONNECTION on page 38.

7.2.1.4. TURNING FAN OFF

A. Press the S2.1 "STOP" button located on the control panel. The fan will stop with a slow run in the case of UFO-A-N or after 30 seconds in the case of UFO-A-N/R. The green lamp S2.H2 will turn off. See Picture 29 on page 47 wyżej.

7.2.1.5. TURNING THE MAIN POWER OFF



A. Turn off the power by setting the main switch Q1 on the side of the switchgear to the "OFF" position. The white lamp H1 will go out. See Picture 30 on page 50 or Picture 31 on page 51.

EKONOMIZER E1T

01/03/2016

7.2.1.6. CONTROLLER

See the operating instructions for the TURBO sequencer:

- Title of the manual:
- Publication date:

User manual version: 1.24

- Hardware version: 1.3
- Manufacturer's name and address:

TURBO s.r.l.

Electronic Control Systems For Dust Collectors e-mail: info@turbocontrols.it web: www.turbocontrols.eu Tel. ++39 (0)362 574024 Fax ++39 (0)362 574092

INFORMATION



For instructions on how to use the controller, see **APPENDIX B** in this manual.

7.2.1.7. FACTORY SETTING VALUES

Function No	Description	Value			
F02	Time of action		0.2	20"	
F03	Pause time in normal cycle ¹⁶	240"	120"	80"	60"
F04	Number of outputs ¹⁷	1	2	3	4
F05	Output voltage: 24Vdc, 24Vac, 115Vac, 230Vac.		24	Vac	
F06	Manual activation of the solenoid valve 1				
F13	Number of cycles after the fan has stopped 2				
F14	time during the cycle with the fan off 020"				
F15	Maintenance break in 10 hours. (1 = 10h, 100 = 1000h) 100				
F16	Enable (1) either deactivation or (0) of the maintenance interval alarm 0				
F17	Reset maintenance hour counter: By setting 1, the maintenance counter is reset to zero after confirmation	ero O			
F24	Valve shutdown during short circuit	1			

¹⁶ The settings for each version of the device are different, i.e.: 240 s for UFO-A-5000-N,

¹⁷ The settings for each version of the device are different, i.e.: 1 for UFO-A-5000-N, 2 – UFO-A-10000-N, 3 – UFO-A-15000-N, 4 – UFO-A-20000-N

¹²⁰ s – UFO-A-10000-N, 80 s – UFO-A-15000-N, 60 s – UFO-A-20000-N



7.2.1.8. ELECTRICAL APPARATUS – BASIC VERSION

Picture 30 View of the interior of the electrical switchgear with a standard 3x400V power supply and Y- Δ type start-up

,,

Type of apparatus ¹⁸	Description	Function	
Q1	Power switch	Provides power to the device, indicated by the H1 lamp	
Q1M	Motor circuit breaker	It is used to protect the motor against damage due to blocked start, overload, short circuit	
F1	Miniature circuit breaker	Protects the transformer and driver circuit	
K1M, K2M, K3M	Contactors	They are used to soft start the star-delta fan	
K1		Engine failure relay	
K2		Controller failure relay	
K1T	Time transmitter	Controls the start-up of the fan	
B1	UFO controller	Control of solenoid valves	
CKF Monitoring relay It is used to detect missing sequence		It is used to detect missing, asymmetry and wrong phase sequence	
KR	Resistance relay	Controls the temperature of the fan's electric motor	

¹⁸ The electrical diagrams of the device are presented in point. 13 on page 85.



7.2.1.9. ELECTRICAL APPARATUS – INVERTER VERSION



INFORMATION Image: Im

Type of apparatus ¹⁹	Description	Function		
Q1	Power switch	Provides power to the device, indicated by the H1 lamp		
Q1M	Motor circuit breaker	Is used for protection of the motor from damages due to blocked start, overload, short circuit		
FAL1	Inverter (frequency converter)	It is used to regulate the efficiency of the system and performs the monitoring function of the motor circuit		
B1	UFO controller	Control of solenoid valves		
F1	Overcurrent circuit breaker	Protects the transformer and driver circuit		
К1		Operating relay		
K2	Electromagnetic relays	Motor failure relay		
K3		Controller failure relay		
тн	Thermostat	Controls the operation of the switchgear ventilation fan		
G1	Ventilation fan	Ventilates the switchboard with automation		
CKF	CKF Supervisory relay It is used to detect absence, asymmetry and wrong sequence			
KR	Resistance relay	Controls the temperature of the fan motor		

Table 4 Functions of the electrical apparatuses included in the UFO-A-N/R electrical assembly

7.2.2. PRESSURE FREQUENCY CONTROL

The regulation of operation with the maintenance of constant vacuum is carried out only by automation for **UFO-A-N/R** devices.

7.2.2.1. OPERATION WITH CONSTANT VACUUM

For the **UFO-A-N/R** device to be able to operate while maintaining a constant negative pressure, a differential pressure transmitter must be used for this purpose. The negative pressure measurement using this transmitter must take place on the collective manifold before the filtering ventilation device and must be properly installed - see point 6.3.4 – INSTALLATION OF DIFFERENTIAL PRESSURE TRANSMITTER on page 39.

The automation of the UFO-A-N/R device maintains the negative pressure following the diagram below:



7.2.2.2. TRANSDUCER SETTINGS

The transducer model used in the device has **8 measuring range settings**. Depending on the tightness of the system and the operating point of the device (i.e. the pressure to be maintained in the channel), the measuring range of the transmitter should be adjusted by selecting one of the jumper configurations.



Picture 32 Jumper configuration of the pressure measuring transducer

¹⁹ The electrical diagrams of the device are presented in point. 13 on page 85.

KLIMAWENT

EN



The jumper should be attached as shown below:





Picture 34 Functions of transducer components

- Jumpers **J1**, **J2** and **J3** are used to set the operating range of the pressure sensor.
- Jumper J4 is used to determine the response time to a pressure change closed circuit 8s, open circuit 0.8s.
- Jumper **J5** is used to change the displayed unit.
- Jumper J6 has no function



7.2.2.3. INVERTER SETTINGS

! CAUTION

The inverter's range is set on the display from **0** to **50** units, with the lower value of **0** being the lowest controllable frequency value determined by the **LL** parameter, whose value is set to **15 Hz** by default. Similarly, the **UL** parameter determines the highest controllable frequency value of the inverter set at **50** Hz.

! WARNING

Potential for engine damage



When the unit is powered by a frequency converter (inverter) (version UFO-A-N/R), the maximum motor speed **MUST NOT** be higher than the nominal speed of the fan motor. So, limit the frequency variation from below and above so that the frequency is between **15 Hz** and **50 Hz**. This limit **MUST NOT** be exceeded by unauthorized modifications to the fan control system.

Conversion of the inverter range to the desired vacuum

Example:

To maintain a constant negative pressure in the channel at 1500 Pa, we set the transducer range to 4000 Pa.

Conversion of 0 – 50 values to 4000 Pa range.

The value **0** on the inverter display corresponds to a vacuum difference value of **0** Pa and the value **50** on the inverter display corresponds to a value of **4000** Pa.

Based on the ratio:

$$\frac{1500Pa}{4000Pa} = \frac{x}{50}$$

Therefore:

$$x = \frac{1500 \text{Pa} \times 50}{4000 \text{Pa}} = 18,75$$

The value **18.75** should be set on the display as the desired controllable frequency value to be maintained by the inverter.

7.2.3. REPLACEMENT OF FILTERS

- A. Turn off the fan and wait for all mechanisms to stop see 7.2.1.4 TURNING FAN OFF on page 48.
- B. Wait until the final filter regeneration cycles are completed, then turn off the power with the Q1 main switch see 7.2.1.5 TURNING THE MAIN POWER OFF on page 48.
- C. Unscrew and open the access door to the cartridge filter chamber. The **WK limit switch** located at the top of the door will disconnect the power from the device and protect it against the blast of compressed air during service work.



Picture 35

Picture 36

- D. Unscrew and remove the star knobs and filter pressers.
- E. Remove the filters, replace or regenerate them see 8.2.1 CARTRIDGE FILTER MAINTENANCE on page 60.



Picture 37

- F. Put the clean filters back in the same place.
- G. Apply a clamp to the threaded studs, tighten and tighten with the star knobs. Tighten so that the filter cannot be turned around its axis. Do not deform the filter paper!
- H. Close and tighten the access door. The **WK limit switch** located at the top of the door will switch the power on.



EN

EN **KLIMAWENT** Just reliably

- I. Turn on the power with the main switch Q1 see 7.2.1.5 TURNING THE MAIN POWER OFF on page. 48.
- J. The device is now ready for use.

! CAUTION



Opening the filter access door SWITCHES OFF the device!

! WARNING



DO NOT DEFORM the filters when pressing them by excessive squeezing – this may lead to bad adhesion of the gasket and/or damage to the filters in the form of e.g., kinks or perforation of the filter paper!

7.2.4. FILTER REGENERATION

The filter regeneration process takes place automatically during operation and is controlled by the device controller mounted in the device's electrical unit. The process of releasing the impulse of compressed air is determined by the time parameters coded in the controller, and they have been adjusted to the average (standard) operating conditions of **UFO-A-N(/R)** type devices.

! WARNING



DO NOT CHANGE the filter regeneration parameters without consulting the manufacturer. To adjust the parameters to the specific operating conditions of the device, **CONTACT** the manufacturer of **KLIMAWENT S.A.**

7.2.5. EMPTYING DUST CONTAINER

During operation, it is necessary to control the state of filling of the dust tank. For this purpose, there are visors on both sides of the tank. Do not allow overloading with dust - this can cause entrainment of dust during operation.

- A. Turn off the fan and wait until the fan stops and the airflow stops see 7.2.1.4 TURNING FAN OFF on page 48.
- B. Wait until the final filter regeneration cycles are completed and turn off the power with the main switch Q1 see 7.2.1.5 TURNING THE MAIN POWER OFF on page 48.
- C. Remove the buckles securing the container and slide it out.
- D. Empty and clean the container from possible permanent dirt.
- E. Slide the container into the same place and tighten the buckles. Check the correctness of pressure and tightness. If necessary, adjust the buckles.
- F. Turn on the power with the main switch Q1 see 7.2.1.2 TURNING THE MAIN POWER ON on page 48.
- G. The device is ready for operation.

KLIMAWENT

EN

! WARNING



REACT immediately to alarm signals displayed by the control unit and take immediate **CORRECTIVE ACTION**!

7.2.6.1. ENGINE FAILURE – STANDARD SWITCHGEAR

In the case of **UFO-A-N** type devices (version with standard power supply – see point 7.2.1.8 – ELECTRICAL APPARATUS – BASIC VERSION on page. 50), in the **ZE-UFO-A-N** electrical switchboard, the fan motor is protected by a **Q1M** motor switch installed.

The **Q1M motor switch protects the fan motor** against overload, short circuit and partial-phase operation. In addition, the fan motor is equipped with a **PTC** sensor, which changes its resistance as the temperature of the motor winding changes. The resistance of the **PTC** sensor is controlled by the **KR1** resistance relay.

If the Q1M switch trips or the PTC resistive relay detects excessive heating of the motor windings, the control system will disconnect the motor power supply circuit and the alarm will be signalled by the illumination of the red H3 "ALARM ENGINE" lamp. When this alarm occurs, check the condition of the motor electrically and mechanically.

Triggering the alarm results in blocking the system's operation until the alarm disappears. The system is ready to work again.

7.2.6.2. ENGINE FAILURE – SWITCHGEAR WITH INVERTER

In the case of **UFO-A-N/R** devices (inverter-controlled version – see point 7.2.1.9 – ELECTRICAL APPARATUS – INVERTER VERSIONon page 51), in the **ZE-UFO-A-N/R** electrical switchboard, the inverter power supply circuit is protected by a switch engine **Q1M**.

The **Q1M motor switch protects the inverter** against overload, short circuit and partial-phase operation. Additionally, the fan motor is equipped with a **PTC** sensor that changes its resistance as the motor winding temperature changes. The resistance of the **PTC** sensor is controlled by the **inverter**.

If the **Q1M switch trips** or the **inverter** detects an error, the control system will disconnect the motor power circuit, and the alarm will be signalled by the illumination of the red **H3 "ENGINE ALARM"** lamp. After this alarm occurs, check the motor's electrical and mechanical condition and read the messages displayed on the inverter's screen for a possible error code.

Triggering the alarm results in blocking the system's operation until the alarm disappears. After removing the cause of the failure, the **system should be restarted** by restoring the power supply. The system is ready to work again.

7.2.6.3. INVERTER ERROR CODES

INFORMATION

Description of error codes - INVERTER user manual - see appendix A of this manual.



7.2.6.4. CONTROLLER ALARM CODES

INFORMATION



Description of alarm codes - CONTROLLER user manual - see appendix B of this manual.

7.2.7. EMERGENCY STOP

To stop the device in an emergency, press the **S2.2 "STOP"** button (red field) on the electrical unit panel – see Picture 6 on page 14. The green lamp **S2.H2.** will go out. The fan will stop with **a free run** in case of **UFO-A-N** or **after 30 s** in case of **UFO-A-N/R**.

7.2.8. RETURN TO NORMAL OPERATION AFTER THE PROBLEM SOLVED

Starting the device after stopping due to a failure requires performing a check of the device's operation - start the device and let it run for **at least 15 minutes** to stabilize its parameters and make sure there are no problems and the failure does not return. After this time, the device can be "*switched on*" back to the technological process.

Restart the following points 7.2.1.2 – TURNING THE MAIN POWER ON on page 49 and 7.2.1.3 – TURNING FAN ON on page 49 and take into account all the guidelines presented in the table "Table 2 Safety rules and residual risk information" – see point 4.5 – RESIDUAL RISK INFORMATION on page 23.

7.2.9. UNPLANNED STOPPING AND RESTARTING

In the event of a power failure, the fan will stop with a free run in both cases for **UFO-A-N** and **UFO-A-N/R**. In the case of **UFO-A-N/R**, despite the inverter control, the fan will stop automatically due to a power failure.

In such a situation, before restarting, first, check the condition of the device to see if the electrical devices in the electrical unit are functional and undamaged and if no **error codes have appeared on the inverter** or **alarm codes on the controller**.

The device should be started and run for **at least 15** minutes to stabilize its parameters and make sure there are no problems. After this time, the device can be "*turned on*" back to the technological process.

Perform the restart according to point. 7.2.1.2 – TURNING THE MAIN POWER ON on page 48 and 7.2.1.3 – TURNING FAN ON on page 48 and take into account all the guidelines provided in table "Table 2 "Safety rules and information on residual risks – see point 4.5 – RESIDUAL RISK INFORMATION on page 23.

7.3. PERSONAL PROTECTION MEASURES

When operating, maintaining and cleaning, i.e. using, cleaning the container from sludge and deposits, cleaning the inside of the tank and other similar activities, always wear personal protective equipment – see point 4.3 – REQUIRED PERSONAL PROTECTION on page 21.



59 / 114

8. MAINTENANCE AND REPAIR MANUAL

8.1. **GENERAL GUIDELINES**

! WARNING



DISCONNECT the unit from the power supply, TURN OFF the controls and WAIT until all mechanisms stop. SECURE the control against uncontrolled start-up!



USE personal protective equipment, protective clothing and work shoes - see point 4.3 -REQUIRED PERSONAL PROTECTION on page 21! DIRECTLY follow safety precautions - see guidelines in point 4.5 - RESIDUAL RISK INFORMATION on page 23.

! CAUTION



The **USER** is responsible for maintaining the device and its parts. Systematic maintenance is a condition for safe use and fulfilment of the WARRANTY CONDITIONS.



All repairs **ARE PERFORMED BY THE MANUFACTURER** or its **REPRESENTATIVE**. In special cases, this can be done by the USER, but in this case, you should contact the manufacturer KLIMAWENT.

8.2. **MAINTENANCE SCHEDULE**

Table 5 Recommended inspection and maintenance intervals

Period	Procedure			
Ongoing control and activities	Regularly clean the device and its components to avoid excessive build-up of dust inside and out. Remove the dust from the container and remove any deposits.			
Once every 1 month	Check the condition and tightness of the connections of the ventilation system connecting the device with the installation on the suction and discharge sides. Drain the condensate from the compressed air tank.			
Once every 3 ÷ 6 month	Perform a visual inspection of the load-bearing structure and housing, as well as the condition of bolted connections and tightness, and close the inspection covers.			
	Clean the noise silencers mounted on the impulse valves.			
	Check the condition of the electrical connections and installations of the compressed air network and pressure vessel and the connection of electrical impulse valves.			
	Clean and check the condition of the fan and the fan motor following the recommendations of the motor manufacturer.			
Once every 12-18 months	Check the continuity of the protective connection and the connection of the device to the main earthing bar.			
	Check the condition of the inside of the filter chambers. Additionally, inspect the chambers behind the filters on the "clean" side by unscrewing the inspection covers on the side of the device. Check that there is any contamination on the "clean" side of the device – see 8.2.1 – CARTRIDGE FILTER MAINTENANCE on page 60. Remove any accumulated deposits.			
Once even 18 to 24 menths	Check the condition of the electric motor, pneumatic system components and pulse solenoid valves. Carry out maintenance according to the instructions of the pulse valve manufacturer.			
Once every to to 24 months	Replace the cartridge filters with new ones or when the filters are worn out, i.e. despite manual or mechanical regeneration of the filters, the device does not return to the rated capacity.			

KLIMAWENT Just reliably

8.2.1. CARTRIDGE FILTER MAINTENANCE

- A. The visual inspection of the cartridge filters should be performed at each operation of removing dust from the container under the chute. Check the correct installation of the filters and the condition of the filtering surface – the degree of contamination, the presence of damage or foreign bodies, sticky and difficult-to-remove deposits, moisture, etc.
- B. When you notice a noticeable decrease in the efficiency of the device, which persists for a longer period, regardless of the operation of the filter regeneration system, remove the filters from the device and clean them manually or mechanically using a device designed for this purpose contact the manufacturer of **KLIMAWENT S.A.**
- C. The filter check should also be performed when there are other irregularities in the operation of the device. In the event of normal wear or damage or perforation, replace the cartridge filter with a new one see 8.5 SPARE PARTS on page 63.
- D. When replacing filters, place them on guides and push them against the rear wall of the chamber. Apply pressure to the threaded studs, tighten and tighten with star-shaped knobs. Tighten so that the filter cannot be turned around its axis. Do not deform the filter paper! Then close the access door tightly and tighten the bolts.

! CAUTION



Both too weak and too strong pressing of the filters may cause dust to get to the "clean" side of the device. Tightening it too lightly will cause dragging of impurities between the filter gasket and the device's partition while pressing too much may distort the filter, damaging the filter paper and leading to its perforation and contamination entering the "clean" side of the device.

! WARNING



MOISTURE or **OIL** contained in the transported air and in the air used to regenerate the filters **CAN DAMAGE** the filters! The device **MUST** be connected to the compressed air network prepared by appropriate filtering and reducing unit with a pressure ranging from **0.6** to **0.8 MPa** and meeting the purity conditions specified in point 6.3.2 – COMPRESSED AIR CONNECTION on page 38.

8.2.2. MAINTENANCE OF THE DUST CONTAINER

The dust container is the most exposed element to the deposition of dust and hard fractions that can permanently stick to internal surfaces therefore, its condition should be regularly checked.

The container has a seal on the edge, which may be damaged during use. If damaged, replace it with a new one. For this purpose, contact the manufacturer **KLIMAWENT S.A.**

8.2.3. MAINTENANCE OF THE COMPRESSED AIR TANK

The compressed air tank must be checked and maintained following the regulations for pressure equipment. All connections of the tank should be checked periodically, and the tank should be drained through a stub pipe installed for this purpose in the lower stub pipe. If damaged, replace it with a new one. For this purpose, contact the manufacturer **KLIMAWENT S.A.**

8.2.4. MAINTENANCE OF PULSE VALVES

The applied solenoid valves do not require ongoing maintenance. You only need to check the condition of electrical connections, grounding and tightness of the pneumatic system. If damaged, replace it with a new one. For this purpose, contact the manufacturer of **KLIMAWENT S.A**

KLIMAWENT

EN

8.2.5. FAN MAINTENANCE

- A. Check the correctness and accuracy of the tightening of mechanical and electrical connections.
- B. Check the condition of the impeller and inside of the fan and detect and remove any accumulated dirt and foreign matter. To do this, dismantle the attached installation and the elbow. Perform a visual inspection of the interior. Secure the device against unintentional switching on or rotation of the impeller as a result of induced airflow!
- C. Check the impeller's alignment with the inlet stub (the uniform distance around the entire circumference between the impeller inlet and the fan inlet stub). For this purpose, look under the fan by removing the inspection cover of the regeneration chamber of the fan.
- D. If vibrations or noise occur during fan operation, measure the vibrations on the motor (see point 8.4 MEASURING VIBRATIONS OF THE FAN on page 62) and check whether the rotor elements are in contact with the inlet stub pipe or other housing elements. In the event of excessive vibration, deformation and/or damage, contact the manufacturer of KLIMAWENT S.A. without delay. to replace parts with new ones.

! WARNING



It is **FORBIDDEN** to use the machine with a damaged motor or impeller or show excessive vibrations during operation. This can lead to impeller or motor damage, fire or explosion due to sparking!

8.3. SERVICE AND REPAIR

! CAUTION



The **USER** is responsible for the maintenance of the device and its parts. Regular maintenance is a prerequisite for safe use and compliance with the **WARRANTY CONDITIONS**.



Any repairs are **MADE BY THE MANUFACTURER** or his **REPRESENTATIVE**. In special cases, it may be performed by the **USER**, but in this case, please contact the manufacturer of **KLIMAWENT S.A.**

KLIMAWENT Just reliably

8.4. MEASURING VIBRATIONS OF THE FAN

Pomiar Measurement of fan vibrations should always be performed before the first start-up of the device in the installation or during the maintenance inspection according to the schedule for the given type of device. Nevertheless, it is recommended to constantly monitor the fan vibration with a sensor or to carry out vibration measurements during fan inspections every **4,000 operating hours** or in the event of increased noise, vibrations and other symptoms indicating a possible defect.

Before measuring vibrations, allow the device to run for **at least 15 minutes** to stabilize its operating parameters, assuming that the fan is powered by electricity of **rated voltage**, **frequency** and the appropriate **number of phases**.

8.4.1. DIRECTION AND PLACE OF MEASURING VIBRATIONS

The vibration values should be measured in two mutually perpendicular directions on the motor body in each bearing location and one perpendicular to the other, i.e. one of these directions is to be parallel to the axis of rotation of the motor shaft and the other two directions should be in a plane perpendicular to this axis.

The measurement perpendicular to the axis of rotation should be made in the plane of the lower and upper motor bearings in two or three mutually intersecting directions. It should be noted that the measurement in the plane of the upper bearing should be performed on the housing, i.e. before the measurement, if possible, remove any non-rigid motor covers, and if it is not possible, perform the measurement just below.

The measurement of vibrations parallel to the axis of rotation should be performed on the motor flange or the fan housing right next to the motor.

8.4.2. VIBRATION LIMITS

The measurement result should be compared with the limit values recommended by **ISO 14694:2003**. The value of measured vibrations expressed as velocity **Vrms** should not exceed **Vrms = 6.3 mm/s**. Measured values with a value above **Vrms = 11.8 mm/s** are considered alarming, while values above **Vrms = 12.5 mm/s** qualify for an immediate **stop** of the device.

		Flexible attachment		Rigid attachment	
	Peak [mm/s]	RMS [mm/s]	Peak [mm/s]	Peak [mm/s]	
	↓				
	Start-up	6.4	4.5	8.8	6.3
Operation		\checkmark			
		10.2	7.1	16.5	11.8
			Maintenan	ce / Repair	
	Emergency shutdown	12.7	9.0	17.8	12.5

Just reliably **KLIMAWENT EN**

8.5. SPARE PARTS

If one of the device parts is worn out, contact the manufacturer of KLIMAWENT S.A.

Any requests for information or repair work or inquiries regarding spare parts should be directed to:

KLIMAWENT S.A. Chwaszczyńska 194 street 81-571 Gdynia POLAND Phone: +48 58 629 64 80 Fax: +48 58 629 64 19

e-mail: klimawent@klimawent.com.pl

Туре	Catalogue No.	Diameter [mm]	Height [mm]	Mass [kg]	Comments
POH306638U	800F18	Ø380	660	4,5	Standard replacement frequency – 1 to 2 years

! INFORMATION



At the customer's request, the manufacturer **KLIMAWENT S.A.** can equip the device with **filters with non-woven fabric impregnated with active carbon** for additional filtration of gases generated in welding processes! The use of this type of filter increases the absorption of unpleasant odours generated in various technological processes



At the customer's request, the manufacturer **KLIMAWENT S.A.** can provide the **UN-1** sputtering system (see point 6.5 – ADDITIONAL EQUIPMENT on page 44) for sputtering filters with CaCO3 synthetic calcium carbonate, which protects filters by extending their service life by creating a protective layer that reduces sticking of sticky substances. In addition, it increases the safety of operation in dedusting systems installed in many industries.

! CAUTION



The additional equipment is not installed in the device as standard. Additional equipment is delivered on a separate order.

9. WORK DISRUPTIONS, CAUSES, REMEDIES

L.p.	Disruptions	Potential causes	Remedies	
1.		Activation of the Q1M switch.	Check the condition of the electric motor windings.	
2.		the motor supply.	Check if the electric motor is not blocked. Unlock the engine.	
3.		Incorrect power supply. Activation of the CKF relay.	Check for the presence of voltage on the terminals L1, L2, L3, N and PE of the X1 strip. Correct the electrical supply parameters.	
		UFO-A-N		
4.	The fan does not start	Activation of the KR1 relay. An excessive temperature rise of the motor windings.	Check the condition of the electric motor windings.	
		UFO-A-N/R		
5.		Start-up interlock via inwerter.		Check the error code displayed on the inverter and verify the system.
6.		No power.	Check for the presence of voltage on the terminals L1, L2, L3, N and PE of the X1 strip. Correct the electrical supply parameters.	
7.		Damage to the WK switch (WK1 or WK2) at the inspection door of the filtration chamber.	Replace the electric apparatus with a new one.	
8.		Clogged suction port or system.	Check the condition and clean the connector and the installation.	
9.	No or very low fan draft	Filters were contaminated significantly.	Check the condition of the filters. Clean manually or mechanically using a device designed for this purpose or replace the filters with new ones.	
10.		Adherence of sticky or moist dust to the filter surface.	Drain the compressed air tank and check the condition of the compressed air network.	

Table 6 List of sample errors and problems

L.p.	Disruptions	Potential causes	Remedies
11.			Eliminate any source of moisture or sticky substances entering the intake air.
12.			Limit (lower) the temperature of the inlet air below +40°C.
13.	No regeneration pulses or pulses of less force	No power to the solenoid valve.	Check the electrical connections at the valve, electrical switchboard and junction box on the device.
14.		Closed or closed valve supplying compressed air to the tank.	Open the valve.
15.		Too low pressure of compressed air in the tank due to slow filling from the system or low pressure in the system.	Adjust the pressure within the range of 0.6 to 0.8MPa.
16.	Dust ingress into the discharge system	Perforation or loosening of the cartridge filter mounting or damage to the pressure seal.	Replace the filters with new ones or correct the mountings.
17.		Too much dust load on the device.	Limit the amount of dust drawn in by the device to 3 g/m3.
18.		Dust type is not provided for in the intended use of the device.	Contact the manufacturer KLIMAWENT S.A.

10. DISMANTLING, DECOMMISSIONING AND DISPOSAL

10.1. DISASSEMBLY AND DECOMMISSIONING

After the period of use, when decommissioning the device, the device should be disassembled and disassembled following general health and safety and PP regulations, paying special attention to internal elements and potentially hazardous substances accumulated inside. Use personal protection measures such as those mentioned in point 4.3 – REQUIRED PERSONAL PROTECTION on page 21. Follow the recommendations set out in point 4.2 – SAFETY RULES AND APPLICATION RESTRICTIONS on page 19.

10.2. DISPOSAL, SCRAPPING AND RECYCLING

! CAUTION



At the time the product is taken for disposal, the regulations **must be complied** with for the disposal of end-of-life machinery and/or waste recycling.

! WEEE

The symbol shown here indicates that the product marked with it must not be disposed of as unsorted municipal waste. Such a product must go to a separate collection point, where it will be recovered and recycled. The **WEEE** label is placed on every electrical and electronic equipment placed on the EU market.



Some parts of the **UFO-A-N** device must be treated following the recommendations of the European Parliament Directive **2012/19/EU** on Waste Electrical and Electronic Equipment (**WEEE**). These are the elements included in the electrical switchgear, in particular, the control panel with the microcontroller and the display.

Such parts **MUST NOT** be thrown into the unsorted waste bin but should be taken to a special collection point for used electrical and electronic equipment!



The warranty period is specified in the Warranty Card of the device.

! CAUTION



FAILURE TO OBSERVE the recommendations of this manual, and especially if the device is arbitrarily modified or used contrary to its intended use, the **WARRANTY WILL BE LOST**!

! CAUTION



The user is **MANDATORY** to measure the operating parameters of the device during the first startup. **FILLING IN** and **SENDING** the **STURT-UP PROTOCOL** to the manufacturer is a condition of **FULFILLMENT OF THE WARRANTY CONDITIONS** – see point 14 – START-UP PROTOCOL on page 111.

12. DRAWINGS AND SKETCHES

12.1. DRAWING of UFO-A-5000-N(/R)



Picture 38 Overall dimensions of the device UFO-A-5000-N(/R)-RH (with an inlet on the right)

Just reliably **KLIMAWENT**



Picture 39 Overall dimensions of the device UFO-A-5000-N(/R)-LH (with an inlet on the left)









Picture 40 Overall dimensions of the device UFO-A-10000-N(/R)-RH (with an inlet on the right)

Just reliably **KLIMAWENT**



Picture 41 Overall dimensions of the device UFO-A-10000-N(/R)-LH (with an inlet on the left side)

EN







Picture 42 Overall dimensions of the device UFO-A-15000-N(/R)-RH (with an inlet on the right)




Picture 43 Overall dimensions of the device UFO-A-15000-N(/R)-LH (with an inlet on the left)







Picture 44 Overall dimensions of the device UFO-A-20000-N(/R)-RH (with an inlet on the right)





Picture 45 Overall dimensions of the device UFO-A-20000-N(/R)-LH (with an inlet on the left)

12.5. SKETCH of THE SWITCHBOARD UFO-A-N and UFO-A-N/R

12.5.1. SWITCHBOARD of UFO-A-N



Picture 46 Electrical switchgear facade for equipment type UFO-A-N

Q1 – Main switch



Picture 47 LEFT side of electrical switchgear for equipment UFO-A-N

Q1 – Main switch



Picture 48 Interior appearance of electrical switchgear with standard 3x400V supply and Y-Δ type startup for UFO-A-N type device

Q1 – Main switch; Q1M – Motor circuit breaker; F1 – Overcurrent circuit breaker;
K1M, K2M, K3M – Contactors; K1T – Time transmitter; CKF – Phase controller;
KR – Resistance relay; K1, K2 – Electromagnetic relays; B1 – Controller



12.5.2. SWITCHBOARD of UFO-A-N/R

Picture 49 Electrical switchgear facade for devices UFO-A-N type/R

Q1 – Main switch





LEFT SIDE

RIGHT SIDE



Q1 – Main switch

Just reliably **KLIMAWENT EN**



Picture 51 Interior view of electrical switchgear with standard 3x400V power supply and Y-Δ start for UFO-A-N type device

Q1 – Main switch; Q1M – Motor circuit breaker; FAL1 – Inverter; F1 – Overcurrent circuit breaker;
CKF – Phase control; K1, K2, K3 - Electromagnetic relays; TH – Thermostat;
B1 – Controller; G1 - Ventilating fan

13. ELECTRICAL DIAGRAMS

13.1. DIAGRAM of UFO-A-5000-N



Diagram 1 UFO-A-5000-N, pt. 1 of 4



Diagram 2 UFO-A-5000-N, pt. 2 of 4

EN C KLIMAWENT Just reliably



Diagram 3 UFO-A-5000-N, pt. 3 of 4

Filtering devices UFO-A-N and UFO-A-N/R





13.2. DIAGRAM of UFO-A-5000-N/R



Diagram 5 UFO-A-5000-N/R, pt.1 of 3



EN



Diagram 6 UFO-A-5000-N/R, pt. 2 of 3

87 / 114



Diagram 7 UFO-A-5000-N/R, pt.3 of 3





Diagram 8 UFO-A-10000-N, pt. 1 of 4



Diagram 9 UFO-A-10000-N, pt. 2 of 4





EN KLIMAWENT Just reliably







Diagram 12 UFO-A-10000-N/R, pt.1 of 3



Diagram 13 UFO-A-10000-N/R, pt. 2 of 3















EN C KLIMAWENT Just reliably















Diagram 20 UFO-A-15000-N/R, pt. 2 of 3







Diagram 22 UFO-A-20000-N, pt. 1 of 4







EN KLIMAWENT Just reliably









Diagram 26 UFO-A-20000-N/R, pt. 1 of 3



Diagram 27 UFO-A-20000-N/R, pt. 2 of 3






START-UP PROTOCOL

! CAUTION



The user is MANDATORY to measure the operating parameters of the device during the first startup. FILLING IN and SENDING the protocol to the manufacturer is a condition of the FULFILLMENT OF THE WARRANTY CONDITIONS.

START-UP PROTOCOL

"Filtering devices and installations"					
	Date:, hour:				
The person drawing up the report:		5	Structure:		
		/	Address:		
		(Contact person:		
The name of the device:		Serial number	:	Type/model:	
Description of the place of installa	ation of the device. list of supported devi	ces/rooms:			
<i>Type of electric unit:</i> O integrated O internal swite	chboard \bigcirc switchboard on the device	e O swit	tchgear outside	the device	
Electric supply:					
\bigcirc through the power s	upply and control cabinet O direct	O other:			
1x230V measured value	V/50HZ 3X400V measured values L1-L2	2	L1-L3I	_2-L3 V/50Hz	
Checking Checking the fas	the operation of the circuit breaker: $\bigcirc \gamma$		O	plicable	
	Wiring test performed: $\bigcirc \gamma$	$ES \bigcirc N$	O O not ap	plicable	
	Supply air damper: O	works correc	ctly O doesn't	work properly O lack	
	Extract air damper: \bigcirc v	works correc	ctly 🔿 doesn't	work properly \bigcirc lack	
Actuators	Recirculation air damper: \bigcirc v	works correc	ctly 🔿 doesn't	work properly \bigcirc lack	
	other: 🔿 v	works corre	ctly 🔿 doesn't	work properly \bigcirc lack	
	Filter pressure switch: O works correctly O doesn't work pr	operly O	setting: lack		
Pressure switches	Filter pressure switch: setting:				
Compressed air preparation unit	Filter unit for cleanliness ISO 8753:2010	D-6:4:4 O	YES O NO		



EN **KLIMAWENT** Just reliably

Pressure transducers					
Fan		Fan motor type, designation, manu Rated power:kW The connection of the windings or Electric supply: O 1x230V,50Hz Starting: O direct O star-d Motor protection switch setting: Inverter settings: - minim - maxim - therm - setting Adjustment: O grad O smo O corr Measured current consumption:	Ifacturer: Rated current: _ the motor: O star Y O 3x400V,50Hz O leita O inverter O othe A um frequency: H num frequency: H al protection setting: g of the rated motor curren dual: gear 1 Hz, g both, of the function: rect direction of rotation	A delta Δ Ο o other er, Hz Hz A ht: A gear 2 of the rotor	
TC/PTC TC – temperature PTC - positive te	e controller emperature	TC of the fan O connect PTC of the fan O connect	ed \bigcirc not connected \bigcirc ed \bigcirc not connected \bigcirc) lack) lack	
Work simulation	Perfor	mance measurement was performed: Full airflow: Minimal airflow: Maximum dustiness:) NO m³/h m³/h g/m³/h		
Working environment	ing onment Location $ \begin{array}{c} \bigcirc \text{ outdoors without a roof} \\ \bigcirc \text{ outdoors with a roof} \\ \hline \text{The distance between the engine ventilator and the partition is maintained:} \\ \bigcirc \text{YES} \bigcirc \text{NO} \\ \hline \text{Preserved work area and communication space:} } \bigcirc \text{YES} \bigcirc \text{NO} \\ \hline \end{array} $		partition is maintained:		
	Training	\bigcirc C arried out \bigcirc not carried	ed out		
	Leader:		Date:		
	Scope o	of the training:			
	\bigcirc use of automation		\bigcirc filter replacement	nt	
	O user's manual of the device		\bigcirc user responsibil	\bigcirc user responsibilities	
	O health and safety conditions		\bigcirc access to contro	\bigcirc access to controlled points	
Training	• failure reporting procedure		\bigcirc complaint proto	○ complaint protocol	
	No.	First name and last name	Positio	n	Signature
	1.				
	2.				
	3. 1				
	- - . 5.				
	6.				
I declare that	at all me with	asurements have been made corr the rules, applicable regulations a	rectly and in compliance and technical standards:	Date and signatur	e of the recording person:

 $\hat{\mathbf{x}}$







User's manual – title: "Filtering devices UFO-A-N and UFO-A-N/R" I0-805UFN-EN-20231115



KLIMAWENT S.A. Poland

Chwaszczynska 194 street, 81-571 Gdynia phone: +48 58 629 64 80 fax: +48 58 629 64 19 e-mail: klimawent@klimawent.com.pl website: www.klimawent.com.pl

klimawent@klimawent.com.pl

Copyright © by KLIMAWENT S.A. Gdynia 2023-11-15

Filtering devices UFO-A-N and UFO-A-N/R





APPENDIX A

To the user's manual: IO-805UFN-EN

Filtering device UFO-A-N/R





The appendix is valid for the following device models:

Catalog No.	Product name
805U24	UFO-A-5000-N/R
805U25	UFO-A-10000-N/R
805U26	UFO-A-15000-N/R
805U27	UFO-A-20000-N/R

Altivar 212

Variable speed drives for synchronous and asynchronous motors

Programming Manual

11/2014





The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2014 Schneider Electric. All rights reserved.

Table of Contents



	Safety Information	7 8
Gen	eral Overview	1
Chapter 1	Setup 1 Steps for setting-up the drive 1	3 4
Chapter 2	Overview1Factory configuration1Preliminary recommendations1Embedded display terminal1Monitoring Mode2Run Mode2Programming Mode2Menu Navigation2Submenus3Graphic display option3Finding a parameter in this document3Detected fault screens3Pre-alarms screens3Modbus communication status3SoMove software3Structure of the parameter tables4Parameters that cannot be changed while the drive is running4Drive Operation4	5 6780334457788904129
Prog	gramming	7
Chapter 3	Quick Menu	; 9 30
Chapter 4	Programming Parameters6Parameter Reset6Macro Programming (AU4)6Parameter Lock6Display of Submenu AUF (F738)6	5 56 57 58 58
Chapter 5	Motor Control Parameters6Motor Control Mode7Other Motor Control Mode Parameters7Motor Tuning7Auto-tuning7Expert parameters7Supply Voltage Correction and Motor Voltage Limitation7	9 10 12 14 15 17 18

	Motor 2 Control Parameters Permanent Magnet Motor Control Law ([PM Control] (РП))	79 81
Chapter 6	Drive Control Parameters	. 87
Chapter 7	Application Parameters Application parameters Application parameters Skip Frequencies DC Injection Braking Parameters Skip Frequencies	. 91 92 97 98
Chapter 8	I/O Control Parameters Logic Inputs Functions Logic Input Function Compatibility Relay Output Functions Analog Input Functions Analog Output Functions Analog Input Adjustments. Active Logic Function Preset Speeds +/- Speed Control Parameters Damper control.	. 99 100 107 108 114 115 116 122 123 124 127
Chapter 9	Display Parameters	129 130
Chapter 10	Detected Fault Management Parameters Time delay Catch On The Fly (F301) Overtorque Detection Nuisance Overvoltage And Input Phase Detected Fault Avoidance Motor Overload Characteristics	133 136 137 143 144 145
Chapter 11	Serial Communication Parameters	147 148 150
Chapter 12	Start/Stop Control By Speed Reference Level	153 154
Chapter 13	Droop Control	155 156
Chapter 14	Functions for ScrollDriving Scroll (F324)Pre-start Scroll (F325)Std Oiling Cycle (F330)Low Speed Oiling (F334)Scroll Protection (F338)Discharge gas (F349)Crankcase heating (F355)	157 160 170 172 173 174 175 176
Diagno	stics and troubleshooting	177
Chapter 15	Diagnostics and troubleshooting	179 180 184 186 187

	Annex
Chapter	16 Migration 191 Migration ATV21 - ATV212 192
Chapter	17 Parameters Reset Tables
Chapter	18 User Settings Tables

Safety Information



Important Information

NOTICE

Please read these instructions carefully and examine the equipment in order to familiarize yourself with the device before installing, operating or carrying out any maintenance work on it.

The following special messages that you will come across in this document or on the device are designed to warn you about potential risks or draw your attention to information that will clarify or simplify a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER indicates an imminently hazardous situation, which, if not avoided, **will result** in death or serious injury.

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.

CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

NOTICE

NOTICE, used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result** in equipment damage.

PLEASE NOTE

The word "drive" as used in this manual refers to the controller portion of the adjustable speed drive as defined by NEC.

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this product. © 2014 Schneider Electric. All Rights Reserved.

About the Book



At a Glance

Document scope

The purpose of this document is to:

- · help you to set-up the drive,
- · show you how to program the drive,
- · show you the different menus, modes and parameters,
- · help you in maintenance and diagnostics.

Validity note

This documentation is valid for the Altivar 212 drive.

Related documents

Title of Documentation	Reference Number	
ATV212 Quick Start	S1A53825	
ATV212 Installation manual	S1A53832	
ATV212 Modbus manual	S1A53844	
ATV212 BACnet manual	S1A53845	
ATV212 Metasys N2 manual	S1A53846	
ATV212 Apogée FLN P1 manual	S1A53847	
ATV212 LonWorks manual	S1A53848	
Multi-Loader manual	BBV48778	
SoMove Mobile manual S1A51444		
ATV212 other option manuals: see www.schneider-electric.com		

You can download the latest versions of these technical publications and other technical information from our website at www.schneider-electric.com.

Standards and Terminology

The technical terms, terminology, and the corresponding descriptions in this manual normally use the terms or definitions in the relevant standards.

In the area of drive systems this includes, but is not limited to, terms such as **error, error message, failure, fault, fault reset, protection, safe state, safety function, warning, warning message**, and so on.

Among others, these standards include:

- IEC 61800 series: Adjustable speed electrical power drive systems
- IEC 61508 Ed.2 series: Functional safety of electrical/electronic/programmable electronic safety-related
- · EN 954-1 Safety of machinery Safety related parts of control systems
- EN ISO 13849-1 & 2 Safety of machinery Safety related parts of control systems.
- · IEC 61158 series: Industrial communication networks Fieldbus specifications
- · IEC 61784 series: Industrial communication networks Profiles
- · IEC 60204-1: Safety of machinery Electrical equipment of machines Part 1: General requirements

Product related information

A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Only appropriately trained persons who are familiar with and understand the contents of this manual and all
 other pertinent product documentation and who have received safety training to recognize and avoid
 hazards involved are authorized to work on and with this drive system. Installation, adjustment, repair and
 maintenance must be performed by qualified personnel.
- The system integrator is responsible for compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.
- Many components of the product, including the printed circuit boards, operate with mains voltage. Do not touch. Use only electrically insulated tools.
- · Do not touch unshielded components or terminals with voltage present.
- Motors can generate voltage when the shaft is rotated. Prior to performing any type of work on the drive system, block the motor shaft to prevent rotation.
- AC voltage can couple voltage to unused conductors in the motor cable. Insulate both ends of unused conductors of the motor cable.
- Do not short across the DC bus terminals or the DC bus capacitors or the braking resistor terminals.
- Before performing work on the drive system:
 - Disconnect all power, including external control power that may be present.
 - Place a "Do Not Turn On" label on all power switches.
 - Lock all power switches in the open position.
 - Wait 15 minutes to allow the DC bus capacitors to discharge. The DC bus LED is not an indicator of the absence of DC bus voltage that can exceed 800 Vdc.
 - Measure the voltage on the DC bus between the DC bus terminals (PA/+ and PC/-) using a properly rated voltmeter to verify that the voltage is < 42 Vdc.
- If the DC bus capacitors do not discharge properly, contact your local Schneider Electric representative. Install and close all covers before applying voltage.
- Failure to follow these instructions will result in death or serious injury.

UNINTENDED EQUIPMENT OPERATION

- Prevent accidental grounding of logic inputs configured for sink logic. Accidental grounding can result in unintended activation of drive functions.
- Protect the signal conductors against damage that could result in unintentional conductor grounding.

Failure to follow these instructions will result in death or serious injury.

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop, overtravel stop, power outage, and restart.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.
- Observe all accident prevention regulations and local safety guidelines (1).
- Each implementation of the product must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

(1) For USA: Additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable Speed Drive Systems."

General Overview

I

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
1	Setup	13
2	Overview	15

Setup

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Steps for setting-up the drive	14

Steps for setting-up the drive

INSTALLATION

1. Please, refer to the installation manual..



PROGRAMMING

2. Apply input power to the drive, but do not give a run command.

3. Configure

- □ the nominal frequency of the motor [Parameter reset] (*L Y P*) = [50 Hz reset] (*I*) if this is not 50Hz,
- □ the motor parameters, page <u>70</u>, only if the factory configuration of the drive is not suitable,
- the application functions in the Drive Control Parameters section, page <u>87</u> and the I/O Control Parameters section, page <u>99</u>, only if the factory configuration of the drive is not suitable.

4. Adjust the application parameters

- □ [Acceleration time 1] (ACC), page <u>93</u> and [Deceleration time 1] (dEC), page <u>93</u>.
- □ [Low limit frequency] (LL), page <u>92</u> and [Upper limit freq] (UL), page <u>92</u>.
- □ [Motor thermal prot.] (tHr), page <u>74</u>.
- 5. Start the drive

Tips:

- Before beginning programming, complete the customer setting tables, page <u>203</u>.
- Perform an auto-tuning operation to optimize performance, page <u>75</u>.
- If you get lost, return to the factory settings, page <u>66</u>.

Overview

2

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Factory configuration	16
Preliminary recommendations	17
Embedded display terminal	18
Monitoring Mode	20
Run Mode	23
Programming Mode	23
Menu Navigation	24
Submenus	34
Graphic display option	35
Finding a parameter in this document	
Detected fault screens	
Pre-alarms screens	38
Modbus communication status	38
SoMove software	
Structure of the parameter tables	
Parameters that cannot be changed while the drive is running	
Common control schemes	
Drive Operation	

Factory configuration

Drive factory settings

The Altivar 212 is factory-set for the most common operating conditions:

- [Mot cont. mode sel.] (*P L*): [Variable torque] (*P L* = *I*). See page <u>71</u>.
- [Upper limit freq] (*U L*) = 50.0 Hz. See page <u>92</u>.
- [Low limit frequency] (L L) = 0.0 Hz. See page <u>92</u>.
- [Switch. freq. level] (F 3 0 0): depending on drive rating (see page 95)
- [Auto ramp] (*A U I*) = [Enable] (*A U I* = *I*). See page <u>95</u>.

Parameter which depends on Macro Programming [Auto set function] ($P \sqcup Y$) = \Box (see page <u>67</u>):

- Command reference: logic inputs ([Command mode sel] ([□ □ □]) = 0). See page 87.
- Speed reference: analog input VIA = 0–10 V or 0–20 mA ([Frequency mode sel] (F □ □ d) = 1, (F 2 □ I)= 0).
 See [Frequency mode sel] (F □ □ d) page 87 and Analog Input Speed Reference page 116.
- F: run forward (F | | |= 2). See [LI F selection] page 100.
- R: preset speed 1 (F / / 2 = 6). See [LI R selection] page 100.
- RES: clear detected fault (F / / 3 = 10). See [LI RES selection] page 100.
- Drive ready for operation (F | | D = 1). See [Logic Funct 2 active] page <u>122</u>.

If the above values are compatible with the application, the drive can be used without changing the settings.

Preliminary recommendations

NOTICE

INCOMPATIBLE LINE VOLTAGE

Before turning on and configuring the drive, ensure that the line voltage is compatible with the supply voltage range shown on the drive nameplate. The drive may be damaged if the line voltage is not compatible. **Failure to follow these instructions can result in equipment damage.**

Power switching via line contactor

NOTICE

RISK OF DAMAGE TO THE DRIVE

- Avoid operating the contactor frequently.
- Power cycling must be MORE than 60 seconds.

Failure to follow these instructions can result in equipment damage.

User adjustment and extension of functions

- The display unit and buttons can be used to modify the settings and to extend the functions described in the following pages.
- Return to factory settings is made easy by the [Parameter reset] (E Y P) (see page <u>66</u>).

A DANGER

UNINTENDED EQUIPMENT OPERATION

Check that changes made to the settings during operation do not present any danger.

We recommend stopping the drive before making any changes.

Failure to follow these instructions will result in death or serious injury.

Test on a low power motor or without a motor

- In factory settings mode, [Output phase loss] (F 6 0 5) (page <u>140</u>) is active F 6 0 5 = 3. To check the drive in a test or maintenance environment without having to switch to a motor with the same rating as the drive (particularly useful in the case of high power drives), set F 6 0 5 to 0.
- Set [Mot cont. mode sel.] (*P L*) = [Constant V/Hz] (*D*) (see page <u>71</u>).

NOTICE

UNINTENDED EQUIPMENT OPERATION

Motor thermal protection will not be provided by the drive if the motor 's nominal current is 20% lower than that of the drive. Find an alternative source of thermal protection.

Failure to follow these instructions can result in equipment damage.

Using motors in parallel

• Set [Mot cont. mode sel.] (P L) = [Constant V/Hz] (D) (see page 71).

NOTICE

RISK OF DAMAGE TO THE MOTOR

Motor thermal protection is no longer provided by the drive. Provide an alternative means of thermal protection. Failure to follow these instructions can result in equipment damage.

Using in single phase supply

• Set [Input phase loss] (F & D B) to Disabled D (see page 138).

NOTICE

RISK OF DAMAGE TO THE DRIVE

Using ATV212 in single phase supply is only allowed in training mode with motor and without load. **Failure to follow these instructions can result in equipment damage.**

Embedded display terminal

This section describes the features of the integrated display terminal.

Embedded display terminal features



	LED/Key	Characteristics
1	Display RUN LED	Illuminates when a run command is applied to the drive.
		Flashes when there is a speed reference present with a Run command.
2	Display PRG LED	Illuminates when Programming mode is active.
		Flashes in <i>RUF</i> , <i>GrU</i> modes
3	Display MON LED	Illuminates when Monitoring mode is active.
		Flashes in detected fault history display mode
4	Display unit	4 digits, 7 segments
5	Display unit LED	The % LED illuminates when a displayed numeric value is a percentage.
		The Hz LED illuminates when a displayed numeric value is in hertz.
6	UP/DOWN keys	Depending on the mode, you can use the arrows to:
		Navigate between the menus
		Change a value
		Change the speed reference when the UP/DOWN LED (7) is illuminated
7	UP/DOWN LED	Illuminates when the navigation arrows are controlling the speed reference
8	Loc/Rem LED	Illuminates when Local mode is selected
9	MODE	Press to select the embedded display terminal mode.
		Run mode (default on power-up)
		Programming mode
		Monitoring mode
	=	Can also be used to go back to the previous menu.
10	Loc/Rem	Switches between Local and Remote modes
11	ENT	Press to display a parameter's value or to save a changed value.
12	RUN LED	Illuminates when the Run key is enabled
13	RUN	Pressing this key when the RUN LED is illuminated starts the drive.
14	STOP	Stop/reset key.
		In Local mode, pressing the STOP key causes the drive to stop based on the setting of parameter [Loc.
1		mot stop mode] ($F \neg 2$ I).
1		In Remote mode, pressing the STOP key causes the drive to stop based on the setting of parameter
1		[Ext. fault stop Mode] (F 6 0 3). The display will indicate a flashing "E".
1		If [HMI reset button] (F 1 3 5) is set to 0, pressing the stop key twice will reset the drive, if the detected
1		Tault condition has been cleared.

An optional graphic display option (VW3A1101) is also available.

Embedded display terminal modes

The Altivar 212 embedded display terminal has three modes of operation: Monitoring, Run and Programming. The drive powers up in the Run mode. To select a different mode, use the MODE key as illustrated below.



The red LED in left side of the display indicates the current mode selected, RUN for Run mode, PRG for Programming mode and MON for Monitoring mode.

Monitoring Mode

The Monitoring mode displays drive operational data in real time. To access the Monitoring mode, press the MODE key until the MON LED is illuminated. Then use the UP and DOWN keys to view up to 30 different types of data.



Monitoring Mode Displays

Display example	Display on graphic terminal	Description
	[Direction]	E = = [Eonward]
FF-F		F = F = [Poweree]
		Commond for more to drive, displayed either on the or in system white of
F 6 U. U	[Speed reference]	Command frequency to drive, displayed either as Hz or in custom unit set
		by parameter [Customized freq val] (F T U Z)
	[Motor current]	The average of the 3 phases of motor current displayed either as amperes
		or as a percentage of the drive's nameplate-rated output current. Select %
		or A with parameter [Unit value selection] (F TU T).
9 100	[Line voltage]	I he average of the 3 phases of line to line input voltages displayed either
		In volts or as a percentage of the drive's rated input voltage (200 v for
		208/240 V models - 400 V for 480 V models). Select % or volts with param-
	[Motor voltogo]	The sucross of the 2 shapes of line to line output voltages displayed either
		The average of the 5 phases of the drive's reted output voltages displayed either
		200/240 V models 400 V for 480 V models). Sologt % or volta with param
		eter [] Init value selection] (E 7 0 1)
9 6 7	[Motor torque %]	Estimated motor torque as a percentage of the motor's rated torque
		Estimated motor torque as a percentage of the motor's rated torque
c 90	[Torque current]	The average of the 3 phases of torque-producing motor current displayed
		entrer as amperes or as a percentage of the motor's rated torque-producing
		The meter surrent as a percentage of the drive's reted sutput surrent, which
		The motor current as a percentage of the drive's fated output current, which may be reduced from the drive's namenlate current rating by adjustments
		in switching frequency
		drive input newer displayed in accordance with parameter [Power cons
		unit (E 749)
U 76		drive output power displayed in accordance with parameter [Power cons
בו ח		unit (E 7 4 8)
	[Motor frequency]	Motor operating frequency, displayed either as Hz or in custom unit set by
	[Motor frequency]	narameter [Customized freq val] (E 70.2)
	[Logic input man]	
		ON: / // // The bar representing VIA is dis-
		OFF: $($ $($ $)) () ($
		<u> </u>

Display	Display on graphic terminal	Description
example		
0. 1	[Relay map]	OFF:,
u 10 1	[CPU CTRL ver.]	CTRL version 101
u c 0 1	[CPU MMI ver.]	MMI version 1.0
uED I	[Memory ver.]	Version of memory
d50.0	[PID feedback]	Level of PID feedback, displayed either as Hz or in custom unit set by parameter [Customized freq val] (F 7 0 2)
670.0	[PID computed ref.] speed reference	Speed reference command to drive as computed by the PID function, dis- played either as Hz or in custom unit set by parameter [Customized freq val] (F 7 D 2)
h85	[Total input power]	Accumulated input power consumed by the drive displayed in kWh
H 7 5	[Total motor power]	Accumulated output power supplied by the drive displayed in kWh
A 16. S	[Drive out. rat. cur. A]	Drive nameplate rated output current in amperes
1500	[Motor speed rpm]	Motor speed in rpm
N S D	[Comm. counter 2]	Displays the counter numbers of communication through the network
n 5 D	[Comm. counter 1]	Displays the counter numbers of communication only at normal state in every communication through the network
nErr	[Past fault] Examples: - 1 blink Err5 - 2 blink Err5 - 3 blink CFI2 - 4 blink nErr	The most recent detected fault stored in the detected fault history. If the drive is in a detected fault state, this is not the active detected fault. A detected fault is stored in the detected fault history after it is cleared by clear detected fault action. Press ENT to review drive state at time of detected fault. See "Detected fault Display and History" on page <u>21</u> and "Diagnostics and troubleshooting" on page <u>179</u> for more detail. There are 4 detected faults recorded. The detected fault 4 is cleared when a new detected fault appears.
ΠΙ	[Drive service alarm]	ON: / OFF: , Cumulative Operation Time Cooling fan DC Bus capacitor
ПЪтт	[Mdb com stat]	ON: / OFF: , RJ45 Rx QpenStyle Tx OpenStyle Rx RJ45 Tx
EO. 10	[Drive run time 100h]	Cumulative drive run time. 0.01 = 1 hour. 1.00 = 100 hours

Detected fault display and history

When the drive detected faults, the graphic terminal displays a code. To review data about drive operation at the time of the detected fault, press the MODE key to enter the Monitoring mode. Then use the Up/Down keys to scroll through the data listed in table page <u>20</u>.

Up to five detected faults can be displayed on the graphic terminal in Monitoring mode: the present detected fault (if the drive is in a detected fault state) and the previous four detected fault codes. To review drive operation data recorded at the time of detected fault for a previous detected fault, press ENT when the code for the detected fault is displayed. See table below for the available information.

When a detected fault is cleared or power is cycled to the drive, the present detected fault becomes Past detected fault 1.

Detected fault History

Display	Display on graphic terminal	Description
n 2	[Comm. counter 1]	Number of times in succession that this particular detected fault has oc-
		curred
o 6 0. O	[Motor frequency]	Motor operating frequency, displayed either as Hz or in custom unit set by
		parameter [Customized freq val] (F 7 0 2)
Fr-F	[Direction]	F r - F = [Forward]
		F r - r = [Reverse]
F60.0	[Speed reference]	Command frequency to drive, displayed either as Hz or in custom unit set
		by parameter [Customized freq val] (F 7 0 2)
C 8 O	[Motor current]	The average of the 3 phases of motor current displayed either as A or as a
		percentage of the drive's nameplate-rated output current. Select % or A
		with parameter [Unit value selection] (F 7 0 1).
9 1 0 0	[Line voltage]	The average of the 3 phases of line to line input voltages displayed either
		in volts or as a percentage of the drive's rated input voltage (200 V for
		208/240 V models - 400 V for 480V models). Select % or volts with param-
		eter [Unit value selection] (F 7 D I).
P 100	[Motor voltage]	The average of the 3 phases of line to line output voltages displayed either
		in volts or as a percentage of the drive's rated output voltage (200 V for
		208/240 V models - 400 V for 480 V models). Select % or volts with param-
		eter [Unit value selection] (F 7 0 1).
11	[LOGIC INPUT MAP]	
	Logic input map	OFF: / / // The bar representing VIA is
		VIA / / F displayed only if
		R = 102
		\
0. 1	[Relay map]	ON: /
		FL LRYA-RYC
EO. 10	[Drive run time 100h]	Cumulative drive run time. 0.01 = 1 hour. 1.00 = 100 hours

I/O Map

In both the monitoring mode and the detected fault history, it is possible to view the state of the logic inputs and the relay outputs. See previous tables on pages $\frac{20}{21}$ and $\frac{21}{21}$.

Logic Input Map



The ON or OFF status of each logic input is displayed in bits. VIA is included in this display if parameter *F* 109 is set to either 1 or 2.

Relay Output Map



The ON or OFF status of each relay output is displayed in bits.

Run Mode

To access the Run mode, press the MODE key until the drive operating frequency, a detected fault code, or a pre-alarm code is displayed.

See Diagnostics and troubleshooting beginning on page <u>179</u> for the detected fault and pre-alarm codes.

Changing the Display in Run Mode

Motor operating frequency is the default value displayed on the graphic terminal in Run mode. This displayed value can be changed by setting parameter [Displayed param.] (F 7 I \square). See page 130 for a list of the display choices.

The displayed value can be expressed as a percentage of the drive rating, or in amperes or volts, as appropriate for the value displayed. The units can be changed by setting parameter [Unit value selection] (F 7 D I) (see page 130).

In addition, the resolution of the speed reference and output frequency displays can be adjusted by setting parameters [Loc. speed ref. step] ($F 7 \square 7$) and [Display ref. resol.] ($F 7 \square B$) (see pages <u>87</u> and <u>130</u>).

Programming Mode

Use this mode to program the drive.

To access the Programming mode, use the MODE key until the PRG indicator LED on the display is illuminated. See Menu Navigation page <u>24</u>.

Menu Navigation

Menu navigation diagrams below illustrate how to navigate through the programming menus and submenus.



FUF [5 LAST PARAM CHANGE] submenu



L r U [ALL PARAM CHANGE] submenu





I D [I/O MENU] submenu



[] [COMMUNICATION MENU] submenu




5 [r [SCROLL MENU] submenu 2



5 [r [SCROLL MENU] submenu 3



РП [PM MOTOR MENU] submenu



Submenus

The ATV212 drive features 6 submenus (see diagrams starting on page 24) that are designed to reduce the time and effort required to program application parameters. Parameters can be modified within these submenus.

HUH [5 LAST PARAM CHANGE]

The R U H submenu displays, in reverse chronological order, the last 5 parameters that have been changed from their factory settings. Each time the R U H submenu is accessed, it searches for the latest parameters changed from their factory settings. If every parameter is at its factory settings, no display is generated.

Parameter Lock F 700 is not displayed in the RUH menu, even if its value has been changed (see page <u>68</u>).

RUF [QUICK MENU]

The RUF submenu provides ready access to the ten basic parameters commonly used in programming the drive. In many cases, programming the ATV212 drive is complete when these 10 parameters have been properly set (see chapter Quick Menu page 59).

G r **U** [ALL PARAM CHANGE]

The C r U submenu displays every parameter that has been changed from its factory settings. Each time the C r U submenu is accessed, its content is refreshed with the latest list of parameters changed from their factory settings. If every parameter is at its factory setting, no display is generated.

Parameters F_{n} and $F_{10} - F_{11} - F_{11}$ are not displayed in the \Box_{r} \Box menu, even if their values have been changed.

F--- [EXTENDED MENU]

The extended parameter submenu provides access to parameters used for special settings and applications.

I [I/O MENU]

The 10 submenu provides access to parameters used for input/output setting.

COMMUNICATION MENU

The [] I submenu provides access to parameters used for the communication setting.

5 C r [SCROLL MENU]

The 5 [r submenu provides access to parameters used for the Synchronous scroll motors setting.

P [PM CONTROL MENU]

The P I submenu provides access to parameters used for the Synchronous motor setting.

Graphic display option

LOSS OF CONTROL

- Do not use the ATV21 and ATV12 terminal display (VW3A21101 and VW3A1006).
- Only VW3A1101 is compatible with ATV212.
- Failure to follow these instructions can result in death, serious injury, or equipment damage.

Description of the graphic display option

With the graphic display option, which works with FLASH V1.1IE29 or higher, it is possible to display more text information than can be shown on the integrated display terminal.



 To increase or decrease the reference if control via the graphic display option is activated

Note: Keys 3, 4, 5 and 6 can be used to control the drive directly, if control via the graphic display option is activated.

Powering up the drive with graphic display option for the first time

When powering up the graphic display option for the first time, the user has to select the required language.



Display after the graphic display option has been powered up for the first time. Select the language and press ENT.

♦ ENT



MAIN MENU	
DRIVE MENU	ENT
LANGUAGE	



The graphic display option to drive synchronization screen will now appear.



Move

up/down keys



MAIN MENU

Finding a parameter in this document

The following assistance with finding explanations on a parameter is provided:

- With the integrated display terminal and the optional graphic display terminal : Direct use of the parameter code index, page 203, to find the page giving details of the displayed parameter.
- With the graphic display option: The parameter code and the name are displayed.

Example: ACC

AUF: QUICK MEN	IU
vLv: Motor rated voltage	
AU1: Auto ramp	
ACC: Acceleration time 1	
DEC:Deceleration time 1	
LL: Low limit frequency	
Rem	Loc/Rem

Then use the parameter code index, page 203, to find the page giving details of the displayed parameter.

Detected fault screens

Example: Output phase loss fault



This screen is displayed the detected fault type and diagnostic information related to the detected fault. Then use the alarm code table page <u>180</u> for more information.

Line undervoltage



Pre-alarms screens

Here some type of screens:

Current Limit pre-alarm



Motor overload pre-alarm

Alarm L
OPERATIONAL VALUE
29.0 нz
Rem Loc/Rem

Current Limit and DC bus overvoltage pre-alarm

Alarm C	Alarm P	
C	PERATIONAL VALUE	
	29.0 Hz	
Re	em Loo	:/Rem

DC bus overvoltage pre-alarm



Drive overheating pre-alarm



Motor overload and drive overheating pre-alarm



Modbus communication status

[Mdb com stat] (*Π b* (*m*) parameter display

This parameter is able to check the modbus communication on RJ45 and OpenStyle port.



Example : With Communication on RJ45 port



SoMove software



Description

SoMove is user-friendly setup software PC for setting up Altivar 212 drives.

SoMove software incorporates various functions for the device setup phases, such as:

- Configuration preparation
- Start-up
- Maintenance

It can be downloaded free of charge from the internet at www.schneider-electric.com.

Connection

SoMove software can use a direct USB/RJ45 cable link or a Bluetooth[®] wireless link. See catalog on www.schneider-electric.com.

Structure of the parameter tables

The parameter tables contained in the descriptions of the various menus are organized as follows. Example:

Code	Name / Description	Adjustment range	Factory setting		
►F 400	[Auto-tuning drive] Auto tuning enable	-	0		
	Disabled] nitialize constant]: Application of individual settings of Auto Torque Boost [Auto Torque Boost] 5 4 0 2) Complete tune]: complete auto tuning. arameter F 4 0 0 is reset to "0" after the auto tuning is performed.				
Value of parameter on graphic display option Parameter value on embedded display					
Name of parameter on graphic display option and description if needed.					
Parameter code on 4-digit 7-segment display					

Note: The text in square brackets [] indicates what you will see on the graphic display option.

Parameters that cannot be changed while the drive is running

The table below lists the parameters that cannot be changed unless the drive is stopped.

Code	Description	Code	Description
AU I	[Auto ramp]	F 3 3 8	[Scroll Protection]
A U 4	[Auto set function]	F 3 4 9	[Discharge gas]
6003	[Command mode sel]	F 3 5 5	[Crankcase heating]
FNOd	[Frequency mode sel]	F400	[Auto-tuning drive]
ЕУР	[Parameter reset]	F405	[Motor rated cap.]
F H	[Max frequency]	F415	[Motor rated current]
<u> </u>	[Upper limit freq]	F416	[Mot no-load current]
u L u	[Motor rated voltage]	FYIT	[Motor rated speed]
PE	[Mot cont. mode sel.]	F418	[Frequency loop gain]
F 108	[Logic Funct 1 active]	F419	[Freq. loop stability]
F 109	[VIA selection]	F 4 5 8	[Current loop gain]
F D	[Logic Funct 2 active]	F480	[No load cur. coef]
F I I I	[LI F selection]	F48 I	[In noise comp. filter]
F 2	[LI R selection]	F482	[In noise Inhibit filter]
F 3	[LI RES selection]	F483	[In noise inhibit gain]
F 8	[VIA LI selection]	F 4 8 4	[Pwr supply adj. gain]
F 130	[RY Relay Function 1]	F 4 8 5	[Stall control coef. 1]
F 132	[FL Relay Function]	F492	[Stall control coef. 2]
FIJT	[RY Relay Function 2]	F 4 9 4	[Mot. adj coefficient]
F 139	[RY logic select.]	F495	[Motor voltage coef.]
F 170	[Mot 2 rated Freq.]	F496	[PWM adj. coef.]
F I T I	[Motor 2 rated Volt]	F60 I	[Motor Current Limit]
F 3 0 0	[Switch. freq. level]	F603	[fault stop Mode]
F 3 0 1	[Catch on fly]	F605	[Output phase loss]
F 3 0 2	[Supply loss behav.]	F608	[Input phase loss]
F 3 0 3	[Number auto reset]	F6 13	[Short circuit det.]
F 3 0 5	[Overvoltage fault]	F626	[Overvoltage level]
F 3 0 7	[Mot volt limitation]	F627	[Undervolt detect.]
FJII	[Motor direction]	F 7 3 2	[Loc/rem key]
F 3 16	[Switch. freq. mode]	F915	[PM mode selection]
F 3 2 4	[Driving Scroll]	F916	[PM Align cur. Level]
F 3 2 5	[Pre-start Scroll]	F920	[Position Adjust]
F 3 3 0	[Std Oiling Cycle]	F921	[Init. Pos. Current]
F 3 3 4	[Low Speed Oiling]		

Common control schemes

A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

Read and understand the instructions in "before you begin" chapter, before performing the procedure in this section.

Failure to follow these instructions will result in death or serious injury.

UNINTENDED EQUIPMENT OPERATION

- To modify the setting of the switches, the product must be switched off.
- Do not change the setting of switch SW102 unless your system is properly wired.

Failure to follow these instructions will result in death or serious injury.

2-wire control



- 1. Wire the logic inputs as indicated in the above figure.
- 2. Set switch SW102 to source.
- 3. Program common parameters of ATV212 (see Quick Menu page 59).
- 4. Program specific parameters for 2-wire control as indicated in the following table:

Parameter	Page	Setting	Factory value
[II] d [Command mode sel]	<u>87</u>	[Logic inputs]	0
F I I I [LI F selection]	<u>100</u>	2 [forward]	2
F I I Z [LI R selection]	<u>100</u>	3 [reverse]	6

Note: If F I I I and F I I 2 are switched simultaneously, the drive will go at 0 speed.

3-wire control



- 1. Wire the logic inputs as indicated in the above figure.
- 2. Set switch SW102 to source.
- 3. Program common parameters of ATV212 (see Quick Menu page 59).
- 4. Program specific parameters for 3-wire control as indicated in the following table:

Parameter	Page	Setting	Factory value
[II] d [Command mode sel]	<u>87</u>	[Logic inputs]	0
F I I I [LI F selection]	<u>100</u>	[forward]	2
F I I Z [LI R selection]	<u>100</u>	49 [3-wire]	6
F I I J [LI RES selection]	<u>100</u>	3 [reverse]	10

3 wire control timing diagram



External speed control potentiometer



- 1. Wire the analog input as indicated in the above figure.
- 2. Set switch SW100 to V (voltage).
- 3. Program common parameters of ATV212 (see Quick Menu page 59).

4. Program specific parameters for external speed control potentiometer as indicated in the following table:

Parameter	Page	Setting	Factory value
F II I d [Frequency mode sel]	<u>87</u>	I [Ref source VIA]	1
F I D 9 [VIA selection]	<u>100</u>	D [AI]	0
F 2 D D [Auto/man speed ref]	<u>118</u>	[Enable]	0

4-20 mA speed control



- 1. Wire the analog input as indicated in the above figure.
- 2. Set switch SW100 to I (current).
- 3. Program common parameters of ATV212 (see Quick Menu page 59).

4. Program specific parameters for 4-20 mA speed control as indicated in the following table:

Parameter	Page	Setting	Factory value
F II II d [Frequency mode sel]	<u>87</u>	/ [Ref source VIA]	1
F 109 [VIA selection]	<u>100</u>	D [AI]	0
F 2 0 0 [Auto/man speed ref]	<u>118</u>	[Enable]	0
F 2 0 / [VIA ref point 1]	<u>116</u>	20%	0 %

Preset speeds (up to seven)



- 1. Wire the logic and analog inputs as indicated in the above figure.
- 2. Set switch SW102 to source.
- 3. Program common parameters of ATV212 (see Quick Menu page 59).
- 4. Program specific parameters for preset speed as indicated in the following table:

Parameter	Page	Setting	Factory value
F ID9 [VIA selection]	<u>100</u>	2 [LI source]	0
F I I I [LI F selection]	<u>100</u>	2 [forward]	2
F I I 2 [LI R selection]	<u>100</u>	6 [PS1]	6
F I I J [LI RES selection]	<u>100</u>	7 [PS2]	10
F I IB [VIA LI selection]	<u>100</u>	B [PS3]	7
5 r I [Preset speed 1]	<u>123</u>	-	15.0
5 r 2 [Preset speed 2]	<u>123</u>	-	20.0
5 r 3 [Preset speed 3]	<u>123</u>	-	25.0
5 r 4 [Preset speed 4]	<u>123</u>	-	30.0
5 r 5 [Preset speed 5]	<u>123</u>	-	35.0
5 r 6 [Preset speed 6]	<u>123</u>	-	40.0
5 r 7 [Preset speed 7]	<u>123</u>	-	45.0





See page <u>123</u> for additionnal information.

Serial communication

RJ45 connection



Port open style connection

Contact	Signal
В	+
A	-
GND	GND
SCR	Screen

• Cable sheath should be peeled off by about 10 mm.

 For wiring work, use a fat blade screwdriver with a 0.6 mm thick and 3.5 mm width blade.

• Tightening torque for the terminal block is 0.5 to 0.6 Nm.

- 1. For Modbus serial communication, plug the network cable into RJ45 connector on the main control board. Connection can also be carried out using the «open style» port.
- 2. Program common parameters of ATV212 (see Quick Menu page 59).
- 3. Program specific parameters for serial communication as indicated in the following table:

Parameter	Page	Setting	Factory value
[II] d [Command mode sel]	<u>87</u>	[Communication]	0
F II I d [Frequency mode sel]	<u>87</u>	4 [Serial com ref.]	1
FBD7 [Com channel choice]	<u>149</u>		1

Forced local



- 1. Wire the logic input as indicated in the above figure.
- 2. Set switch SW102 to source.
- 3. Program common parameters of ATV212 (see Quick Menu page 59).
- 4. Program specific parameter for forced local as indicated in the following table:

Parameter	Page	Setting	Factory value
F I I 3 [LI RES selection]	<u>100</u>	HB [forced local]	10

PID control



- 1. Wire analog inputs as indicated in the above figure.
- 2. Set switch SW102 to source.

3. If the feedback is a milliamp signal, set switch SW100 to the I (current) position. If the feedback is a voltage signal, set switch SW100 to the V (voltage) position.

4. Program common parameters of ATV212 (see Quick Menu page 59).

5. Program specific parameters for PID control as indicated in the following table:

Parameter	Page	Setting	Factory value
F II II d [Frequency mode sel]	<u>87</u>	2 [Communication]	1
F ID9 [VIA selection]	<u>100</u>	D [AI]	0
F 2 D D [Auto/man speed ref]	<u>118</u>	[Enable]	0
F 3 6 0 [PID control enable]	<u>120</u>	I [PID by VIA]	0
F 359 [PID ctrl wait time]	<u>121</u>		0 s
F 362 [PID Prop Gain]	<u>120</u>		0.30 %
F 3 6 3 [PID Integral Gain]	<u>120</u>		0.20
F 3 6 6 [PID Derivative Gain]	<u>121</u>	In accordance	0.00
F 380 [PID reverse error]		application	0
F 3 9 / [Stop on LL hyst]	<u>122</u>		0.2 Hz
F 392 [PID wake up (thres)]	<u>122</u>		0.0 Hz
F 393 [PID wake up, feedb]	<u>122</u>		0.0 Hz

Drive Operation

Local and Remote Modes of Operation

Overview

The ATV212 drive has two modes of operation, local and remote.

In local mode, the ATV212 drive can be operated only from the embedded display terminal or graphic display option:

- Use the RUN and STOP keys for command control
- Use the UP and DOWN keys for speed control

In remote mode, the ATV212 drive is operated from a combination of the command and speed reference sources defined by programming parameters [Frequency mode sel] ($F \sqcap \Box d$) and [Command mode sel] ($L \sqcap \Box d$) (see page <u>87</u>).

Command Sources

- External signals to the control terminal logic inputs F, R, RES and VIA
- Serial communication control (Modbus®, Metasys® N2, Apogee® FLN P1, BACnet, or LonWorks®)
- Embedded display terminal RUN and STOP keys or graphic display option

Speed Reference Sources

The speed reference source [Frequency mode sel] (F [] [] d) choices are:

- External signals to the control terminal analog inputs VIA or VIB
- (4-20 mA, 0-10 Vdc),
- External signals to the control terminal logic inputs assigned to +/- Speed
- Serial communication control (Modbus[®], Metasys[®] N2, Apogee FLN P1[®], BACnet, or LonWorks[®])
- Embedded display terminal UP and DOWN keys or graphic display option

Command Mode Selection and Priorities

The diagram below illustrates the control inputs and selection logic which determine the source of the drive's start/stop and speed reference commands.

Command and Reference Switching



Parameters [Command mode sel] ($[\square \square]$) and [Frequency mode sel] ($[\square \square]$) are the first layers of logic used by the drive to determine its command $[\square \square]$ and speed reference $[\square \square]$ source.

[Remote spd ref 2] ($F \ge 0$ 7) is a secondary speed reference source that may override the source selected by $F \sqcap 0 \dashv$ (see page <u>87</u>).

The speed reference source identified by *F 2 D* 7 takes control if either:

- A logic input assigned to function 38 (frequency reference source switching) is enabled, or
- Parameter [Auto/man speed ref] (F 2 0 0) is set to 1 and the drive's output frequency is equal to or less than 1 Hz (see page <u>118</u>).

If a serial communication link is established, it can take control of the ATV212 drive, overriding inputs identified by $[\Pi \square d, F \Pi \square d, and F 2 \square]$. Control is restored to $[\Pi \square d, F \Pi \square d, and F 2 \square]$ only if:

- The serial communication link relinquishes control, or
- A logic input assigned to function 48 (forced local) is enabled.

The final layer of logic used by the drive to determine its command source is the LOC/REM key on the graphic display option.

When the drive and embedded HMI is set to local mode (by pressing the LOC/REM key, lighting the local mode LED), the drive responds only to commands from the embedded and graphic display option.

Selecting Local or Remote mode

A DANGER

UNINTENDED EQUIPMENT OPERATION

- Know the state of the frequency and run commands from the remote source before exiting the local mode.
- Upon entering the remote mode, the drive will respond to the most recent command from the remote source, even if it was received before entering or while in the local mode.

Failure to follow these instructions will result in death or serious injury.

Switching between local and remote mode is achieved with the LOC/REM key on the drive's embedded display terminal or with F4 key on the graphic display option.

The LOC/REM key can be disabled by setting parameter [Loc/rem key] (F 7 3 2) to 1 (see page 90).

When parameter [Switch rem/Local] ($F \ge 95$) is set to 1 (factory setting), a bumpless tranfer of motor operation is achieved when switching from remote to local mode (see page <u>88</u>).

For example, if the bumpless transfert feature is active and if the motor is running at full speed with the drive in remote mode, the motor will still run at full speed after the drive is transferred to local mode.

Conversely, when switching from local to remote mode, the run and speed command is not transferred to the remote mode. Upon entering the remote mode, the drive will operate on the run and speed command set by the remote source even if it was received before entering or while in the local mode.

The diagram below is an example timing diagram.

Switching Between Local and Remote Mode



Local Mode

When the ATV212 drive is in local mode, the LED above the LOC/REM key is illuminated.

On the graphic display option:

AUF: QUICK MENU			
LL: Low Limit frequency			
DEC: Deceleration time 1			
ACC: Acceleration time 1			
AU1: Auto ramp			
vLv: Motor rated voltage			
Loc Refloc Cmd loc Loc/Rem			

Starting and Stopping the Motor in Local Mode

Start and stop the motor with the RUN and STOP keys on the graphic/embeded display terminals.

The setting of parameter [Loc. mot stop mode] (F 7 2 1) determines how the motor stops when the drive is in local mode (see page <u>88</u>):

- If F 72 / is set to 0 (factory setting), the motor will stop on a ramp, based on the time value set in parameter [Deceleration time 1] (d E C) or parameter [Deceleration time 2] (F 5 D /).
- If F 72 I is set to 1, power will be removed from the motor when the STOP key is pressed, allowing the motor to coast to a stop with the ramp-down time determined by inertia and friction.

Use of the RUN and STOP keys in local mode can be disabled using parameter [Run/stop key] (F 7 3 3) (see page <u>90</u>).

Adjusting Motor Speed in Local Mode

Set the motor speed using the UP and DOWN keys on the graphic/embedded display terminals. Motor speed can be adjusted while the drive is operating.

Normally, motor frequency changes by 0.1 Hz each time the UP or DOWN key is pressed. This rate of speed change can be altered by entering a new frequency step change into parameter [Loc. speed ref. step] (F 7 0 7) (see page <u>87</u>).

If the ENT key is pressed after the motor speed has been adjusted, that speed setpoint value will be entered into parameter $F \ L$. The next time the drive is Power ON in local mode, it will accelerate the motor directly to the speed setpoint memorized by [Local speed ref.] ($F \ L$) (see page <u>87</u>).

Selecting Motor Rotation Direction in Local Mode

Motor rotation direction is set by parameter [Local mot. direction] (F -) (see page <u>87</u>). The four selections are:

- 0: Forward only (factory setting)
- 1: Reverse only
- 2: Forward, with reverse selectable from the graphic/embeded display terminals (1)
- 3: Reverse, with forward selectable from the graphic/embedded display terminals (1)
- (1)If *F* r is set to either 2 or 3, motor rotation can be set to forward by pressing the UP key while holding the ENT key. Reverse can be set by pressing the DOWN key while holding the ENT key.

Motor rotation is indicated on the embedded display terminal as F - F for forward and as F - F for reverse.

The ability to run in the Forward or Reverse direction can be set with parameter [Motor direction] ($F \exists I I$) (see page <u>96</u>).

Resetting drive detected fault in Local Mode

It is not possible to clear a drive detected fault if the cause of the detected fault persists. Be certain to diagnose and rectify the cause of the detected fault before attempting a drive reset.

With the STOP Key

To clear a drive detected fault in local mode:

1. Press the STOP key. See Fault detection codes that can be cleared with the automatic restart function after the cause has disappeared on page <u>135</u> for a list of detected faults that can be cleared with the STOP key. If it is possible to reset the drive, the embedded display terminal will display L r.

2. To clear the detected fault, press the STOP key a second time.

3. If the cause of the detected fault is still present, the *L r* display will not appear. Diagnose and clear the detected fault before attempting to reset the drive.

Use of the STOP key as a clear detected fault can be set with parameter [HMI reset button] ($F 7 \exists 5$) (see page <u>90</u>).

In the event of an $\Box L$ / or $\Box L$ 2 detected fault, the following time periods are necessary before a clear detected fault is possible:

- DL / (drive overload)—about 30 seconds after the detected fault has occured
- DL 2 (motor overload)—about 120 seconds after the detected fault has occured

By Cycling Line Power

A drive detected fault can also be cleared by removing and restoring line power. Be certain that the cause of the detected fault is no longer present and leave power removed long enough for all of the LEDs on the face of the drive to extinguish.

Cycling power to clear a detected fault can cause the detected fault history to be lost. Refer to parameter [Drive Fault Memory] ($F \subseteq D = 2$) on page <u>138</u>.

Logic Input Functions Active in Local Mode

The logic input functions listed in the table below are active, even if [Command mode sel] ($[\square \square \square]$) is set to 1 (embedded display terminal control). See table on page <u>100</u> for logic input function settings.

Logic Input	Description
Function No.	
1	[Run permissive]
54	[Inverse Run permissive]
10	[Fault reset]
55	[Inv fault reset]
11	[Ext Fault]
45	[Inv Ext. fault]
16	[Run reset]
38	[Frequency source]
41	[(+) speed]
42	[(-) speed]
43	[+/- clear]
44	[+/- SPD, FLT CLR]
46	[Ext. Th fault]
47	[Inv Ext. Th fault]
51	[Reset kWh]
52	[Forced mode]
53	[Fire mode]
62	[RY on]
64	[Cancel HMI cmd]

Remote Mode

When the ATV212 drive is in the remote mode, the LOC/REM LED is off.

Starting and Stopping the Motor in Remote Mode

The diagram on page 50 illustrates the start/stop command source when the drive is in remote mode.

With Logic Input Terminals

Use the logic input terminals F, R, RES, or VIA to start the drive if parameter [Command mode sel] ([]] d) is set to [Logic Inputs] (]) (factory setting).

With the display terminals

The drive responds to commands from the embedded display terminal or graphic display option, just as in local mode, if parameter [Command mode sel] ([[] []]]) is set to [HMI] (]).

With Serial Communication

The drive responds to commands sent over the serial communication link (Modbus[®], Metasys[®] N2, Apogee[®] FLN, BACnet or LonWorks[®]) if parameter [Command mode sel] ($[\square \square \square \square]$) is set to [Communication] ($[\square \square]$).

The drive responds to commands sent over the RJ45 communication port if parameter [Com channel choice] ($F \blacksquare \Box$ 7) is set to 0. Other protocols are available when $F \blacksquare \Box$ 7 is set to 1 on open style port.

With the graphic/embeded display terminals STOP Key

The graphic/embeded display terminals STOP key is active when the drive is in remote mode. Pressing the STOP key causes the drive to stop according to the setting of parameters [Ext. fault stop Mode] ($F \subseteq D \exists$), [DC brk time ext flt] ($F \subseteq D \exists$), and [DC braking current] ($F \supseteq 5 I$) (see page <u>126</u> and page <u>98</u>). After the drive has come to a stop, the graphic/embeded display terminals display E and the fault relay is activated.

Adjusting the Motor Speed in Remote Mode

The diagram on page 50 illustrates the speed reference source when the drive is in remote mode.

By Analog Input VIA

A 0-10 Vdc or 4-20 mA signal connected to VIA and CC can be used to adjust the motor speed if:

- Parameter [Frequency mode sel] (F II I d) is set to 1 (factory setting).
- Alternate speed reference source parameter [Remote spd ref 2] (F 2 0 7) has not been enabled (see page 88).

The analog signal type depends on the setting of switch SW100 and parameters $F \mid \Box \mid 9, F \mid 2 \mid \Box \mid -F \mid 2 \mid \Box \mid 4$, and $F \mid 1 \mid \Box \mid -F \mid 4 \mid 1$.

By Analog Input VIB

A 0–10 Vdc signal connected to VIB and CC can be used to adjust the motor speed if:

- Parameter [Frequency mode sel] (F [] [] d) is set to 2.
- Alternate speed reference source parameter [Remote spd ref 2] (F 2 [] 7) has not been enabled.

The control that VIB has over motor speed depends on the setting of switch SW100 and parameters $F \ge 10 - F \ge 13$, $F \le 12 - F \le 13$, and $F \le 15$.

By display terminal Control

Control of the motor speed is enabled, if:

- Parameter [Frequency mode sel] (F II II d) is set to 3.
- Alternate speed reference source parameter [Remote spd ref 2] (F 2 0 7) has not been enabled.

By Serial communication control

Serial communication control (Modbus, Metasys N2, Apogee FLN, BACnet or LonWorks) of the motor speed is enabled, if:

- Parameter [Com channel choice] (F B D 7) is set to 0 (only for Modbus on RJ45 port),
- Parameter [Com channel choice] (F B D 7) is set to 1,
- Parameter [Frequency mode sel] (F II I d) is set to 4.
- Alternate speed reference source parameter [Remote spd ref 2] (F 2 0 7) has not been enabled.

By +/- Motor Speed Control

+/- Motor speed control is enabled, if:

- Parameter [Frequency mode sel] (F [] [] d) is set to 5,
- Alternate speed reference source parameter [Remote spd ref 2] (F 2 0 7) has not been enabled.

Selecting Motor Rotation Direction in Remote Mode

The diagram on page 50 illustrates the motor rotation command source when the drive is in remote mode.

With Logic Input Terminals

Use the logic input terminals F, R, RES, or VIA to select motor rotation direction if parameter [Command mode sel] ($[\square \square \square]$) is set to 0 (factory setting).

With the embedded display terminal or graphic display option

Motor rotation direction can be set by pressing the display terminal UP and ENT keys if:

- Parameter [Command mode sel] ([I I]]) is set to 1,
- Serial communication control has not been established.
- Parameter [Local mot. direction] (F r) is set to either 2 or 3.

With Serial Communication

The drive responds to commands sent over the serial communication link (Modbus, Metasys N2, Apogee FLN, BACnet or LonWorks) if Parameter [Command mode sel] ($[\Pi \Box d$) is set to 2.

Resetting drive detected faults in Remote Mode

The diagram on page 50 illustrates the clear detected fault command source when the drive is in remote mode.

It is not possible to clear a drive detected fault if the cause of the detected fault persists. Be certain to diagnose and rectify the cause of the detected fault before attempting to reset the drive.

See Automatically Resettable detected faults on page <u>135</u> for a list of detected faults that can be cleared in remote mode.

With the Logic Input Terminals

Use the logic input terminals F, R, RES, or VIA to clear a drive detected fault if parameter [Command mode sel] ($[\Pi \square d]$) is set to 0 (factory setting).

With the graphic/embeded display terminals

The STOP key can be used to clear a drive detected fault if parameter [Command mode sel] ([ח ם d) is set to 1.

To clear a drive detected fault, press the STOP key. If it is possible to reset the drive, it will display *L L r*. To clear the detected fault, press the STOP key a second time.

If the cause of the interruption is still present, the *L r* display will not appear. Diagnose and clear the detected fault before attempting to reset the drive.

The use of the STOP key as a clear detected fault can be managed by parameter [HMI reset button] (F 7 3 5).

With Serial Communication

A drive detected fault can be cleared over the serial communication link (Modbus, Metasys N2, Apogee FLN, BACnet or LonWorks) if parameter [Command mode sel] ($[\Pi \square d]$) is set to 2.

In the event of an $\Box L$ / or $\Box L Z$ detected fault, the following time periods needs to pass before a clear detected fault is possible:

- DL / (drive overload) about 30 seconds after the occurrence of the event.
- DL 2 (motor overload) about 120 seconds after the occurrence of the event.

By Cycling Line Power

A drive detected fault can also be cleared by removing and restoring line power. Be certain that the cause of the detected fault is no longer present and leave power removed long enough for all of the LEDs on the face of the drive to go out.

Cycling power to clear a detected fault can cause the detected fault history to be lost. Refer to parameter F = D = 2 on page 138 for drive fault memory options.

Programming

Ш

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
3	Quick Menu	59
4	Programming Parameters	65
5	Motor Control Parameters	69
6	Drive Control Parameters	87
7	Application Parameters	91
8	I/O Control Parameters	99
9	Display Parameters	129
10	Detected Fault Management Parameters	133
11	Serial Communication Parameters	147
12	Start/Stop Control By Speed Reference Level	153
13	Droop Control	155

Quick Menu

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Quick menu	60

Quick menu

The $F \sqcup F$ submenu provides ready access to the ten basic parameters commonly used in programming the drive.

In many cases, programming the ATV212 drive is complete when these 10 parameters and motor parameters have been properly set. .

Code	Name / Description	Adjustment range	Factory setting	
AU I	[Auto ramp] Automatic ramp adaptation	-	1	
0 2	[Disabled] [Enable]: [Acceleration time 1] (R [[) and [Deceleration time 1] (d []) [ACC only]: [Acceleration time 1] (R []) only If parameter R U I is set to 1 or 2, the drive will monitor its own loading level and optimize the acceleration and deceleration ramps. The acceleration and deceleration R U I = 1 only rates will be automatically adjusted between 1/8 to 8 times the settings of R [] and J E [, depending on the drive's current rating and the load level on the motor. R [] and J E [, should be appro-			
	priately set for an average load in the application. If the load on the motor increases rapidly during ramp up or ramp down, the auto ramp adaptation feature may not help to prevent the drive from experiencing an overcurrent or overvoltage.			
	If the application requires a consistent acceleration and deceleration time, set $R \ U \ I$ to 0, and set $R \ C \ L$ and $d \ E \ C$ manually as needed. The manual acceleration and deceleration times can still be overridden by the [Motor Current Limit] ($F \ D \ I$) (see page $\underline{73}$) and [Overvoltage fault] ($F \ B \ D \ S$) (see page $\underline{139}$) and [Overvoltage level] ($F \ B \ B \ S$) (see page $\underline{139}$) functions.			
A C C	[Acceleration time 1]	0.0 to 3200 s	According to drive rating (1)	
	The setting of parameter $R \ L \ L$ determines the slope of the acceleration ramp and the drive to increase from 0 Hz to the setting of [Max frequency] (<i>F H</i>) (see page <u>92</u>). If parameter [Auto ramp] ($R \ U \ I$) is set to 1 or 2, the acceleration ramp may be increas depending on the amount of load on the motor during ramp up.	time it takes for the out	put frequency of the	
	If two different acceleration rates are needed, see parameter [Acceleration time 2] (F 5 0 0) on page 93.			
	Output frequency (Hz)	(s)		
d E C	[Deceleration time 1]	0.0 to 3200 s	According to drive rating (1)	
	The setting of parameter $d \in C$ determines the slope of the deceleration ramp and the the drive to decrease from the setting of [Max frequency] (<i>F H</i>) to 0 Hz. If parameter [Auto ramp] (<i>R U I</i>) is set to 1 or 2, the deceleration ramp may be increas depending on the amount of load on the motor during ramp down. See diagram above If two different deceleration rates are needed, see parameter [Deceleration time 2] (<i>F</i>	e time it takes for the c ed or decreased from t e. 5 0 1) on page <u>93</u> .	utput frequency of the setting of <i>d E [</i> ,	
LL	[Low limit frequency]	0.0 to [Upper limit freq] (<i>U L</i>) Hz	0.0 Hz	
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 30%.			
	Parameter L sets the minimum frequency that can be commanded to the drive by the	ne local or remote spee	ed reference source.	
UL	[Upper limit freq]	0.5 to [Max fre- quency] (F H) Hz	50.0 Hz	
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 90%.			
	Parameter UL sets the maximum frequency that can be commanded to the drive by the local or remote speed reference source. The top end of its range is limited by the setting of [Max frequency] (<i>F H</i>).			

(1) See table page 199



Code	Name / Description	Adjustment range	Factory setting
υL	[Motor rated freq.] Motor rated frequency	25.0 to 400.0 Hz	50.0 Hz
	Set parameter μL (vL) to the motor's rated frequency as indicated on the motor nameplate. Note: It is possible to set the drive's various motor control frequencies to 50 Hz by setting [Parameter reset] ($L \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$		
υLυ	[Motor rated voltage]	According to drive rating	According to drive rating (1)
	Set parameter $U \downarrow U$ (vLv) to the motor's rated voltage as indicated on the motor nameplate. ATV212eeeM3X: 50 to 330 V. ATV212eeeN4: 50 to 660 V Note: Drive output voltage cannot be set to exceed the input line voltage level.		

(1) See table page 199

Motor parameters

Configure the motor parameters and perform an auto-tuning ([Auto-tuning drive] ($F \ 4 \ \Box \ \Box$) = 2, see page $\frac{75}{10}$ for auto-tuning).

Code	Name / Description	Adjustment range	Factory setting	
F415	[Motor rated current] Motor rated full load current	0.1 to 200.0 A	According to drive rating (1)	
	Set parameter F 4 15 to the motor rated full load current in amperes as indicated on	the motor's nameplate	е.	
FYIT	[Motor rated speed]	100 to 15000 rpm	According to drive rating (1)	
	Set parameter F 4 17 to the motor rated speed in rpm as indicated on the motor's na	ameplate.		
F 6 0 I	[Motor Current Limit]	10 to 110% of the drive's output cur- rent rating	110%	
NOTICE				
	 RISK OF DAMAGE TO THE MOTOR AND THE DRIVE Check that the motor will withstand this current. Check that the profile mission complies with the derating curve given in the installation manual Failure to follow this instruction can result in equipment damage. 			
 Parameter <i>F</i> 6 0 <i>I</i> can be adjusted to limit current during motoring or braking. Display in Current Limit Mode: When the drive goes into current limit mode, it will: Adjust the output frequency to limit the flow of motor current (down when motoring, up when braking). 				
	Display the letter C and the output frequency flashing on the embedded software terminal, ex:			
	If parameter [Unit value selection] ($F \ 7 \ D \ I$) is set to 1 (see page <u>130</u>), parameter $F \ E$ eter $F \ 7 \ D \ I$ is set to 0, parameter $F \ E \ D \ I$ will be adjusted as a percentage of the dr nameplate.	i / will be adjusted in ive's output rated current	n amperes. If param- ent as listed on its	
	The setting of parameter [Switch. freq. level] (F 3 0 0) (see page 95) does not change this calculation.	ge the drive's rated cu	rrent for the sake of	
	Do not set parameter F 6 0 / below the no-load current rating of the motor.			
	(1) See table page <u>200</u> .			

Code	Name / Description	Adjustment range	Factory setting	
F 4 0 0	[Auto-tuning drive] Auto tuning enable	-	0	
	A DANGER HAZARD OF ELECTRIC SHOCK OR ARC FLASH • During auto-tuning, the motor operates at rated current. • Do not service the motor during auto-tuning. Failure to follow these instructions will result in death or serious injury.			
	A WARNING			
 LOSS OF CONTROL It is essential that the following parameters u L u, u L, F Y I 5 and F Y I 7 are correctly configured before tuning. When one or more of these parameters have been changed after auto-tuning has been performed, F Y D and the procedure will have to be repeated. Failure to follow these instructions can result in death or serious injury. 				
	NOTICE			
	 RISK OF DAMAGE TO THE MOTOR Conduct auto-tuning only after the motor has been connected and operation completely stopped. If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in tuning. Failure to follow these instructions can result in equipment damage. 			
0	[Disabled]: Disabled			
1	[Initialize constant]: Factory setting of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Factory setting of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), and [Motor Rated Voltage] (vlv) for synchronous motor.	[Autotune L d-axis] (<i>F</i>	9 / 3), and	
2	[Tun Dyn. 1] : Tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), synchronous motor.	and [Autotune L d-axis	s] (<i>F </i>	
Э	[Tun Dyn. 2] : Complete tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (<i>F</i> 4 0 2), [Autotune L q-axis] (<i>F</i> 9 12), [Motor Rated Voltage] (vlv) for synchronous motor.	[Autotune L d-axis] (F	9 / 3), and	
4	[Tun Static 1] : Tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), synchronous motor.	and [Autotune L d-axis	s] (<i>F </i>	
5	[Tun Static 2] : Complete tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 1 2), [Motor Rated Voltage] (vlv) for synchronous motor.	and [Autotune L d-axis	5] (<i>F 9 13</i>), and	
	Parameter F 4 D D is reset to "0" after the auto tuning is performed.			

Programming Parameters

4

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Parameter Reset	66
Macro Programming (AU4)	67
Parameter Lock	68
Display of Submenu AUF (F738)	68
Parameter Reset

Parameter Reset Options

The ATV212 drive offers three options to return parameters to their factory default settings:

- Factory reset: set parameter [Parameter reset] (L UP) to 3
- 50 Hz reset: set parameter [Parameter reset] (*L Y P*) to 1
 60 Hz reset: set parameter [Parameter reset] (*L Y P*) to 2

Code	Name / Description	Factory setting
ĿУP	[Parameter reset]	0
	UNINTENDED EQUIPMENT OPERATION When L Y P is set to 3 or B: - Check that the modification of the current configuration is compatible with the wiring diagram used. - All logic inputs must be deactivated to avoid unintended restart. Failure to follow these instructions will result in death or serious injury.	
0	[No action]	
I	[50 Hz reset] : 50 Hz parameter reset Setting parameter <i>L J P</i> to a value of 1 will set specific parameters to values suitable for many 50 Hz (motor base free plications.	quency) ap-
	See Parameters whose values after a reset vary by reset type table on page <u>198</u> and table on page <u>200</u> for a list of paral are affected by this reset action and their resultant values.	meters that
	Setting parameter <u>L</u> <u>U</u> P to 2 sets specific parameters to values suitable for many 60 Hz (motor base frequency) applicate table "Parameters whose values after a reset vary by reset type" on page <u>198</u> and table "Parameters whose values after a reset type" on page <u>199</u> for a list of parameters that are affected by this r and their resultant values.	ations. See ter a reset reset action
Э	 Factory set]: Factory reset Setting parameter <i>L</i> ¹/₂ <i>P</i> to 3 resets most parameters to their factory settings. See tables listed below for a listing of th will be copied into the drive by this factory reset action: Parameters whose values after a reset do not vary by reset type (on page <u>194</u>). Parameters whose values after a reset are drive model dependant but do not vary reset type (on page <u>199</u>). Parameters whose values after a reset are drive model and reset type dependant (on page <u>200</u>). Parameters whose values do not change if a reset is performed (on page <u>201</u>). 	
	A factory reset will also clear the detected fault history.	
4	[Trip cleared]: detected fault history cleared Setting parameter L Y P to 4 clears the detected fault history. As soon as the detected fault history is reset, parameter sumes its default value of 0.	אר <i>ב צף</i> re-
5	[Cumul time clear] : Elapsed Motor Run Time Reset Setting parameter $E \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	reset, pa-
6	[EtYP fault reset] : Clear $E \vdash \Box P$ detected fault Setting parameter $E \sqcup \Box P$ to 6 clears a $E \vdash \Box P$ detected fault. As soon as the $E \vdash \Box P$ detected fault is cleared, parameter resumes its default value of 0.	eter <u>E </u>
٦	[Save parameters]: Save user-defined settings The drive parameter settings can be stored into memory into the drive as a custom parameter set. Set parameter by UP to 7 to save the current drive parameter settings to memory.	
B	[Recall parameters]: Recalls user-defined settings The drive parameter settings can be reloaded into the drive as a custom parameter set. Set parameter <i>L Y P</i> to 8 to reload into the drive the parameter settings last saved by setting <i>L Y P</i> to 7.	
9	[Elapse time reset]: Elapsed drive run time reset Setting parameter <i>L J P</i> to 9 resets the elapsed drive run time clock. As soon as the elapsed motor run time clock is re eter <i>L J P</i> resumes its default value of 0.	set, param-

Macro Programming (AU4)

The ATV212 drive can be configured for four common control schemes by setting parameter AU4:

Code	Name / Description	Factory setting
A U 4	[Auto set function] Macro Programming (1)	0
	A DANGER UNINTENDED EQUIPMENT OPERATION Check that the selected macro configuration is compatible with the wiring diagram used.	
	Failure to follow these instructions will result in death or serious injury.	
٥	[Factory set] Command reference: logic inputs (CMOd = 0). See page <u>87</u> . Speed reference: analog input VIA = 0–10 V or 0–20 mA (FMOd = 1, F201 = 0). See [Frequency mode sel] (<i>F II L</i> Analog Input Speed Reference page <u>116</u> . F: run forward (F111 = 2). See F Logic Input Function page <u>100</u> . R: preset speed 1 (F112 = 6). See R Logic Input Function page <u>100</u> . RES: clear detected fault (F113 = 10). See RES Logic Input Function page <u>100</u> . Drive ready for operation (F110 = 1). See Active Logic Function 2 page <u>122</u> .	고 d) page <u>87</u> and
I	[Run permissive] Command reference: logic inputs (CMOd = 0). See page <u>87</u> . Speed reference: analog input VIA = 0–10 V or 0–20 mA (FMOd = 1). See [Frequency mode sel] (<i>F II D d</i>) page F: run forward (F111 = 2). See F Logic Input Function page <u>100</u> . R: run permissive (F112 = 1). See R Logic Input Function page <u>100</u> . RES: clear detected fault (F113 = 10). See RES Logic Input Function page <u>100</u> .	<u>87</u> .
2	 [3-wire] Command reference: logic inputs (CMOd = 0). See page <u>87</u>. Speed reference: analog input VIA = 0–10 V or 0–20 mA (FMOd = 1). See See [Frequency mode sel] (F Π □ d) p F: run forward (F111 = 2). See F Logic Input Function page <u>100</u>. R: stop ramp (F112 = 49). See R Logic Input Function page <u>100</u>. RES: clear detected fault (F113 = 10). See RES Logic Input Function page <u>100</u>. 	age <u>87</u> .
Э	 [+/- Speed] Command reference: logic inputs (CMOd = 0). See page <u>87</u>. Speed reference: +/- Speed (FMOd = 5). See See [Frequency mode sel] (<i>F Π □ d</i>) page <u>87</u> F: run forward (F111 = 2). See F Logic Input Function page <u>100</u>. R: + Speed (F112 = 41). See R Logic Input Function page <u>100</u>. RES: - Speed (F113 = 42). See RES Logic Input Function page <u>100</u>. 	
ч	 [4-20 mA speed ref] Command reference: logic inputs (CMOd = 0). See page <u>87</u>. Speed reference: analog input VIA = 4–20 mA (FMOd = 1, F201 = 20). SeeSee [Frequency mode sel] (F II D d) particular provides and the set of the se	age <u>87</u> and Analog

(1) When programming parameter *PUY*, the embedded display terminal will display two numbers. The left number is the value last entered into *PUY*. The right number will be 0. Use the UP/DOWN keys to change the right number to the desired value and press ENT. Entering 0 into *PUY* has no effect on the drive. Programming 0 into *PUY* will not return the seven parameters to their factory default values.

Parameter Lock

Code	Name / Description	Factory setting
F 7 D D	[Parameter lock]	0
٥	[Unlocked] : All parameters are unlocked and can be changed. See table on page <u>41</u> for the parameters that cannot be changed while the drive is running.	
1	[Locked]: Only parameter F 7 D D can be changed.	

Display of Submenu AUF (F738)

Code	Name / Description	Factory setting
F 7 3 8	[Quick menu AUF]	0
0	The setting of this parameter determines whether the $P \sqcup F$ submenu, Quick Menu, will be displayed on the H [AUF displayed]: AUF parameter displayed	MI (see page <u>34</u>).
1	[AUF hidden]: AUF parameter hidden	

Motor Control Parameters

5

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Motor Control Mode	70
Other Motor Control Mode Parameters	72
Motor Tuning	74
Auto-tuning	75
Expert parameters	77
Supply Voltage Correction and Motor Voltage Limitation	78
Motor 2 Control Parameters	79
Permanent Magnet Motor Control Law ([PM Control] (PM))	81

Motor Control Mode

Constant V/Hz Mode with AutomaticTorque Boost ([Mot cont. mode sel.] (P L) = 2 [Cst V/Hz+Boost])

Use parameter [Auto Torque Boost] (F 4 0 2) to adjust the amount of automatic torque boost (see page 79).

If the ATV212 drive and the connected motor have the same power rating, and if the motor has a nominal 1500 rpm rating, no motor auto-tuning is required to use this motor control mode. Otherwise, follow the steps outlined in "Motor Tuning" on page <u>74</u>.

Due to the feedback circuit used in this mode, it is possible for motor speed to oscillate. If this occurs, select the Constant V/Hz mode ([Mot cont. mode sel.] ($P \ge$) = 0) and adjust torque boost manually with parameter [Motor Voltage Boost] ($u \ge$).



Sensorless Vector Control Mode ([Mot cont. mode sel.] (P L) = 3 [SVC])

Sensorless vector control mode is only for use in applications where:

- Each motor is powered by its own ATV212 drive (not for multi-motor applications).
- The motor has a power rating equal to that of the ATV212 drive, or no lower than one hp rating less.
- The motor has between two and eight poles (750...3000 rpm).

Sensorless vector control will not improve motor control above the motor's rated speed.

Sensorless vector control is more effective if the motor leads are less than 30 m (100 ft) in length. If motor leads longer than 30 m (100 ft) are required, perform an auto-tuning with the long motor leads included in the circuit. Motor torque may not be maximized at the motor's rated frequency due to voltage drop in the motor leads.

Connecting a load reactor or a motor filter on the output of the ATV212 drive may reduce the torque generated by the motor in sensorless vector control mode. Auto-tuning will most likely not be possible with a reactor or filter attached to the drive. Manual tuning will be required

Permanent Magnet motors Mode ([Mot cont. mode sel.] (PL) = 6 [PM control])

Permanent magnet motors that are light, small in size, and highly efficient, as compared to induction motors, can be operated in sensor-less operation mode.

This feature can be used only for specific permanent magnet motors:

- IPM, Interior-buried Permanent Magnet motor.
- SPM, Surface-mounted Permanent Magnet motor.

Code	Name / Description	Factory setting
PE	[Mot cont. mode sel.] Motor control mode	1
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by [SVC] (3).	
٥	[Constant V/Hz] : Constant V/Hz Use constant V/Hz mode for loads that require the same torque at low speeds as at rated speeds. Low speed justed manually by setting parameter [Motor Voltage Boost] (μb) (see page <u>73</u>).	torque can be ad-
	Motor rated voltage	
	Motor Rated Frequency	
	[Variable Torque]: Variable torque Use variable torque mode for loads such as centrifugal fans and pumps whose torque requirements increase increase in motor speed. Low speed torque can be adjusted manually by setting parameter $\underline{u} \ b$. Motor rated voltage	as a square of the
	Motor Voltage Boost	
2	[Cst V/Hz+Boost]: Constant V/Hz with automatic torque boost See the diagram on page 70. This mode is similar to the constant V/Hz mode (for loads that require the same torque at low speeds as at rate it automatically increases motor voltage and torque to compensate for increases in load.	d speeds), except
3	[SVC]: Sensorless vector control See the diagram on page <u>70</u> . Use sensorless vector control mode to increase torque at motor speeds below 3 Hz or to improve speed regu	lation (0.5 to 1%).
4	[Economy]: Energy saving In energy savings mode, the ATV212 drive monitors motor loading and automatically modulates the voltage ap to optimize energy consumption. If the ATV212 drive and the connected motor have the same power rating, and if the motor has a nominal 150 motor auto-tuning is required to use this motor control mode. Otherwise, follow the steps outlined in "Motor To	oplied to the motor 00 rpm rating, no uning" on page <u>74</u> .
5	[Do not use]: Reserved	
6	[PM Control]: Permanent Magnet Motor Control Law	
	 HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH If [Mot cont. mode sel.] (Pt) is set to (6) (Permanent Magnet Motor Control Law), output phase loss monitoring is running, is disabled. Phase loss and, by implication, accidental disconnection of cables, are not detected Verify that this behavior does not result in unsafe conditions and implement alternative monitoring function. Failure to follow these instructions will result in death or serious injury. 	, while the motor on if required.

Other Motor Control Mode Parameters

The table below lists other parameters that may need to be adjusted, depending on the setting of parameter [Mot cont. mode sel.] (P L).

Relationship between [Mot cont. mode sel.] (P L) setting and Other Motor Parameters

		Parameter [Mot cont. mode sel.] (P L) setting					
		0	1	2	3	4	6
Parameter	Function	Constant V/Hz Control	Variable Torque Control	Constant V/Hz with Automatic Torque Boost Control	Sensorless Vector Control	Energy Saving Control	Permanent magnet Control
L (VL) ل	[Motor rated freq.]	8	\otimes	\otimes	\otimes	\otimes	\otimes
υLu	[Motor rated voltage]	8	\otimes	\otimes	\otimes	\otimes	\otimes
υb	[Mot Voltage Boost]	8	\otimes	Х	Х	Х	Х
םרו F	[Mot 2 rated Freq.]	0	Х	Х	Х	Х	Х
F 7	[Motor 2 rated Volt]	0	Х	Х	Х	Х	Х
F 172	[Motor 2 Volt Boost]	0	Х	Х	Х	Х	Х
F 4 0 0	[Auto-tuning drive]	Х	Х	0	0	0	8
F 4 D I	[Slip Compensation]	Х	Х	Х	0	Х	Х
F 4 D 2	[Auto Torque Boost]	Х	Х	\otimes	\otimes	\otimes	\otimes
F 4 15	[Motor rated current]	0	0	\otimes	\otimes	\otimes	\otimes
F 4 16	[Mot no-load current]	Х	Х	0	0	0	Х
F 4 1 7	[Motor rated speed]	0	0	\otimes	\otimes	\otimes	\otimes
F 4 18	[Frequency loop gain]	Х	Х	0	0	0	0
F 4 5 8	[Current loop gain]	Х	Х	0	0	0	0
F 4 19	[Freq. loop stability]	Х	Х	0	0	0	0
F 4 8 0	[No load cur. coef]	Х	Х	0	0	Х	Х
F 4 8 5	[Stall control coef. 1]	0	0	0	0	0	0
F 4 9 2	[Stall control coef. 2]	0	0	0	0	0	0
F 4 9 4	[Mot. adj coefficient]	0	0	0	0	0	0
F 4 9 5	[Motor voltage coef.]	0	0	0	0	0	0
F 4 9 6	[PWM adj. coef.]	0	0	0	0	0	0
F 9 12	[Autotune L q-axis]	Х	Х	Х	Х	Х	\otimes
F 9 3	[Autotune L d-axis]	Х	Х	х	Х	х	\otimes
F 9 2 T	[Init. Pos. Current]	Х	Х	Х	Х	Х	0
F 9 Y	[N-S direction]	Х	Х	х	Х	х	0
F 9 1 5	[PM mode selection]	Х	Х	Х	Х	Х	\otimes
F 9 16	[PM Align cur. Level]	х	Х	Х	Х	х	0

X: Not applicable for the [Mot cont. mode sel.] (P L) setting

 $\otimes:$ Adjustment of this parameter is required.

O: Adjust this parameter if necessary.

Code	Name / Description	Adjustment range	Factory setting		
υb	[Motor Voltage Boost]	0.0 to 30.0%	According to drive rating (1)		
	Low speed motor torque can be adjusted with parameter μb when paramete 0 (Constant V/Hz) or 1 (Variable Torque). See curves on page <u>70</u> for more in If nuisance overcurrent faults occur during starting, reducing the setting of page 70 parameters.	r [Mot cont. mode sel.] (<i>F</i> formation. rameter <u>u</u> b may help.	7 <i>L</i>) (see page <u>71</u>) is set to		
F 6 0 I	[Motor Current Limit]	0.0 to 30.0%	10 to 110% of the drive's output current rating 110%		
	NOTICE				
	 RISK OF DAMAGE TO THE MOTOR AND THE DRIVE Check that the motor will withstand this current. Check that the profile mission complies with the derating curve given in the installation manual Failure to follow this instruction can result in equipment damage. 				
	Parameter F E D I can be adjusted to limit current during motoring or braking.				
	Display in Current Limit Mode: When the drive goes into current limit mode, it will: Adjust the output frequency to limit the flow of motor current (down when motoring, up when braking).				
	Display the letter C and the output frequency flashing on the embedded software terminal, ex:				
	If parameter [Unit value selection] ($F \ 7 \ 0 \ I$) is set to 1 (see page <u>130</u>), parameter $F \ 7 \ 0 \ I$ is set to 0, parameter $F \ 5 \ 0 \ I$ will be adjusted as a percentage nameplate.	neter F 6 0 / will be adju of the drive's output rated	isted in amperes. If param- d current as listed on its		
	The setting of parameter [Switch. freq. level] (F 3 0 0) (see page 95) does not change the drive's rated current for the sake of this calculation.				
	Do not set parameter <i>F E D I</i> below the no-load current rating of the motor.				

(1) See table page 199.

Motor Tuning

Tuning the drive to specific motor values will optimize motor performance if parameter [Mot cont. mode sel.] (P L) (see page <u>71</u>) is set to:

- 2 (constant V/Hz with automatic boost),
- 3 (sensorless vector control), or
- 4 (energy savings)

At a minimum, manually set parameters $\Box L$ (vL), $\Box L \Box$ (vLv), F 4 15, F 4 16, and F 4 17.

Parameters [Slip Compensation] (F + D I), [Auto Torque Boost] (F + D Z), [Frequency loop gain] (F + IB) and [Freq. loop stability] (F + IB) can be set manually or they can be set automatically using the auto tuning function, parameter [Auto-tuning drive] (F + DD).

More precise motor control adjustments can be made with parameters $F \exists D \neg$, $F \lor B D$, $F \lor B \Box$, $F \lor B \sqcup$, $F \lor B \Box$, $F \lor B \sqcup$, $F \lor B \lor$

Code	Name / Description	Adjustment range	Factory setting	
υLυ	[Motor Rated Voltage]	According to drive rating (1)	According to drive rating (1)	
	Set parameter $U L U$ (vLv) to the motor's rated voltage as indicated on the motor nam ATV212eeeM3X: 50330 V. ATV212eeeN4: 50660 V Note: Drive output voltage cannot be set to exceed the input line voltage level.	neplate.		
υL	[Motor rated freq.]	25.0 to 400.0 Hz	50.0 Hz	
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 50.0 Hz.		•	
	Set parameter $\Box L$ (vL) to the motor's rated frequency as indicated on the motor name Note: It is possible to set the drive's various motor control frequencies to 50 Hz by set 50 Hz reset. For more information, see page <u>66</u> .	plate. ting [Parameter reset] (<i>노 </i>	
EHr	[Motor thermal prot.] Motor rated current overload setting	10 to 100% of the drive's output cur- rent rating	100%	
	Set parameter $E H_{\Gamma}$ to the motor's rated current as indicated on the motor nameplate If parameter [Unit value selection] ($F \ \square I$) is set to 1 (see page <u>130</u>), parameter $E H$ If parameter $F \ \square I$ is set to 0, parameter [Motor thermal prot.] ($E H_{\Gamma}$) will be adjusted motor rated current by the drive rated current (as listed on its nameplate) and set para The setting of parameter [Switch. freq. level] ($F \ \exists \square \square$) does not change the drive's lation (see page <u>95</u>).	for the selected operation of the selected operation operat	ing voltage. mperes. s case, divide the alting percentage. sake of this calcu-	
F 6 0 7	[Mot overload time] Motor overload time	102400 s	300 s	
	NOTICE			
	RISK OF DAMAGE TO THE MOTORCheck that the motor will withstand this time without overheatingFailure to follow this instruction can result in equipment damage.			
	Parameter F 6 0 7 determines how long the drive will support a 150% motor over	rload before a fault de	etection occurs.	
F415	[Motor rated current]	0.1 to 200.0 A	According to drive rating (1)	
	Set parameter F 4 15 to the motor rated current in amperes as indicated on the motor	r's nameplate.		
F416	[Mot no-load current] Motor no-load current	10.0 to 100.0%	According to drive rating (1)	
	Set parameter F 4 1 E to the ratio of the motor's no load current to its rated current	nt.		
FYIT	[Motor rated speed] Motor rated speed	100.0 to 15000 rpm	According to drive rating (1)	
	Set parameter F 4 1 7 to the motor rated speed in rpm as indicated on the motor	's nameplate.		

(1) See table page <u>199</u>.

Auto-tuning

Before performing an auto-tune, verify that:

- A motor is connected and any load-side disconnect is closed.
- The motor is completely stopped and de-energized.
- The motor should be cool (room temperature).
- There is only one motor connected to the drive.
- All of the motor leads that will be used in the final installation are included in the output circuit during the autotuning process.
- Motor leads are no longer than 30 m (100 ft). Motor leads longer than 30 m (100 ft) may result in reduced motor torque and less than optimal motor control.
- No load reactors or filters are included in the motor circuit. Output reactors and filters may cause an autotuning detected fault E L n I and reduce effectiveness of sensorless vector control.
- The motor is not more than 1 hp size smaller than the drive.
- The motor has at least 2 and not more than 8 poles (750...3000 rpm).
- The motor does not have a high slip rating.

Auto tuning is performed upon the first start command after parameter [Auto-tuning drive] ($F \lor \Box \Box$) below is set to 1, 2 and 3 and is normally completed within 3 seconds. During the auto-tuning process, the graphic display option displays $R \vdash \Box I$.

During the auto-tuning process voltage is applied to the motor, although it barely rotates and produces very little torque.

During the auto-tuning process, the drive checks for an output phase loss detection regardless of the setting of parameter F = D = 5. An output phase loss detection E = P + D will abort the auto-tuning process.

If the auto-tuning process is unsuccessful, the drive will display $E E_{\Omega}$ /. In this event, no results of the aborted auto-tuning 1 will be saved in the drive, and a manual tuning of parameters [Slip Compensation] (F + D /), [Auto Torque Boost] (F + D /), [Frequency loop gain] (F + IB) and [Freq. loop stability] (F + IB) will be required.

Code	Name / Description	Adjustment range	Factory setting
F 4 0 0	[Auto-tuning drive]	-	0
	A DANGER HAZARD OF ELECTRIC SHOCK OR ARC FLASH • During auto-tuning, the motor operates at rated current. • Do not service the motor during auto-tuning. Failure to follow these instructions will result in death or serious injury.		
	A WARNING		
	 LOSS OF CONTROL It is essential that the following parameters <u>u</u> L <u>u</u>, <u>u</u> L, F <u>4</u> <u>15</u> and F <u>4</u> <u>17</u> are tuning. When one or more of these parameters have been changed after auto-tuning has and the procedure will have to be repeated. Failure to follow these instructions can result in death or serious injury. 	correctly configured be s been performed, <i>F</i> ५	efore starting auto-
	NOTICE		
	 RISK OF DAMAGE TO THE MOTOR Conduct auto-tuning only after the motor has been connected and operation con If auto-tuning is conducted immediately after operation stops, the presence of a tuning. Failure to follow these instructions can result in equipment damage. 	npletely stopped. residual voltage may r	esult in abnormal
٥	Auto tuning enable [Disabled]		
I	[Initialize constant]: Factory setting of [Auto Torque Boost] (F 4 D 2) for asynchronous motor. Factory setting of [Auto Torque Boost] (F 4 D 2), [Autotune L q-axis] (F 9 1 2), and [Motor Rated Voltage] (vlv) for synchronous motor.	[Autotune L d-axis] (<i>F</i>	9 / 3), and
2	[Tun Dyn. 1] : Tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), synchronous motor.	and [Autotune L d-axis	s] (F 9 I 3) for
3	[Tun Dyn. 2] : Complete tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), [Motor Rated Voltage] (vlv) for synchronous motor.	[Autotune L d-axis] (F	9 13), and
ч	[Tun Static 1] : Tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), synchronous motor.	and [Autotune L d-axis	s] (F 9 I 3) for
5	[Tun Static 2] : Complete tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), [Motor Rated Voltage] (vlv) for synchronous motor.	and [Autotune L d-axis	5] (<i>F 9 13</i>), and
	Parameter F 4 D D is reset to "0" after the auto tuning is performed.		

Expert parameters

Code	Name / Description	Adjustment range	Factory setting
F 3 9 D	[LL for ov.cur. prev.] Lower Limit function for Over Current Prevention	0.0 - <u>L</u> L	0.0
	In the present software, motor speed is decreased to 0 Hz in case the stall prewind when motor speed is lower than $F \exists g \Box$ during stall prevention, motor speed is In this situation, motor current is beyond stall prevention level ($F \sqsubseteq \Box$) or F is detected fault may occur in some case.	evention state is conti s kept to <i>F ∃ 9 0</i> to in 8 5), therefore over c	nued. crease motor current. urrent or over load
	Output Frequency (Hz)		
	Frequency command F 3 9 0 0	 → Time ON	
	RUN command (F or R)	OFF	
	Over current alarm status	ON OFF	
FYAD	[No load cur, coef] Magnetizing current coefficient	100 to 130%	100%
	Use parameter <i>F</i> 480 to fine-tune motor torque during low-speed operation. Operating range, increase the setting of parameter <i>F</i> 480. However, only adjunct yield sufficient low-speed torque. Increasing the setting of parameter <i>F</i> 480 during low-speed operation. Do not set this parameter so that the motor's no-l current.	To increase motor tor ust parameter F 4 B D 7 may increase the m oad current exceeds	que in the low-speed i if an auto tune does otor's no-load current its rated operating
F 4 8 5	[Stall control coef. 1] Stall prevention control coefficient 1	10 to 250	100
	Use parameter $F + B = 5$ to adjust the drive's response to large, sudden changes its rated frequency. If a sudden change in load causes the motor to stall before reduce the setting of $F + B = 5$.	in load when the mo the drive goes into c	tor is operated above urrent limit, gradually
F 4 9 2	[Stall control coef. 2] Stall prevention control coefficient 2	50 to 150	100
	Use parameter $F + g = 2$ to adjust the drive's response to a drop in the line supply v rated frequency. Such a drop in voltage often causes fluctuations in motor current of turbances, set parameter $F + g = 2$ to a value from 80 to 90. Note: Reducing the $F + g = 2$ setting increases the motor running current level.	oltage when the motor or vibration in the moto	is operated above its r. To reduce these dis-
F 4 9 4	[Mot. adj coefficient] Motor adjustment coefficient	-	-
	DO NOT ADJUST.		
F495	[Motor voltage coef.] Maximum voltage adjustment coefficient	90 to 120%	104%
	Use parameter <i>F</i> 4 9 5 to limit the drive's maximum output voltage. Increasing motor is operated above its rated frequency, but may also cause motor vibration motor vibrations occur.) this setting increase on. Do not increase th	s torque when the ne value of <i>F Ч <mark>9</mark> 5</i> if
F496	[PWM adj. coef.] Waveform switching adjustment coefficient	0.1 to 14.0 kHz	14.0 kHz
	Adjusting the value of parameter <i>F</i> 496 may reduce motor noise and vibration in the mid-speed operating range.	n during PWM wavef	orm frequency shifts

Supply Voltage Correction and Motor Voltage Limitation

The setting of parameter F 3 0 7 determines:

- If the drive's voltage output will be corrected for fluctuations in the line supply voltage, or
- If the drive's voltage output will be limited, despite increases in the line supply voltage.

The drive's output voltage will not exceed the input supply voltage.

If parameter $F \ni \Box$ 7 is set to 0 or 2, no corrections are made in the motor voltage gating process in response to fluctuations in supply voltage. As a result, the V/Hz value of the output waveform to the motor will change in proportion to the input voltage. Conversely, if $F \ni \Box$ 7 is set to 1 or 3, the V/Hz value of the output waveform will be held constant, despite changes in the supply voltage level.

If parameter $F \exists \Box \uparrow$ is set to 0 or 1, output motor voltage will be limited to the value set by parameter [Motor rated voltage] ($\Box L \Box$) (see page 74), even if the input supply voltage rises. If $F \exists \Box \uparrow$ is set to 2 or 3, output motor voltage can rise above the level set by $\Box L \Box$ if the input supply voltage rises above the motor rated voltage.

If parameter [Mot cont. mode sel.] (P E) is set to a value of 2, 3, 4, 5, or 6, the supply voltage is corrected, regardless of the setting of parameter $F \exists D 7$.

The diagrams below illustrate the impact of each setting of parameter F 3 D 7.



Code	Name / Description	Factory setting
FJD7	[Mot volt limitation] Supply Voltage Correction and Motor Voltage Limitation	3
0 2 	[Motor volt limit]: Supply voltage uncorrected – motor voltage limited [Line&mot correct.]: Supply voltage corrected – motor voltage limited [No action]: Supply voltage uncorrected – motor voltage unlimited [U Line correction]: Supply voltage corrected – motor voltage unlimited	

Motor 2 Control Parameters

When logic inputs assigned to functions 39 or 40 are active, parameters $F \mid 70$ to $F \mid 73$ and $F \mid 85$ are the active set of motor control parameters.

When motor 2 control parameters are active, only constant V/Hz Motor Control Mode ([Mot cont. mode sel.] (P L) = 0) is available (see page <u>71</u>).

Code	Name / Description	Adjustment range	Factory setting		
םרו F	[Mot 2 rated Freq.] Motor 2 rated frequency	25.0 to 400.0 Hz	50.0 Hz		
	Set parameter F 17 D to the motor's rated frequency as indicated on the motor name	plate.			
	Note: It is possible to set the drive's various motor control frequencies to 50 Hz by setting [Parameter reset] (<i>L J P</i>) to 1, the 50 Hz reset. For more information, see page <u>66</u> .				
FITI	[Motor 2 rated Volt] Motor 2 rated voltage	According to drive rating (1)	According to drive rating (1)		
	Set parameter <i>F</i> 171 to the motor's rated voltage as indicated on the motor namepla ATV212000M3X: 50330 V. ATV212000N4: 50660 V Note: Drive output voltage cannot be set to exceed the input line voltage.	ate.			
FITZ	[Motor 2 Volt Boost] Motor 2 voltage boost	0 to 30%	According to drive rating (1)		
FITB	[Motor 2 Overload] Motor 2 rated current overload setting	10 to 100% of the drive's output cur- rent rating	100%		
	Set parameter F 173 to the motor's rated current as listed on the motor namep	ate for the selected or	perating voltage.		
F 185	[Mot. 2 current limit] Motor 2 current limit	10 to 100% of the drive's output cur- rent rating	110%		
	NOTICE				
	 RISK OF DAMAGE TO THE MOTOR AND THE DRIVE Check that the motor will withstand this current. Check that the profile mission complies with the derating curve given in the installa Failure to follow this instruction can result in equipment damage. Adjust parameter F 18 5 to limit current during motoring or braking. Do not set parameter F 18 5 below the no-load current rating of the motor; otherwise, is taking place and will increase the frequency applied to the motor. 	ation manual. the drive will determine	that motor braking		
F 4 D I	IS taking place and win increase the nequency applied to the motor.	0 to 150%	50%		
	If [Driving Scroll] (F324) page 160 is set to [ves] (1) the setting is replaced by 0%		0070		
	Before adjusting parameter $F \neq D$ /, verify that parameter [Motor rated speed] ($F \neq I = 7$) (see page <u>74</u>) is set to the rated speed of the motor in rpm. Parameter $F \neq D$ / can be used to fine tune the drive's slip compensation feature. Increasing the value of parameter $F \neq D$ / increases the drive's compensation of motor slip.				
F 4 0 2	[Auto Torque Boost]	0.0 to 30.0%	According to drive rating (1)		
	Use parameter F 4 D 2 to adjust the amount of automatic torque boost that is applied				
	Motor rated voltage	cy (Hz)			

⁽¹⁾ See table page <u>199</u>.

Code	Name / Description	Adjustment range	Factory setting	
F 4 18	[Frequency loop gain]	1 to 150	40	
	Parameters $F + IB$ and [Freq. loop stability] ($F + IB$) reduce the speed of the drive's response to a change in speed command. The factory setting of these two parameters assumes that the inertia of the load is three times as large as that of the motor shaft. Adjust these two parameters if the factory setting is not appropriate for the application. Note: It is possible for the drive's output frequency to exceed its upper limit (parameter [Max frequency] ($F + I$)) if the acceleration parameter ($R \subseteq C$ or $F = D = T$) is set to its minimum value. Increasing the setting of parameter $F + IB$ reduces the drive's response time to changes in the speed reference.			
F419	[Freq. loop stability] Frequency loop stability	1 to 100	20	
	Increasing the setting of parameter F 4 19 further reduces the drive's response to changes in the speed reference.			

Permanent Magnet Motor Control Law ([PM Control] (РП))

Drive may be set to control synchronous motor. When [PM control] is activated, motor parameters are set to new default value. You can access to additional settings to optimize the motor control.

Motor parameters setting.

These motor parameters below are needed to set:

1 - Set (P L) [Mot cont. mode sel.] to [PM Control] (L) see page 82.

2 - Set [Motor rated freq.] (L), see page 74:

Note: Motor rated freq.] (μ L) = [Motor rated speed] (F 4 17)/(60/np) [Motor rated speed] (F 4 17), see page 74, indicated on the motor nameplate or follow the procedure step 4 above. np = Number of pole pairs, indicated on the motor nameplate.

3 - Set the Motor rated power (unit is kW) by [Motor rated cap.] (*F* 4 D 5), see page <u>82</u> Note: $P = C \times \omega$ **P** = Power in W **C** = N.m, indicated on the motor nameplate. $\omega = \text{rad s}^{-1}$ $\omega = 2\pi \times (\text{FRS/np})$ **FRS** = [Motor rated freq.] (ωL) see page <u>74</u>, indicated on the motor nameplate. **np** = Number of pole pairs, indicated on the motor nameplate.

4 - Motor rated current (unit is A) is set by [Motor rated current] (F 4 15), see page 74.

5 - Set [Motor rated speed] (F + I = 7), see page <u>74</u>, without information: Set the motor rated speed by FRS x (60 / np)

FRS = [Motor rated freq.] (μ L) see page <u>74</u>, indicated on the motor nameplate.

np = Number of pole pairs, indicated on the motor nameplate.

6 - Configure [Auto-tuning drive] (F 4 D D) to [Tun Static 2] (5), see page 83. Make the TUN (Run order is needed to start the TUN.)

- Motor's rated voltage is set by [Motor Rated Voltage] (μ L μ)^a, see page 82.

- Stator resistance is set by [Auto Torque Boost] (F 4 0 2)^a, see page 84.

- Axis "q" stator inductance in mH is set by [Autotune L q-axis] (F 9 12)^a, see page 85.

- Axis "d" stator inductance in mH is set by [Autotune L d-axis] (F 9 1 3)^a, see page 85.

7 - Check the value of [Saliency Level] (F 9 3 6), see page 84.

8 - Set [PM mode selection] (F 9 15) according to the [Saliency Level] (F 9 36) value (see page 84).

9 - If (F 9 3 6) is ≥ 0.2, increase [Init. Pos. Current] (F 9 2 1) see page 85.

Configure [Auto-tuning drive] (F 4 D D) to [Tun Static 2] (5), see page 83. Make the TUN (Run order is needed to start the TUN.)

10 - Start the motor,

- if there is current limitation on starting, increase the [PM Align cur. Level] (F 9 16) value (See page 85).

- if its behavior is not optimal, reduce by 20% [Motor Rated Voltage] (*u L u*) value (see page <u>82</u>).

- After this procedure, if you need further assistance, contact your Schneider Electric Product Support.

(a) Auto Torque Boost] ($F 4 \square 2$), [Autotune L q-axis] ($F 9 \square 2$), [Autotune L d-axis] ($F 9 \square 3$), and [Motor Rated Voltage] ($__ L __$) may be defined automatically after activation of [Auto-tuning drive] ($F 4 \square \square$) = [Tun Dyn. 2] (3) or [Tun Static 2] (5)

Code	Name / Description	Adjustment range	Factory setting		
PE	[Mot cont. mode sel.] Motor control mode selection	-	1		
	If [Driving Scroll] (F324) page 160 is set to [yes] (1) the setting is replaced by [SVC] (3)				
٥	[Constant V/Hz]: Constant V/Hz				
1	[Variable Torque]: Variable torque				
2	[Cst V/Hz+Boost]: Constant V/Hz with automatic torque boost				
E	[SVC]: Sensorless vector control				
4	[Economy]: Energy saving [Do not use]: Reserved				
6	6 [PM Control]: Permanent Magnet Motor Control Law				
	A A DANGER				
	HAZARD OF ELECTRIC SHOCK. EXPLOSION OR ARC FLASH				
	If [Mot cont. mode sel.] (Pt) is set to (6) (Permanent Magnet Motor Control Law), output	phase loss monitoring	, while the motor		
	is running, is disabled. Phase loss and, by implication, accidental disconnection of ca	bles, are not detected	if required		
	Failure to follow these instructions will result in death or serious injury.		i lequileu.		
	· · · · · · · · · · · · · · · · · · ·				
υLυ	[Motor Rated Voltage]	According to drive rating (1)	According to drive rating (1)		
	Set parameter (u, v) to the meter's relead voltage as indicated on the meter name	oplato			
	ATV212eeeM3X: 50, 330 V	epiale.			
	ATV212000N4: 50660 V				
	Note: Drive output voltage cannot be set to exceed the input line voltage level.				
	$\Box L \omega$ (vLv) may be defined automatically after activation of F 4 U U = [1 un Dyn. 2] (3)) or [Tun Static. 2] (5)	if [Mot cont. mode		
	[Motor rated freq]	25.0 to 400 Hz	50 0 H-7		
02		25.0 10 400 HZ	50.0 HZ		
	Set parameter $\frac{L}{L}$ (vL) to the motor's rated frequency as indicated on the motor nameplate.				
	Note: It is possible to set the drive's various motor control frequencies to 50 Hz by sett 50 Hz reset. For more information, see page 66.	ing [Parameter reset] (<i>E </i>		
6406		0.044 75 1044			
כטרי	[Motor rated capacity	0.01 to 75 kW	According to		
			unveracing (1)		
	Set parameter F 4 0 5 to the motor rated capacity in kilowatt.	A subscription of shires 1			
	It permite to calculate automatically [Motor Rated Voltage] (L) after TUN F 4 U U	Auto-tuning drivej	1		
F4 15	[Motor rated current]	0.1 to 200.0 A	According to		
			drive rating (1)		
	Set parameter F 4 15 to the motor rated current in amperes as indicated on the moto	r's nameplate.			
FYIT	[Motor rated speed] Motor rated speed	100.0 to 15000 rpm	According to		
			drive rating (1)		
	Sat parameter 5 H 1.7 to the mater rated aread in rom as indicated on the mater's par	monlato	2.7		
		nepiale.			

(1) See table page <u>199</u>.

EYNN	[Auto-tuning drive]		0		
		-	0		
	A DANGER				
	HAZARD OF ELECTRIC SHOCK OR ARC FLASH				
	 During auto-tuning, the motor operates at rated current. Do not service the motor during auto-tuning. 				
	Failure to follow these instructions will result in death or serious injury.				
	 LOSS OF CONTROL It is essential that the following parameters <u>u L u</u>, <u>u L</u>, <u>F 4 15</u> and <u>F 4 17</u> are tuning. 	correctly configured t	pefore starting auto-		
	When one or more of these parameters have been changed after auto-tuning has and the procedure will have to be repeated. Failure to follow these instructions can result in death or serious injury	is been performed, F	4 🛛 🖓 will return 🖉		
	Tanure to follow these instructions can result in death of serious injury.				
	NOTICE				
	 RISK OF DAMAGE TO THE MOTOR Conduct auto-tuning only after the motor has been connected and operation completely stopped. If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in at tuning. Failure to follow these instructions can result in equipment damage 				
٥	Auto tuning enable [Disabled]				
I	[Initialize constant]: Factory setting of [Auto Torque Boost] (F 4 D 2) for asynchronous motor. Factory setting of [Auto Torque Boost] (F 4 D 2), [Autotune L q-axis] (F 9 1 2), and [[Motor Rated Voltage] (vlv) for synchronous motor.	Autotune L d-axis] (<i>F</i>	9 / 3), and		
2	[Tun Dyn. 1] : Tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), and [Autotune L d-axis] (F 9 13) for synchronous motor.				
Э	[Tun Dyn. 2] : Complete tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (<i>F</i> 4 0 2), [Autotune L q-axis] (<i>F</i> 9 12), [Motor Rated Voltage] (vIv) for synchronous motor.	[Autotune L d-axis] (<i>F</i>	5 9 / 3), and		
4	[Tun Static 1] : Tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), and [Autotune L d-axis] (F 9 13) for synchronous motor.				
5	[Tun Static 2] : Complete tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), a [Motor Rated Voltage] (vIv) for synchronous motor.	and [Autotune L d-axi	s] (<i>F 9 3</i>), and		
	Parameter F 4 D D is reset to "0" after the auto tuning is performed.				
F 4 5 8	[Current loop gain] Current loop gain	0100 Hz	0 Hz		
	Parameter <i>F</i> 4 5 <i>B</i> is set to the response gain of current loop. If [Mot cont. mode sel.] (Pt) page <u>82</u> is set to [PM control] (6) the setting is replaced b	y 25 Hz.			
	Note: Contact Schneider electric product support to confirm the modification of this pa	arameter.			
	1				

(1) See table page 199.

F4 18	[Frequency loop gain]		1 to 150	40
	Parameters $F \ 4 \ 1B$ and [Freq. loop stability] ($F \ 4 \ 1B$) reduce the speed of the drive's response to a change in speed command. The factory setting of these two parameters assumes that the inertia of the load is three times as large as that of the motor shaft. Adjust these two parameters if the factory setting is not appropriate for the application. Note: It is possible for the drive's output frequency to exceed its upper limit (parameter [Max frequency] ($F \ H$)) if the acceleration parameter ($R \ C \ C \ or \ F \ 5 \ D \ 7$) is set to its minimum value. Increasing the setting of parameter $F \ 4 \ 1B \ reduces the drive's response time to changes in the speed reference.$			
F419	[Freq. loop stability] Freque	ency loop stability	1 to 100	20
	Increasing the setting of parameter F	4 / 9 further reduces the drive's response to cha	nges in the speed refe	rence.
F 4 9 5	[Motor voltage coef.] Maxim	num voltage adjustment coefficient	90 to 120%	104%
	Use parameter <i>F</i> 4 9 5 to limit the drive's maximum output voltage. Increasing this setting increases torque when the motor is operated above its rated frequency, but may also cause motor vibration. Do not increase the value of <i>F</i> 4 9 5 if motor vibrations occur.			
F936	[Saliency Level] Salien	cy coefficient for PM motor	0 to 2.55	0
	PM type [PM mode selection] ($F = I$ F = F = F = 0.2 = high saliency F = F = F = 0.2 = low saliency. Note: This parameter is automatically	5) is selected by the saliency level [Saliency Lev computed with the setting of [Autotune L q-axis] (el] (<i>F 9 3 5</i>) F912) and [Autotune L	_ d-axis] (F913)
F 9 / S	[PM mode selection] PM co	ontrol mode selection	-	3
0 1 2 3 4	[Basic Ctrl]: basic control [Ctrl Type1]: control type 1 (for IPM, ir [Ctrl Type2]: control type 2 (for IPM, ir [Ctrl Type3]: control type 3 (for IPM / Si [Ctrl Type4]: control type 4 (for IPM / Si	nterior-buried Permanent Magnet motor) nterior-buried Permanent Magnet motor) PM, interior-buried Permanent Magnet motor / Sur PM, interior-buried Permanent Magnet motor / Sur	face-mounted Perman	ent Magnet motor) ent Magnet motor)

Refer to the following tables to select the setting of the parameter F 9 15, F 9 15 is selected by the saliency level F 9 3 6

	 big starting torque is needed. for constant torque application.(1) 	 big starting torque is not needed. for variable torque application (2) 	 big starting torque is not needed for variable torque application motor electrical magnetic noise is forbidden (3)
The saliency level is high ($F = 3 = 6 \ge 0.2$)	F915 = 4 or 2	F915 =1 or 3	F915 =0
The saliency level is low ($F = 3 = 6 < 0.2$)		F915 =3	

(1) There is some motor electrical magnetic noise at start and low speed area.(2) There is some motor electrical magnetic noise at start. It can not be started in case of high start-up torque.

(3) It goes opposite direction at start sometimes. It cannot be started in case rotor saliency is high.

Code	Name / Description	Adjustment range	Factory setting
F 4 D 2	[Auto Torque Boost]	0.0 to 30.0%	According to drive rating
	Use parameter F 4 D 2 to adjust the amount of automatic torque boost that is appli	ied.	
	Motor rated voltage		
	Motor Rated Frequency UL Output Frequ	iency (Hz)	

F 9 1 2			
	[Autotune L q-axis] q-axis self-inductance	0.01 to 650 mH	10
	Axis "q" stator inductance in mH The setting is replaced by the result of the auto-tuning operation, if it has been perf	ormed.	
	Measured between the neutral and the phase, its value could be differente than the [Autotune L q-axis] (F 9 12) is defined automatically after activation of [Auto-tunin	e datasheet of the moto g drive] (F 4 0 0) = [T	or. iun Dyn. 2] (3)
F 9 3	[Autotune L d-axis] d-axis self-inductance	0.01 to 650 mH	10
	Axis "d" stator inductance in mH The setting is replaced by the result of the auto-tuning operation, if it has been perf	ormed.	
	Measured between the neutral and the phase, its value could be differente than the [Autotune L q-axis] ($F = I = J$) is defined automatically after activation of [Auto-tunin	e datasheet of the mot g drive] (<i>F Կ D D</i>) = [T	or. ['] un Dyn. 2] (3)
F 9 16	[PM Align cur. Level] Stabilization at the starting and low speed(for PM)	0 to 100 %	25 %
	It might be able to stabilize the motor rotation behavior by the current in D axis at n	o load when starting o	or low-speed
	If you have a torque jolt, when starting / stopping or low-speed, it is recommended If $E - 2D$ [Excess torque boost fit] trip occurs at the start, it is recommended to inc	to increased the settin reased the setting of	g of 9 /6. 9 /6.
	In the case of F915=0, 1, 2, 3		
	Current Level (%)		
	F916 to 25 % Stabilization current in D axis		
	0 K*En (K*ul.)	Potor speed	
		Rotor speed	
	In the case of F915=4		
	Current Level (%)		
	Stabilization ourrant in D ovi		
		8	
	F916 to 25 %	3	
	F916 to 25 %	3	
	F916 to 25 %	3	
	F916 to 25 %	3	
	F916 to 25 % 0 K*Fn (K*vL)	s Rotor speed	- 1
	F916 to 25 % 0 K*Fn (K*vL) Starting current F916 is set 25% as the default setting, Limit it to the value of about 75% in the maximum with consideration of copper loss If the loss of motor at no load is made decreased, please decrease the value of F9	Rotor speed and iron loss of the m f6 confirming the stab	- I notor. ility when starting.
F 9 2 1	F916 to 25 % 0 K*Fn (K*vL) Starting current F916 is set 25% as the default setting, Limit it to the value of about 75% in the maximum with consideration of copper loss If the loss of motor at no load is made decreased, please decrease the value of F9 [Init. Pos. Current] Current for initial position estimation	Rotor speed and iron loss of the m f6 confirming the stab	notor. ility when starting.
F 9 2 1	F916 to 25 % 0 K*Fn (K*vL) Starting current F916 is set 25% as the default setting, Limit it to the value of about 75% in the maximum with consideration of copper loss If the loss of motor at no load is made decreased, please decrease the value of F9 [Init. Pos. Current] Current for initial position estimation In case of position detection 3, the current level can be set by this parameter, during the maximum current level can be adjusted by this parameter setting.	Rotor speed and iron loss of the m 16 confirming the stab 10 to 150 % the auto-tuning for d a	notor. ility when starting. 100 % axis / q axis inductance,
F 9 2 1 F 4 2 0	F916 to 25 %	Rotor speed and iron loss of the m 16 confirming the stab 10 to 150 % the auto-tuning for d a 0 to 200%	notor. ility when starting. 100 % axis / q axis inductance, 90 %
F 9 2 1 F 4 2 D	F916 to 25 % F916 to 25 % K*Fn (K*vL) Starting current F916 is set 25% as the default setting, Limit it to the value of about 75% in the maximum with consideration of copper loss If the loss of motor at no load is made decreased, please decrease the value of F9 [Init. Pos. Current] Current for initial position estimation In case of position detection 3, the current level can be set by this parameter, during the maximum current level can be adjusted by this parameter setting. [Torque Boost Coef] Compensation coefficient of torque boost If synchronous or asynchronous motor is used, F 42 D [Torque Boost Coef] is set If you have a torque jolt, when starting / stopping or low-speed, increase the value of F9	Rotor speed and iron loss of the m 16 confirming the stab 10 to 150 % the auto-tuning for d a 0 to 200% to 90%. of <i>F H 2 D</i>	notor. ility when starting. 100 % axis / q axis inductance, 90 %

Parameters described in this page can be accessed by the extended menu

Code	Name / Description	Adjustment range	Factory setting	
F 9 4	[N-S direction] Method of detection	0 - 1	0	
	N-S Method of detection.	<u> </u>		
0 1	If $F = 14 = 0$, the N-S direction of rotor position is judged by the method of DC offs If $F = 14 = 1$, the N-S direction of rotor position is judged by the method of AC offs	set for position detection set for position detection de	on. on.	
	Note : N-S method of detection is available if [PM mode selection] (F915) is set to	[Ctrl Type1] (1) or [Ctrl	Type2] (2)	
F 9 7	[PM Max torq. Ctrl] Max torque control activation (for IPM)	0 - 1	1	
	[0] : Deactivation [1] : Activation			
F918	[Cur. phase adjt]	- 45.0 to 45.0	0	
	It is possible to aim the higher efficiency in the case of IPM (Interior Permanent Magnet), by activation of [PM Max torq. Ctrl] (F917) which makes required current the minimum, the loss of m otor and driver may be reduced and the efficiency may be attained higher level.			
F 9 2 D	[Position Adjust]	0 - 150 %	0 = Auto	
	In case of heavy load, the estimated position can be adjusted by setting this param	eter.		
	Adjustment for position estimation, available if [PM mode selection] (F915) is set to	[Ctrl Type2] (2) or Ctr	rl Type4] (4).	

Drive Control Parameters

6

Code	Name / Description		Adjustment range	Factory setting	
C N D d	[Command mode sel] Remote Mode S	Start/Stop Control	-	0	
0 2	The setting of parameter [[]] d determines the source of start, stop, forward, and reverse operation commands when the drive is in remote mode. The drive needs to be stopped to make changes to parameter []] d. See diagram on page 50 and description page 54 for more information on the source of the drive's operation commands. [Logic inputs]: Control terminal logic inputs [HMI]: Graphic display option [Communication]: Serial communication				
FNDd	[Frequency mode sel] Remote Mode F	Primary Speed Reference Source	-	1	
 2 4 5	 The setting of parameter <i>F</i> ∩ □ <i>d</i> determines the source of the drive's speed reference when the drive is in remote mode. The drive needs to be stopped to make changes to parameter <i>F</i> ∩ □ <i>d</i>. See diagram on page <u>50</u> and description page <u>54</u> for more information on the source of the drive's speed reference. [Ref source VIA]: VIA [Ref source VIB]: VIB [HMI reference]: Graphic display option [Serial com ref.]: Serial communication [+/- Speed]: +/- Speed 				
FL	[Local speed ref.] Local Mode Spe	eed Reference	LL-UL	0.0 Hz	
	The speed reference set by the UP/DOWN keys in local mode will be stored in parameter $F \ L$ when the ENT key is pressed. The next time the drive is Power ON in local mode, it will accelerate the motor directly to the speed setpoint memorized by $F \ L$.				
Fr	[Local mot. direction] Local Mode Mo	tor Rotation Direction Command	-	0	
0 1 2 3	1 [Run FW]: Run forward only. 1 [Run rev.]: Run reverse only. 2 [Run FW+rev]: Run forward with reverse selectable. 3 [Run rev+FW]: Run reverse with forward selectable. 1 If $F r$ is set to 2 or 3: The motor direction can be changed in local mode to forward by pressing the UP key while holding the ENT key and to reverse by pressing the DOWN key while holding the ENT key. The new motor direction will be displayed (forward = $F r - F$, reverse = $F r - r$) before the motor direction is reversed.The motor's last operating direction in local mode will be stored before a power removal or loss detection. When power is restored to the drive, the local mode motor rotation direction will be the same as before the power loss detection.				
	will assume the same motor rotation direction as in r	remote mode, regardless of the setting	g of F r .		
FTOT	[Loc. speed ref. step] Local Mode Spe	eed Reference Step Changes	-	0.0 Hz	
0 	[Disable]: Disabled (0.00). [Enable]: Enabled (0.01 to Maximum Frequency [Max frequency] (<i>F H</i>) in Hz). If parameter <i>F</i> 707 is disabled in local mode, the drive's speed reference will change in steps of 0.1 Hz each time the UP or DOWN key is pressed.				
	If parameter F 7 D 7 is enabled in local mode, the d time the UP or DOWN key is pressed.	rive's speed reference will change in s	steps equal to the settir	ng of F 7 D 7 each	
	Enabling parameter F 7 D 7 only affects drive opera	ation if parameter [Customized freq va	al] (<i>F</i> 7 0 2) is set to 0.	00. See page <u>131</u> .	
	If the display flashes " H 1" or " L D ", it indicates that r to reach either the [Low limit frequency] (L L) (see p eter F 7 D 7 is set to a value larger than 0.00 Hz.	repeated usage of the UP or DOWN ke age <u>92</u>) or the [Upper limit freq] (<i>U L</i>)	eys has caused to drive (see page <u>92</u>). This ma	's speed reference ay happen if param-	

Code	Name / Description	Adjustment range	Factory setting			
FTZI	[Loc. mot stop mode] Local Mode Motor Stop Type	-	0			
	The setting of parameter <i>F</i> 7 <i>2</i> / determines the type of motor stop that will be executed when then embedded display terminal STOP key is pressed.					
	The RUN and STOP keys needs to be enabled be setting parameter [Run/stop key] (F 7 3 3) (see page 90) to 0 for the motor to stop when the embedded display terminal STOP key is pressed.					
0 1	[Ramp stop]: Ramp stop [Freewheel]: Freewheel stop					
F 2 9 5	[Switch rem/Local] Bumpless transfer from remote to local control	-	1			
	If parameter <i>F 2</i> 9 5 is enabled, the speed reference, run and direction commands will be when the LOC/REM key is pressed. Operation of the drive is not affected by a remote to I	e transferred from remo ocal control mode trans	te to local mode ition.			
	If parameter <i>F</i> 2 9 5 is disabled, a remote to local control mode transition will cause the onew run command and speed reference will need to be entered in the local mode.	drive to remove power f	rom the motor. A			
	Regardless of the setting of parameter $F \ge 95$, a local to remote transition will cause the c commands present at the moment of the transition.	Irive to immediately resp	oond to the remote			
0 1	[No bumpless]: Bumpless disabled [Bumpless]: Bumpless enabled					
F 2 5 6	[Time limit low spd]	0.0 to 600 s	0.0 s			
0 1	[Disable]: (0.0) [Enable]: (0.01 to 600 seconds) If parameter <i>F</i> 2 5 <i>b</i> is enabled and if the drive operates continuously at [Low limit frequency] (<i>L L</i>) (see page <u>92</u>) for a time period equal to the setting of <i>F</i> 2 5 <i>b</i> , the drive will ramp the motor to a stop. While the motor is stopped, " <i>L</i> 5 <i>b P</i> " will flash on the drive embedded display terminal.					
	When the speed reference to the drive exceeds the low speed level $L + F = 9$, the drive will accelerate the motor to the new speed reference.					
	If parameter <i>F</i> 2 5 6 is enabled, drive operation at or below the low speed level is also monitored during startup or during reversing of the motor. See diagram below.					
	Output frequency (Hz)					
	A A A A A A A A A A A A A A A A A A A					
			me (s)			
		OFF				
	Run F256 F256 F256 Command					
F 2 O 7	[Remote spd ref 2]	-	2			
1	VIA					
3	HMI Communication					
5	+/- Speed					
	Parameter [Remote spd ref 2] ($F \ge D$ 7) defines the remote mode secondary speed reference to/man speed ref] ($F \ge D$ D) (see page <u>118</u>) determines whether this source is used for the lf $F \ge D$ D is set to 0, a logic input terminal set to function 38 (see page <u>118</u>) determines if speed reference source. If $F \ge D$ D is set to 1, [Remote spd ref 2] ($F \ge D$ 7) is the speed reference source when the See diagram on page <u>50</u> for more detail.	ence source. The setting e speed reference. [Remote spd ref 2] (<i>F 2</i> drive's output frequenc	of parameter [Au- 7) identifies the y is 1 Hz or below.			

Code	Name / Description	Adjustment range	Factory setting		
F 6 5 0	[Forced fire control]	-	0		
	A WARNING				
	LOSS OF CONTROL The value of F 5 5 D will impact the direction of the motor. - Check wiring motor power UVW is correct. - Verify that the value of F 5 D is convenient for this application. Failure to follow these instructions can result in death, serious injury, or equipment damage.				
0 1 2	 [Disable] [Enable forward] [Enable Reverse] To enable Forced fire control, set parameter <i>F</i> <u>6</u> <u>5</u> <u>0</u> to <i>1</i> or <u>2</u> and assign a logic input to function 52 or 53 (see page <u>104</u>). When parameter <i>F</i> <u>6</u> <u>5</u> <u>0</u> is set to <i>1</i> or <u>2</u>, the embedded display will briefly flash the code <i>F</i> <u>1</u> <u>r</u> <u>E</u>. If parameter <i>F</i> <u>6</u> <u>5</u> <u>0</u> is set to 1 or <u>2</u> and a logic input assigned to function 52 or 53 is activated, the drive will run at the frequency set by parameter [Forced speed freq.] (<i>F</i> <u>2</u> <u>9</u> <u>4</u>) (see below). 				
	 Note: First set [Motor direction] (F 3 / I) page <u>96</u> to allow forward or reverse operation. Push the ENT button for 2 sec to complete the setting. See F 5 5 9 for more information of the behavior. 				
F659	[Forced fire function]	-	0		
٥	[Enable transition] When parameter $F = 5 = 9$ is set to D , the function is enabling on transition 0>1 of the logic the function.	input. The transition 1	>0 will not disable		
	A WARNING				
	LOSS OF CONTROL If the Forced fire mode on logic input (function 52) has been enabled and $F = 5 = 9$ is set to D , the drive will run and only removing power from the drive will stop it. If the Fire mode on logic input (function 53) has been enabled and $F = 5 = 9$ is set to D , the drive will run and only removing power from the drive or a fault detection or a pressing on the STOP key on the display terminal will stop the drive. Check that this value of $F = 5 = 9$ is convenient for the application.				
I	[Enable level 1] When parameter <i>F</i> 5 9 is set to <i>I</i> , if the logic input is set to 0 the function is disabled. If the logic input is set to 1 the function is enable				
	 RISK OF APPLICATION MALFUNCTION When <i>F</i> <u>6</u> <u>5</u> <u>9</u> is set to <i>I</i> for safety reason, the forced mode will be inhibited if the logic input is inactivated for any reason (order removed, input broken, wiring contact lost). Check that this value of <i>F</i> <u>6</u> <u>5</u> <u>9</u> is conveniant for the application. If you need to continue to run if forced mode in any circonstance, select an other value of <i>F</i> <u>6</u> <u>5</u> <u>9</u>. Eailure to follow these instructions can result in death serious injunt, or equipment demage. 				
2	[Enable level 0] When parameter $F = 5 = 9$ is set to 2 , if the logic input is set to 1 the function is disabled. If the logic input is set to 0 the function is enable.				
	Changes UNINTENDED EQUIPMENT OPERATION When F 6 5 9 is set to 2 for safety reason, the motor will run at Forced speed F 2 9 4 in case of intempestive wire disconnet - Check and control the wiring connection periodically. - Protect the signal conductors against damage that could result in unintentional conductor grounding. Failure to follow these instructions will result in death or serious injury.				
F 2 9 4	[Forced speed freq.]	LL-UL	50.0 Hz		
	The F 2 9 4 parameter is used to set the fixed frequency command for the drive when it	is in Forced or Fire mod	le.		

Code	Name / Description	Adjustment range	Factory setting		
FIJO	[Up/down key ref] 0				
0 1	The setting of parameter <i>F</i> 7 3 0 determines whether it is possible to set the drive's spee minal in local mode. [Enable] [Disable]	d by means of the emb	bedded display ter-		
FTJZ	[Loc/rem key]		0		
	Use parameter $F \uparrow \exists z$ to enable or disable the LOC/REM key on the drive embedded display terminal. If the LOC/REM key is disabled, switching between local and remote mode can be achieved with parameters [Frequency mode sel] ($F \sqcap \Box d$) and [Command mode sel] ($E \sqcap \Box d$). See page <u>87</u> .				
٥	[Permitted memo]: still retained with the power off.				
י ב	[Permitted no memo]: cancelled with the power off.				
FTJJ	[Run/stop key]		0		
0 1	[Enable] [Disable]				
	The setting of parameter F 7 \exists \exists determines whether it is possible to start and stop on the drive and graphic display option.	the drive by the Run/S	Stop keys located		
FT34	[Priority stop]				
	A WARNING				
	LOSS OF CONTROL You are going to disable the stop button located on the drive and graphic display option Do not select / unless exterior stopping methods exist. Failure to follow these instructions can result in death, serious injury, or equipment	t damage.			
	The setting of parameter $F \uparrow \exists \forall$ determines whether it is possible to stop the drive by the display option.	Stop key located on the	e drive and graphic		
0 1	[Enable] [Disable]				
F 7 3 5	[HMI reset button]		1		
	The setting of parameter [HMI reset button] (F 7 3 5) determines whether it is possible to the embedded display terminal STOP key (see page <u>55</u> for more detail).	clear a drive detected	fault by means of		
0 1	[Enable] [Disable]				

Application Parameters

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Skip Frequencies	97
DC Injection Braking Parameters	98

Application parameters

Code	Name / Description	Adjustment range	Factory setting		
F H	[Max frequency] Maximum Frequency	30.0 Hz to 400.0 Hz	50.0 Hz		
	 If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 90%. The setting of parameter <i>F H</i> determines the maximum output frequency of the drive. <i>F H</i> limits the setting of parameter [Upper limit freq] (<i>U L</i>) (see page <u>92</u>), which can be adjusted while the drive is operating. Acceleration and deceleration rates are also affected by the setting of <i>F H</i>, as the definition of [Acceleration time 1] (<i>H L C</i>) or [Deceleration time 1] (<i>H E C</i>) (see page <u>93</u>) is the time it takes for the drive to ramp the motor up or down between zero speed and the setting of <i>F H</i>. <i>F H</i> can only be adjusted while the drive is stopped. 				
	Output frequency (Hz) Output frequence	cy (Hz)			
	⁰ Speed Reference 100%	⁰ Speed Reference 100%			
U L	[Upper limit freq] High speed	0.5 to [Max frequency] (F H)	50.0 Hz		
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replace	ed by 90%.	I		
	Parameter <i>UL</i> sets the maximum frequency that can be commanded to the The top end of its range is limited by the setting of Maximum frequency [he drive by the local or remote speed Max frequency] (<i>F H</i>). See diagram	reference source. above.		
LL	[Low limit frequency] Low speed	0.0 to [Upper limit freq] (UL)	0.0 Hz		
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 30%. Parameter <i>L L</i> sets the minimum frequency that can be commanded to the drive by the local or remote speed reference source. See diagram above.				
F 2 4 0	[Mot start freq.] Output Starting Frequency	0.5 to 10.0 Hz	0.5 Hz		
	The setting of parameter <i>F 2 4 D</i> determines the drive's output frequence no acceleration time to reach the parameter <i>F 2 4 D</i> level.	by at the moment it receives a start co	mmand. There is		
	Parameter <i>F</i> ² ⁴ ⁰ is typically set for the rated slip frequency of the motor. This allows motor torque to be generated as soon a a start command is given. Adjust parameter <i>F</i> ² ⁴ ⁰ when a delay in the motor's response to a start command adversely affect the application.				
	To determine the motor's slip frequency: 1) Subtract the motor's rated speed at full load from it's no-load speed (in rpm). 2) Divide the result by the no-load speed. 3) Multiply this result by the motor's rated frequency in Hz.				
	Example: Motor no-load speed = 1500 rpm Motor rated speed at full load = 1450 rpm Motor rated frequency = 50 Hz				
	1500 rpm – 1450 rpm = 50 rpm 50 rpm / 1500 rpm = 3.33% 50 Hz x 0.0333 = 1.7 Hz (motor slip frequency)				

Code	Name / Description	Adjustment range	Factory setting		
A C C	[Acceleration time 1]	0.0 to 3200 s	According to drive rating (5)		
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replace	ed by 0.9 s.			
	The setting of parameter $R [L]$ determines the slope of the acceleration ramp and the time it takes for the output frequency of the drive to increase from 0 Hz to the setting of [Max frequency] (F H) (see page 92). If parameter [Auto ramp] (R U I) (see page 95) is set to 1 or 2, the acceleration ramp may be increased or decreased from the setting of $R [L]$, depending on the amount of load on the motor during ramp up. If two different acceleration rates are needed, see parameter [Acceleration time 2] (F 5 D D) on page 93. Output frequency (Hz) $E = \begin{bmatrix} E \\ 0 \end{bmatrix} = \begin{bmatrix} E \\ 0 \end{bmatrix} \begin{bmatrix} E \\ 0 \end{bmatrix}$				
d E C	[Deceleration time 1]	0.0 to 3200 s	According to drive rating (5)		
	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replace	ed by 0.9 s.			
	The setting of parameter $d \in C$ determines the slope of the deceleration the drive to decrease from the setting of [Max frequency] ($F H$) to 0 Hz.	n ramp and the time it takes for the c	output frequency of		
	If parameter [Auto ramp] (<i>R U I</i>) is set to 1, the deceleration ramp may be increased or decreased from the setting of <i>d</i> depending on the amount of load on the motor during ramp down. See diagram above.				
	If two different deceleration rates are needed, see parameter [Deceleration]	ion time 2] (F 5 0 1) on page <u>93</u> .			
F 5 0 0	[Acceleration time 2]	0.0 to 3200 s	20.0 s		
	Parameter <i>F</i> 5 0 0 sets the second acceleration time. Switching betwee of:	n acceleration rates 1 and 2 is acco	mplished by means		
	Parameter [Ramp switching] ($F \le D 4$) (see page <u>95</u>), A particular operating frequency (see parameter [Commut. ramp freq.] (A logic input assigned to functions 5, 20, 21, 30, 31 – 35, or 40 (see table	F 5 0 5) on page <u>95</u>), or			
	Output Frequency (Hz)				
	Ī				
	Speed Reference				
	 (1) <i>FLC</i> Acceleration Slope (2) <i>F</i> 5 <i>D</i> Acceleration Slope (3) <i>F</i> 5 <i>D</i> I Deceleration Slope (4) <i>dEC</i> Deceleration Slope 				
	Acceleration/Deceleration Switching		Time (S)		
	Logic Input	(3) (4)			
F 5 0 1	[Deceleration time 2]	0.0 to 3200 s	20.0 s		
	 Parameter F 5 0 / sets the second deceleration time. Switching betwee of: Parameter [Ramp switching] (F 5 0 4) (see page 95), A particular operating frequency (see parameter [Commut. ramp freq.] A logic input assigned to functions 5, 20, 21, 30, 31 – 35, or 40 (see table) 	In deceleration rates 1 and 2 is according $(F 5 D 5)$ on page <u>95</u>), or ble beginning on page <u>101</u>).	mplished by means		
	(5) See table nage 199				



Code	Name / Description		Adjustment range	Factory setting
F 5 0 4	[Ramp switching]	Acc/Dec Pattern Selection	-	1
I Z	[Ramp 1] [Ramp 2] Parameter <i>F</i> 5 <u>D</u> 4 determines Output Frequency <i>F</i> <i>F</i> 5 <u>D</u> 4= 1 <i>F</i> 5 <u>D</u> 4= 2	the Acc/Dec pattern. (Hz) H H H H H H H H	Time (S)	-
F 5 0 5	[Commut. ramp freq.]	Acc/Dec pattern switching frequency	0.0 to [Upper limit freq] (<i>UL</i>) (Hz)	0.0 Hz
	If parameter <i>F</i> 5 0 5 is set to a pattern 2 above.	frequency greater than 0.0, the drive will us	se Acc/Dec pattern 1 above that free	quency and Acc/Dec
	Output Frequency (Hz)			
	Speed F (1) R C Acceleration (2) F 5 0 0 Acceleration (3) F 5 0 1 Deceleration (4) d E C Deceleration	Reference		
	Acceleration/Deceleration Switch Logic Input	ning $0 \rightarrow 4$ (1) (2)	(3) (4)	Time (S)
RU I	[Auto ramp]	Auto ramp adaptation		1
0 1 2	[Disabled] [Enable] - [Acceleration time 1 [ACC only] - [Acceleration tim	l] (<i>F </i>	.) (see page <u>93</u>)	
	If parameter <i>RU</i> is set to 1 of ramps. The acceleration and do of [Acceleration time 1] (<i>RCC</i> the motor. <i>RCC</i> and <i>dEC</i> sh rapidly during ramp up or ramp current or overvoltage.	or 2, the drive will monitor its own loading eccleration ($\mathcal{R} \sqcup I = 1$ only) rates will be au) and [Deceleration time 1] ($\mathcal{A} E L$), deper ould be appropriately set for an average lo down, the auto ramp adaptation feature m	level and optimize the acceleration utomatically adjusted between 1/8 to nding on the drive's current rating a bad in the application. If the load on hay not help prevent the drive from e	and deceleration b 8 times the settings and the load level on the motor increases experiencing an over-
	If the application requires a conneeded. The manual accelerat <u>73</u>) and [Overvoltage fault] (<i>F</i>	nsistent acceleration and deceleration time ion and deceleration times can still be over $\frac{3}{9}$ (see page 139) and [Overvoltage le	e, set <i>R U I</i> to 0, and set <i>R E E</i> and rridden by the [Motor Current Limit] evel] (<i>F E 2 E</i>) (see page <u>139</u>) fund	d d E C manually as (F E D I) (see page ctions.
F 3 0 0	[Switch. freq. level]	Switching Frequency Level	6.0 to 16.0 kHz in 0.1 kHz steps	According to drive rating (1)
	Increasing the switching freque Increasing the switching freque accordingly if the switching fre	ency may reduce audible motor noise. ency will increase the heat dissipated by the quency is increased. See the derating cur	e drive. The capacity of the drive ma ves in the ATV212 Installation Man	y need to be derated uual.

(5) See table page <u>199</u>.

Code	Name / Description	Adjustment range	Factory setting
F J I I [Motor direction]		-	1
	Use parameter F 3 / / to permit only forward or reverse operation.		
	If [Driving Scroll] (F324) page 90 is set to [yes] (1) the setting is replaced	by [FW only] (1).	
٥	[Fw & Rev.]		
2	[Fw only] [Rev. only]		
F 3 1 2	[Noise reduction] Switching Frequency Random Mode		0
0 1	Random control of the switching frequency may reduce audible motor no Random control of the switching frequency will not be performed if the switch setting of $F = 12$. [Disable] [Enable]	bise. witching frequency is set above 7.1 k	Hz, regardless of
F 3 1 6	[Switch. freq. mode] Switching frequency control mode		1
0 2 3	[Fixed] - ATV212eeeM3X and ATV212eeeN4: switching frequency NOT [Auto] - ATV212eeeM3X and ATV212eeeN4: switching frequency autor [460 V fixed] - ATV212eeeN4 (2): switching frequency NOT automatical [460 V Auto] - ATV212eeeN4 (2): switching frequency automatically red If parameter $F \exists I B$ is set to 1 or 3, the switching frequency level will be heating. If the drive senses an impending overheating, it will reduce the secontroller. As the temperature approaches normal, the switching frequency freq. level] ($F \exists D D$).	automatically reduced natically reduced ly reduced uced a automatically controlled to help prev witching frequency, thus reducing hea cy will return to the level selected by p	vent a drive over- at produced by the parameter [Switch.

(1) See table page <u>200</u>.
(2) For 400 V applications with motor leads longer than 30 m (100 ft).

Skip Frequencies

Do not set the skip frequency bands so that they overlap.

While the drive will not operate within these skip frequency bands during steady state operation, skip frequency bands are ignored by the drive during motor acceleration and deceleration.

Code	Name / Description		Adjustment range	Factory setting
F 2 7 0	[Jump frequency 1]	Skip frequency 1 midpoint	0.0 to [Max frequency] (F H)	0.0 Hz
FZTI	[Jump bandwidth 1]	Skip frequency 1 bandwidth	0.0 to 30.0 Hz	0.0 Hz
F 2 7 2	[Jump frequency 2]	Skip frequency 2 midpoint	0.0 to [Max frequency] (F H)	0.0 Hz
FZTB	[Jump bandwidth 2]	Skip frequency 2 bandwidth	0.0 to 30.0 Hz	0.0 Hz
				•
F 2 7 4	[Jump frequency 3]	Skip frequency 3 midpoint	0.0 to [Max frequency] (F H)	0.0 Hz
F 2 7 5	[Jump bandwidth 3]	Skip frequency 3 bandwidth	0.0 to 30.0 Hz	0.0 Hz
				-

DC Injection Braking Parameters

The drive can inject DC current into the motor to apply braking torque to the load. Parameters [DC brake start freq.] ($F \ge 5 D$), [DC braking current] ($F \ge 5 I$) and [DC braking time] ($F \ge 5 D$) determine the Output Starting Frequency, current level, and braking time.

During DC injection braking, the drive's switching frequency is 6 kHz regardless of the setting of parameter [Switch. freq. level] ($F \exists \Box \Box$) (see page <u>95</u>).



Code	Name / Description	Adjustment range	Factory setting		
F 2 5 D	[DC brake start freq.]	0.0 to [Max frequency] (F	H) 0.0 Hz		
		A WARNING			
	 NO HOLDING TORQUE DC injection braking does not provide holding torque at zero speed. DC injection braking does not work when there is a loss of power or when the drive detects a fault. When necessary, use a separate brake to maintain torque levels. Failure to follow these instructions can result in death, serious injury, or equipment damage. 				
	When stopping the motor, the drive will apply D by parameter $F = 2 S D$.	C injection braking once the output frequency dro	ps below the level set		
F 2 5 1	[DC braking current] DC braking current	level 0 to 100%	50% (1)		
	NOTICE				
	RISK OF DAMAGE TO THE MOTOR Check that the motor will withstand this current without overheating. Failure to follow this instruction can result in equipment damage.				
	Parameter <i>F</i> 2 5 <i>I</i> sets the level of current applied to the motor during DC injection braking. The displayed value, percent or amperes, is set by parameter [Unit value selection] (<i>F</i> 7 <i>D I</i>) (see page <u>130</u>). During DC injection braking, the drive's overload protection sensitivity increases. The drive automatically lowers the applied DC current to avoid an overload detected fault.				
F 2 5 2	[DC braking time]	0.0 to 20.0 s	1.0 s		
	NOTICE				
	 RISK OF DAMAGE TO THE MOTOR Long periods of DC injection braking can cause overheating and damage the motor. Protect the motor by avoiding long periods of DC injection braking. Failure to follow this instruction can result in equipment damage. 				
	Parameter <i>F 2</i> 5 2 determines how long DC injection braking is applied to the motor.				

(1) Percentage of the drive's rated current or ampere range. This will vary according to drive power rating.

I/O Control Parameters

8

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Logic Inputs Functions	100
Logic Input Function Compatibility	107
Relay Output Functions	108
Analog Input Functions	114
Analog Output Functions	115
Analog Input Adjustments	116
Active Logic Function	122
Preset Speeds	123
+/- Speed Control Parameters	124
Damper control	127

Logic Inputs Functions See table on page <u>101</u> for a complete list of F, R and RES logic inputs assignments

Code	Name / Description		Adjustment range	Factory setting	
FIII	[LI F selection] F Logic Input Function		0 to 73	2	
	The setting of parameter	F / / / determines the control function of logic input termin	al F.	1	
F I 12	[LI R selection]	R Logic Input Function	0 to 73	6	
	The setting of parameter	F / / Z determines the control function of logic input termin	al R.	1	
FIIJ	[LI RES selection]	RES Logic Input Function	0 to 73	10	
	If [Driving Scroll] (F324) pa	age <u>160</u> is set to [yes] (1) the setting is replaced by [Inverse	Run permis.] (54).	+	
	The setting of parameter	F / / J determines the control function of logic input termin	al RES.		
F 109	[VIA selection]	VIA Input Function (Analog or Logic Selection)	-	0	
	UNINTENDED EQUIPMENT OPERATION				
	Prevent accidental grounding of logic inputs configured for sink logic. Accidental grounding can result in unin-				
	tended activation of drive functions. Protect the signal conductors against damage that could result in unintentional conductor grounding				
	Failure to follow these instructions will result in death or serious injury.				
0	[Al]: Analog input				
1	[LI sink]: Logic input - sink (negative logic)				
E	[Li source]. Logic input -				
	The setting of parameter F $I \square 9$ determines whether control input terminal VIA will serve as an analog input (0-10 Vdc or 0–20 mA) or as a logic input (either sink or source).				
	When configuring VIA as a	a logic input, be certain to slide switch SW100 on the main o	control board to the V (voltage) position.	
	When configuring VIA as a logic input using sink (negative) logic, be certain to connect a 4.7 k Ω (1/2 W) resistor between control terminals P24 and VIA.				
	For more information on the	ne use of control input terminal VIA, see ATV212 Installation	n manual.	1	
FIIB	[VIA LI selection]	VIA Logic Input Function	0 to 73	7	
	Set first parameter [VIA se	election] $(F \mid D \mid B)$ before setting parameter $F \mid B$. The security terminal V(A)	tting of parameter F 1	I B determines the	
	See page <u>101</u> for a complete list of VIA logic input assignments.				

Function		Action			
No.	Description				
0	[No assigned] No function assigned	Logic input disabled			
1	[Run permissive] (see also input function 54, page <u>105</u>)	OFF: drive motor output disabled, motor coasts to stop ON: drive ready for operation If [Logic Funct 2 active] (<i>F</i> / / []) is not set to / [Run permissive], a logic input should be assigned to the [Run permissive] logic function to enable the motor to start.			
2	[Forward]	Mode Logic Input Action			
	(2-wire control: input function 49 NOT used)	2-wire control	OFF: Motor ram ON: Motor runs	ps down to a stor forward	0
	or (3-wire control: input	Mode	Stop Input State	Logic Input A	ction
	function 49 USED)	3-wire control	OFF	OFF: no function	on n
		3-wire control	ON	OFF to ON tran forward	nsition starts the drive, motor runs
3	[Reverse]	Mode	Logic Input Act	tion	
	(2-wire control: input func- tion 49 NOT used)	2-wire control	OFF: Motor ram ON: Motor runs	ps down to a stop reverse	0
	or (3-wire control: input	Mode	Stop Input State	Logic Input A	ction
	function 49 USED)	3-wire control	OFF	OFF: no function	on n
		3-wire control	ON	OFF to ON tran	nsition starts the drive, motor runs
5	[Acc / Dec]	OFF: Acceleration/ ON: Acceleration/d	deceleration patte	rn 1 n 2	
6	[PS1]	Input 3	Input 2	Input 1	Motor Speed
	Preset speed command input 1	0	0	0	minimum speed or speed refer- ence per [Frequency mode sel] (F \[\[D] d])
		0	0	1	5 - I: preset speed 1
7	[PS2]	0	1	0	5 - 2: preset speed 2
	Preset speed command	0	1	1	5 - 3: preset speed 3
	input 2	1	0	0	5 r 4: preset speed 4
8	[PS3]	1	0	1	5 - 5: preset speed 5
	Preset speed command	1	1	0	5 - 6: preset speed 6
	input 5	1	1	1	5 r 7: preset speed 7
10	[Fault reset] (see also input function 55, page <u>105</u>)	A DANGER UNINTENDED EQUIPMENT OPERATION This configuration enables to reset the drive. Check this action will not endanger per- sonnel or equipment in any way Failure to follow these instructions will result in death or serious injury. ON to OFF transition clears a detected fault (if cause of detected fault has been cleared			
11	[Ext Fault] (see also input function 45, page 104)	OFF: No external detected fault ON: Motor stops according to method set by parameter [Ext. fault stop Mode] (F & D 3) Embedded display terminal displays E detected fault, detected fault relay activated			

Logic inputs F, R, RES, and VIA (if parameter [VIA selection] ($F I \square \square$) is set to 1 or 2) can be set to the functions described in the table below. See table on page <u>107</u> for logic input function compatibility.
Fun	ction	Action
No.	Description	
13	[DC braking]	Image: Constraint of the second state of the second sta
		Level and time set by parameters [DC braking current] ($F \ge 5$ /) and [DC braking time] ($F \ge 5$ 2)
14	[PID disable]	 OFF: PID control permitted ON: PID control prohibited PID control prohibited input terminal function is available to switch PID control and open-loop control. Also Clear PID integral value input terminal function (function 65) is available. Note: For software version lower than V1.7IE04, when Clear PID integral value (function 65) and PID Control Prohibited (function 14) are used, it is necessary to set [Command mode sel] (<i>C</i> ∩ D d) to [Logic inputs] (<i>D</i>) Control terminal logic inputs.
15	[Param Edit] Functional only when pa- rameter [Parameter lock] (F 7 0 0) = 1	OFF: Parameters locked (if parameter <i>F</i> 7 0 0 = 1) ON: Programming changes permitted
16	[Run reset]	OFF: drive motor output disabled, motor coasts to stop ON: drive ready for operation ON to OFF transition clears a detected fault (if cause of detected fault has cleared)
20	[FW-RMP2] Combination of forward run command and accel- eration/deceleration pat- tern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs forward, ramping up per ACC/dEC pattern 2
21	[Rev- RMP2] Combination of reverse run command and accel- eration/deceleration pat- tern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs in reverse, ramping up per ACC/dEC pattern 2
22	[FW, PS1] Combination of forward run command and preset speed 1 command	OFF: Motor ramps down to a stop ON: Motor runs forward, at speed set by 5 r /, preset speed 1
23	[RV, PS1] Combination of reverse run command and preset speed 1 command	OFF: Motor ramps down to a stop ON: Motor runs in reverse, at speed set by 5 r 1, preset speed 1
24	[FW, PS2] Combination of forward run command and preset speed 2 command	OFF: Motor ramps down to a stop ON: Motor runs forward, at speed set by 5 r 2, preset speed 2
25	[RV, PS2] Combination of reverse run command and preset speed 2 command	OFF: Motor ramps down to a stop ON: Motor runs in reverse, at speed set by 5 r 2, preset speed 2
26	[FW, PS3] Combination of forward run command and preset speed 3 command	OFF: Motor ramps down to a stop ON: Motor runs forward, at speed set by 5 r 3, preset speed 3

Fun	ction	Action				
No.	Description					
27	[RV, PS3] Combination of reverse run command and preset speed 3 command	OFF: Motor ramps down to a stop ON: Motor runs in reverse, at speed set by 5 r 3, preset speed 3				
30	[FW-RMP2-SP1] Combination of forward run command, preset speed 1 command, and acceleration/deceleration pattern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs forward, at speed set by 5 r /, preset speed 1, ramping up per ACC/dEC pattern 2				
31	[Rev-RMP2-SP1] Combination of reverse run command, preset speed 1 command, and acceleration/deceleration pattern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs in reverse, at speed set by 5 c /, preset speed 1, ramping up per ACC/dEC pattern 2				
32	[FW-RMP2-SP2] Combination of forward run command, preset speed 2 command, and acceleration/deceleration pattern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs forward, at speed set by 5 r 2, preset speed 2, ramping up per ACC/dEC pattern 2				
33	[Rev-RMP2-SP2] Combination of reverse run command, preset speed 2 command, and acceleration/deceleration pattern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs in reverse, at speed set by 5 c 2, preset speed 2, ramping up per ACC/dEC pattern 2				
34	[FW-RMP2-SP3] Combination of forward run command, preset speed 3 command, and acceleration/deceleration pattern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs forward, at speed set by 5 r 3, preset speed 3, ramping up per ACC/dEC pattern 2				
35	[Rev-RMP2-SP3] Combination of reverse run command, preset speed 3 command, and acceleration/deceleration pattern 2 selection	OFF: Motor stops, ramping down per ACC/dEC pattern 2 ON: Motor runs in reverse, at speed set by 5 c 3, preset speed 3, ramping up per ACC/dEC pattern 2				
38	[Frequency source] Frequency reference source switching	OFF: drive follows speed reference set by parameter [Frequency mode sel] ($F \sqcap \square d$) ON: drive follows speed reference set by parameter [Remote spd ref 2] ($F \supseteq \square 1$) > (if [Auto/man speed ref] ($F \supseteq \square \square$) = 1)				
39	[Motor switch]	NOTICE RISK OF DAMAGE TO THE MOTOR • The motor switching function disables motor thermal protection. • The use of external overload protection is required when using motor switching. Failure to follow these instructions can result in death, serious injury, or equipment damage. OFF: 1 st motor V/Hz parameter set active: (Motor cont. mode sel.] (<i>P</i> ±), [Motor rated freq.] (<i>u</i> ⊥), [Motor rated voltage] (<i>u</i> ⊥ <i>u</i>), [Mot Voltage Boost] (<i>u</i> b), [Motor thermal prot.] (<i>E</i> H r)) ON: 2 nd motor V/Hz parameter set active: (P ± = 0, F 17 D, F 17 1, F 17 2, F 17 3)				

Fun	ction	Action			
No.	Description				
40	[Mot param. switch] Motor control parameter switching V/Hz, current limit, acceleration/decel- eration pattern	NOTICE RISK OF DAMAGE TO THE MOTOR • The parameter switching function disables motor thermal protection. • The use of external overload protection is required when using motor switching. Failure to follow these instructions can result in death, serious injury, or equipment damage.			
		OFF: 1 st motor control parameter set active: ([Mot cont. mode sel.] ($P \perp$), [Motor rated freq.] ($\perp \perp$), [Motor rated voltage] ($\perp \perp \perp$), [Motor Voltage Boost] ($\perp \perp$), [Motor thermal prot.] ($\perp \parallel r$), [Acceleration time 1] ($R \perp \perp$), [Deceleration time 1] ($a \perp \perp$), [Acc/dec 1 pattern] ($F \leq \square a$), [Motor Current Limit] ($F \leq \square a$))) ON: 2 nd motor control parameter set active: ($P \perp = 0, F \perp \square \square, F \leq \square \square, F \leq \square \square, F \leq \square \square$)			
41	[(+) speed]	OFF: No motor speed increase ON: Motor accelerates			
42	[(-) speed]	OFF: No motor speed reduction ON: Motor decelerates			
43	[+/- clear]	OFF to ON transition clears frequency level set by +/- speed inputs			
44	[+/- SPD, FLT CLR]	OFF to ON transition clears frequency level set by +/- speed inputs ON to OFF transition clears a detected fault (if cause of detected fault has been cleared)			
45	[Inv Ext. fault] Inversion of external de- tected fault signal (see also input function 11, page <u>101</u>)	OFF: Motor stops according to method set by parameter [Ext. fault stop Mode] (<i>F</i> 6 0 3) Embedded display terminal displays <i>E</i> detected fault ON: No external detected fault			
46	[Ext. Th fault] External overheating in- put (see also input func- tion 47)	OFF: No external overheating ON: Motor stops, embedded display terminal displays D H 2			
47	[Inv Ext. Th fault] Inversion of external over- heating input (see also in- put function 46)	OFF: Motor stops, embedded display terminal displays D H 2 ON: No external overheating			
48	[Forced local]	OFF: No forced local function ON: Control of the drive is forced to mode set by [Frequency mode sel] (<i>F</i> \[\[\[\] \] \], [Com- mand mode sel] (<i>L</i> \[\[\] \] \], and [Remote spd ref 2] (<i>F</i> \[\] \[\] \]).			
49	[3-wire]	OFF: Motor ramps down to a stop ON: drive ready for operation			
51	[Reset kWh] Clear accumulated power consumption kWh display	OFF: No function ON: Clears kWh memory			
52	[Forced mode]	A DANGERLOSS OF PERSONNEL AND EQUIPMENT PROTECTIONWhen F 5 5 0 is set to 1 or 2 and a logic input set to function "52" is activated, all the drive controller protection will be disable.• Logic input should not be enable on function 52 for typical applications• Logic input should be enable on function 52 only in extraordinary situations where a thorough risk analysis demonstrates that the presence of adjustable speed drive protection poses a greater risk than personnel injury or equipment damage. Failure to follow these instructions will result in death or serious injury.This function enables the "Forced fire" mode. In this mode, all the detected fault will be ignored or if it is a hardware trip, the drive will be reset to try to restart.OFF: No function ON: Motor runs at speed set by F 2 9 4 Note: F 6 5 0, F 6 5 9 and F 2 9 4 must be configured to activate this function.			

Fun	ction	Action						
No.	Description							
53	[Fire mode]	This function enables the "Fire" mode OFF: No function ON: Motor runs at speed set by <i>F 2 9 4</i> Note: <i>F 6 5 0</i> , <i>F 6 5 9</i> and <i>F 2 9 4</i> must be configured to activate this function.						
54	[Inverse Run permis.] Inversion of run permis- sive (see also input func- tion 1 page <u>101</u>)	OFF: drive ready for operation ON: drive motor output disabled, motor coasts to stop This mode allows to have a freewheel stop using a terminal command.						
55	[Inv fault reset] Inversion of clear detect- ed fault (see also input function 10 page <u>101</u>)	CADANGER UNINTENDED EQUIPMENT OPERATION This configuration enables to reset the drive. Check this action will not endanger per- sonnel or equipment in any way Failure to follow these instructions will result in death or serious injury. OFF to ON transition clears a detected fault (if cause of detected fault has been cleared)						
56	[Run, FW] Combination of run per- missive and run forward command (2-wire control only)	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs forward						
57	[Run, RV] Combination of run per- missive and run reverse command (2-wire control only)	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs reverse						
61	[I limit 1/2] Current limit level selec- tion	OFF: Current limit level 1 [Motor Current Limit] (<i>F</i> 5 0 1) selected ON: Current limit level 2 [Mot. 2 current limit] (<i>F</i> 185) selected						
62	[RY on] Holding of RYA-RYC relay output	OFF: Normal real-time relay operation ON: RYA-RYC is held on once activated						
64	[Cancel HMI cmd] Cancellation of last graphic display option command	OFF: Last graphic display option command cancelled ON: Last graphic display option command retained						
65	[PID integral] Clear PID integral value	OFF: No action ON: PID integral value held at zero						
66	[Run-fw-sp1] Combination of run per- missive, run forward com- mand, and preset speed 1 command	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs forward at speed set by 5 r /, preset speed 1						
67	[Run-rev-sp1] Combination of run per- missive, run reverse com- mand, and preset speed 1 command	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs reverse at speed set by 5 r 1, preset speed 1						
68	[Run-fw-sp2] Combination of run per- missive, run forward com- mand, and preset speed 2 command	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs forward at speed set by 5 r 2, preset speed 2						
69	[Run-rev-sp2] Combination of run per- missive, run reverse com- mand, and preset speed 2 command	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs reverse at speed set by $5 r 2$, preset speed 2						

Fun	ction	Action
No.	Description	
70	[Run-fw-sp4] Combination of run per- missive, run forward com- mand, and preset speed 4 command	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs forward at speed set by $5 r 4$, preset speed 4
71	[Run-rev-sp4] Combination of run per- missive, run reverse com- mand, and preset speed 4 command	OFF: drive motor output disabled, motor coasts to stop ON: Motor runs reverse at speed set by $5 r 4$, preset speed 4
72	[PID rev] PID error signal reversed	OFF: if $F \mid I \mid = 72$ and F terminal is OFF, PI error input = reference - feedback ON: if $F \mid I \mid = 72$ and F terminal is ON, PI error input = feedback - reference
73	[Damper feedBack]	OFF: if $F \mid I \mid$ or $F \mid I \stackrel{?}{_{_{_{_{_{_{}}}}}}}$ or $F \mid I \stackrel{?}{_{_{_{_{}}}}}$ is not set to 73 the damper has no effect. ON: if $F \mid I \mid$ or $F \mid I \stackrel{?}{_{_{_{_{}}}}}$ or $F \mid I \stackrel{?}{_{_{_{_{}}}}}$ = 73 the damper is ON. The damper feedback has not effect if not configured to an output.

Logic Input Function Compatibility

- O = Compatible
- X = Incompatible
- + = Compatible under some conditions
- @ = Priority

Function No. / Function		1/54	2	3	5	6-9	10/55	11/45	13	14	15	46/47	48	41-43	49	38	39	40	52/53
1/54	[No assigned] / [Inverse Run permissive]		@	@	@	@	0	0	@	0	0	0	0	0	@	0	0	0	х
2	[Forward]	+		х	0	0	0	х	х	0	0	х	0	0	Х	0	0	0	х
3	[Reverse]	+	+		0	0	0	х	Х	0	0	х	0	0	Х	0	0	0	х
5	[Acc / Dec]	+	0	0		0	0	х	Х	0	0	х	0	0	0	0	0	Х	0
6~8	[PS1]~[PS3]	+	0	0	0		0	х	Х	0	0	х	0	0	0	0	0	0	х
10/55	[Fault reset] / [Inv fault reset]	0	0	0	0	0		х	0	0	0	х	0	0	0	0	0	0	х
11/45	[Ext. fault] / [Inv. Ext. fault]	+	@	@	@	@	@		@	0	0	+	0	@	@	0	0	0	х
13	[DC braking]	+	@	@	@	@	0	х		@	0	х	0	@	@	0	0	0	х
14	[PID disable]	0	0	0	0	0	0	х	Х		0	х	0	0	0	0	0	0	х
15	[Param Edit]	0	0	0	0	0	0	0	0	0		0	0	0	0	0	0	0	0
46/47	[Ext. Th fault] / [Inv Ext. Th fault]	@	@	@	@	@	@	+	@	0	0		0	0	@	0	0	0	х
48	[Forced local]	0	0	0	0	0	0	0	0	0	0	0		0	0	0	0	0	х
41-43	[(+) speed] [(-) speed] [+/- clear]	0	0	0	0	0	0	0	0	0	0	0	0		0	0	0	0	х
49	[3-wire]	+	@	@	0	0	0	х	х	0	0	х	0	0		0	0	0	х
38	[Frequency source]	0	0	0	0	0	0	0	0	0	0	0	0	0	0		0	0	х
39	[Motor switch]	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0		Х	0
40	[Mot param. switch]	0	0	0	@	0	0	0	0	0	0	0	0	0	0	0	@		0
52/53	[Forced mode] / [Fire mode]	@	@	@	0	@	@	@	@	@	0	@	@	@	@	@	0	0	

The following logic input functions are active, regardless of the [Frequency mode sel] (*F* \sqcap \square *d*) and [Command mode sel] (*L* \sqcap \square *d*) setting.

- (1) Run permissive
- (10) Clear detected fault
- (11) External detected fault

When determining function compatibility using the table above, the function listed horizontally is activated first and the function listed vertically is activated second.

Relay Output Functions

The two relay outputs (FL and RYA-RYC) can be set to the functions described in the table below.

Func	tion No. / Description	Action					
0	[Low speed reach] Low speed reached	OFF: output frequency is low speed setting [Low limit frequency] (L L) ON: output frequency is > low speed setting L L					
1	[Inv low spd reach] Inversion of low speed reached	OFF: output frequency is > low speed setting [Low limit frequency] ($L L$) ON: output frequency is low speed setting $L L$					
2	[High speed reach] High speed reached	OFF: output frequency is < high speed setting [Upper limit freq] ($U L$) ON: output frequency is high speed setting $U L$					
3	[Inv Hi spd reach] Inversion of high speed reached	OFF: output frequency is high speed setting [Upper limit freq] (UL) ON: output frequency is < high speed setting UL					
4	[F100 speed reach] F 0 0 speed reached (See page <u>125</u> for more details on parameter F 0 0)	OFF: output frequency is < [Freq. 1 reached] ($F \mid \square \square$) speed setting ON: output frequency is $F \mid \square \square$ speed setting					
5	[Inv F100 sp reach] Inversion of F I 🛛 🖓 speed reached	OFF: output frequency is [Freq. 1 reached] (F D D) speed setting ON: output frequency is < F D D speed setting					
6	[Speed reach] Commended speed reached	OFF: output frequency is commanded speed +/- [Freq.2 bandw.] ($F \mid \square 2$) hysteresis band ON: output frequency is > commanded speed +/- $F \mid \square 2$ hysteresis band					
7	[Inv speed reach] Inversion of commanded speed reached	OFF: output frequency is > commanded speed +/- [Freq.2 bandw.] (F] 2) hysteresis band ON: output frequency is commanded speed +/- F] 2 hysteresis band					
8	[F101 speed reach] F 0 speed reached (See page <u>125</u> for more details on parameters F 0 and F 0 2.)	OFF: output frequency is [Freq. 2 reached] (<i>F</i> / <i>D</i> /) speed +/- [Freq.2 bandw.] (<i>F</i> / <i>D</i> 2) hysteresis band ON: output frequency is > <i>F</i> / <i>D</i> / speed +/- <i>F</i> / <i>D</i> 2 hysteresis band					
9	[Inv F101 sp reach] Inversion of <i>F</i> / D / speed reached	OFF: output frequency is > [Freq. 2 reached] ($F \mid D \mid$) speed +/- [Freq.2 bandw.] ($F \mid D \mid D$) hysteresis band ON: output frequency is $F \mid D \mid$ speed +/- $F \mid D \mid D$ hysteresis band					
10	[Drive fault] Fault relay. The drive is not in a fault state during auto fault reset attempts. See also function 36 page <u>112</u> .	OFF: No drive detected fault ON: drive detected fault WARNING					
		 LOSS OF CONTROL When F 130, F 132, F 137 is set to 10, the output will be active when the drive will detect a fault. The drive status will not be detected if the wiring is damaged for any reason. Do not select 10 unless you are sure that your signal will be present in any case. Failure to follow these instructions can result in death, serious injury, or equipment damage. 					
11	[No drive fault] Inversion of Drive fault function.	OFF: drive detected fault ON: No drive detected fault					
12	[Overload flt] Overtorque fault Overtorque fault detection is active only if parameter $F = 15 = 1$. See page <u>143</u> for more detail on an overtorque detected fault and parameters $F = 15$ and $F = 18$.)	OFF: Estimated motor torque has NOT been at [Overtorque level] ($F \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$					
13	[Inv overload flt] Inversion of Overload flt function	OFF: Estimated motor torque has been at [Overtorque level] ($F \ E \ I \ E$) level for a time period longer than that set by [Ovtorque det time] ($F \ E \ I \ B$). drive stopped, displaying $\square \ E$ ON: Estimated motor torque has NOT been at $F \ E \ I \ E$ level for a time period longer than that set by $F \ E \ I \ B$					

Fund	tion No. / Description	Action
14	[Drive running] Run relay	OFF: drive is not powering the motor ON: drive is powering the motor, accelerating, decelerating, at constant speed, or DC braking
15	[Drive no run] Inversion of Drive no run function	OFF: drive is powering the motor, accelerating, decelerating, at constant speed, or DC braking ON: drive is not powering the motor
16	[Motor overload] Motor overload alarm detection is only active if parameter $\Box L \Pi$ is set to either 0, 1, 4, or 5. See page <u>146</u> for more detail on motor overload protection settings.	OFF: motor thermal state is < 50% of motor overload detected fault level ON: motor thermal state is 50% of motor overload detected fault level
17	[Inv mot. overload] Inversion of Motor overload function	OFF: motor thermal state is 50% of motor overload detected fault level ON: motor thermal state is < 50% of motor overload detected fault level
20	[Torque alarm] Overtorque alarm detection is active only if parameter $F \ge 15 = 0$. See page <u>143</u> for more detail on the over- torque alarm and parameters [Over- torque level] ($F \ge 15$), [Overtorque band] ($F \ge 19$).	OFF: Estimated motor torque is < 70% of <i>F E I E</i> level minus <i>F E I g</i> hysteresis band ON: Estimated motor torque is 70% of <i>F E I E</i> level
21	[Inv torque alarm] Inversion of Torque alarm function	OFF: Estimated motor torque is 70% of [Overtorque level] ($F \ge I \ge$) level ON: Estimated motor torque is < 70% of $F \ge I \ge$ level minus [Overtorque band] ($F \ge I =$) hysteresis band
22	[Gen. alarm] General alarm	 OFF: No detected fault condition from the sources listed below exists ON: A detected fault has been issued by one of the following sources: Overtorque detected fault (output functions 12 and 13) Motor overload (output functions 16 and 17) Overtorque detected fault (output functions 20 and 21) Load detection loss (output functions 24 and 25) Run time (output functions 42 and 43) Undervoltage (output functions 54 and 55) drive in sleep mode (see for more detail on parameter F 2 5 5) Power loss (see for more detail on parameter F 3 0 2) Overcurrent – motor current limit level (parameter F 5 0 1) Overvoltage – DC bus voltage overvoltage stall level (parameter F 5 2 5) Drive overheating
23	[Inv gen. alarm] Inversion of General alarm function [Underload detect.] (See page <u>141</u> for more detail on pa- rameters $F = D = -F = T = T$ and the underload function.)	 OFF: A detected fault has been issued by one of the following sources: Overtorque detected fault (output functions 12 and 13) Motor overload (output functions 16 and 17) Overtorque detection loss (output functions 20 and 21) Failure of load detection (output functions 24 and 25) Run time (output functions 42 and 43) Undervoltage (output functions 54 and 55) Drive in sleep mode (see for more detail on parameter <i>F</i> 2 5 6) Power loss (see for more detail on parameter <i>F</i> 3 0 2) Overcurrent – motor current limit level (parameter <i>F</i> 6 0 1) Overvoltage – DC bus voltage overvoltage stall level (parameter <i>F</i> 5 2 6) drive overheating ON: No alarm condition from the sources listed above exists
25	[Inv underl. det.] Inversion of Underload detect. func- tion	OFF: Motor current is less than $F \vdash I$ level for the time set by $F \vdash I \supseteq$ ON: Motor current is greater than $F \vdash I$ level + $F \vdash \Box \supseteq$ hysteresis band

Fund	ction No. / Description	Action
26	[Manu reset fit.] Non-autoresettable detected fault	OFF: None of the detected fault conditions listed below existON: One (or more) of the following detected fault conditions exists and hasstopped the drive:• $E - external detected fault• E - IB - VIA analog input signal detected fault• E - IB - VIA analog input signal detected fault• E - IB - VIA analog input signal detected fault• E - IB - VIA analog input signal detected fault• E - IB - VIA analog input signal detected fault• E - IB - VIA analog input signal detected fault• E - 2D - excessive torque boost• E - 2D - excessive torque fault CPU detected fault 1• E F - 2 - main control board RAM• E r r I - amain control board CPU detected fault 1• E r r J - emain control board CPU detected fault 1• E r r J - main control board RAM• E r r J - main control board CPU detected fault 1• E r r J - main control board CPU detected fault 1• E r r J - amain control board CPU detected fault 1• E r r J - excessil communication network• E r r J - auto-tunin$
27	[Inv manu reset flt.] Inversion of Manu reset flt. function	 OFF: One (or more) of the following fault conditions exists and has stopped the drive: <i>E</i> - external detected fault <i>E</i> - 18 - VIA analog input signal <i>E</i> - 19 - main control board CPU communication <i>E</i> - 20 - excessive torque boost <i>E</i> - 21 - main control board CPU detected fault 2 <i>E E P</i> 1 - main control board EEPROM detected fault 1 <i>E E P</i> 2 - main control board EEPROM detected fault 2 <i>E E P</i> 3 - main control board EEPROM detected fault 1 <i>E F</i> 2 - ground fault <i>E P H</i> 0 - output phase loss detection <i>E r r</i> 1 - speed reference <i>E r r</i> 2 - main control board CPU detected fault 1 <i>E r r</i> 3 - main control board RAM <i>E r r</i> 4 - main control board CPU detected fault 1 <i>E r r</i> 5 - serial communication control <i>E r r</i> 7 - motor current sensor <i>E r r</i> 8 - serial communication network <i>E r r</i> 9 - graphic display option communication interruption <i>E L</i> 9 P - drive ratings 0 <i>C R</i> - short-circuit detected in drive output wiring during motor startup 0 <i>L L</i> - short-circuit detected in motor or output wiring during motor startup 0 <i>L L</i> - subort-directing <

Fund	tion No. / Description	Action					
28	[Auto-reset fault] Auto-clear detected fault Note: Relay activates when maximum number of autoclear set by [Number auto reset] ($F \exists \Box \exists$) page <u>135</u> is reached.	 OFF: None of the detected fault conditions listed below exist ON: One (or more) of the following detected fault conditions exists: F d I – damper detected fault 1 (closed damper) F d Z – damper detected fault 2 (opened damper) D [I – overcurrent during acceleration D [Z – overcurrent during deceleration D [J – Short circuit or ground detected fault during acceleration D [Z P – Short circuit or ground detected fault during deceleration D [Z P – Short circuit or ground detected fault during deceleration D [Z P – Short circuit or ground detected fault during deceleration D [Z P – Short circuit or ground detected fault during constant speed D [Z P – Short circuit or ground detected fault during constant speed D [J P – Short circuit or ground detected fault during constant speed D [Z P – Short circuit or ground detected fault during constant speed D [Z P – Short circuit or ground detected fault during constant speed D [Z P – Short circuit or ground detected fault during constant speed 					
29	[Inv auto-reset fit] Inversion of Auto-reset fault function Note: Relay deactivates when maximum number of autoclear set by [Number auto reset] (<i>F</i> = D =) page <u>135</u> is reached.	 OFF: One (or more) of the following detected fault conditions exists: F d I - damper detected fault 1 (closed damper) F d Z - damper detected fault 2 (opened damper) D [I - overcurrent during acceleration D [Z - overcurrent during deceleration D [J - overcurrent during constant speed D [I - Short circuit or ground detected fault during acceleration D [Z P - Short circuit or ground detected fault during deceleration D [Z P - Short circuit or ground detected fault during deceleration D [Z P - Short circuit or ground detected fault during constant speed D [Z P - Short circuit or ground detected fault during constant speed D [Z P - Short circuit or ground detected fault during constant speed D [Z P - Short circuit or ground detected fault during constant speed D [Z P - Short circuit or ground detected fault during constant speed D [Z P - Short circuit or ground detected fault during constant speed O [P - drive overheating D L P - drive overload D P Z - overvoltage during acceleration D P Z - overvoltage during constant speed ON: None of the detected fault conditions listed above exist 					
30	[Drive rdy 1] drive ready condition 1	OFF: drive not ready for operation ON: drive ready for operation (ready includes active run permissive and ac- tive run command)					
31	[Inv drive rdy 1] Inversion of Drive rdy 1 function	OFF: drive ready for operation (ready includes active run permissive and active run command) ON: drive not ready for operation					
32	[Drive rdy 2] drive ready condition 2	OFF: drive not ready for operation ON: drive ready for operation (ready does not include active run permissive or active run command)					
33	[Inv drive rdy 2] Inversion of Drive rdy 2 function	OFF: drive ready for operation (ready does not include active run permis- sive or active run command) ON: drive not ready for operation					
34	[VIB ref source] VIB input reference source	OFF: analog input terminal VIB is NOT the active speed reference source ON: VIB is the active speed reference source					
35	[Inv VIB ref source] Inversion of VIB ref source function	OFF: analog input terminal VIB is the active speed reference source ON: VIB is NOT the active speed reference source					

Fund	tion No. / Description	Action					
36	[Fault relay] (The drive is not in a fault state during auto clear detected fault attempts. See also function 10 page <u>108</u>)	 LOSS OF CONTROL When F 13D, F 132, F 137 is set to 36, the output will be active when the drive will detect a fault. The drive status will not be detected if the wiring is damaged for any reason. Do not select 36 unless you are sure that your signal will be present in any case. Failure to follow these instructions can result in death, serious injury, or equipment damage. 					
		OFF: No drive detected fault ON: drive detected fault. Relay activates when a clearable fault occurs and the drive attempts to re- start. Relay deactivates when drive is restarting.					
37	[Inv fault relay] Inversion of Fault relay function 36	OFF: drive detected fault ON: No drive detected fault Relay deactivates when a clearable fault occurs and the drive attempts to restart. Relay activates when drive is restarting.					
38	[Ser. data relay FL] Serial communication data	OFF: Serial communication word $F R 5 D$ bit 0 = 0 ON: Serial communication word $F R 5 D$ bit 0 = 1					
39	[Inv ser. dat rel. FL] Inversion of ser. dat rel. FL function	OFF: Serial communication word $F = 5$ bit 0 = 1 ON: Serial communication word $F = 5$ bit 0 = 0					
40	[Ser. data relay RY] Serial communication data	OFF: Serial communication word $F R 5 D$ bit 1 = 0 ON: Serial communication word $F R 5 D$ bit 1 = 1					
41	[Inv ser. dat rel RY] Inversion of ser. dat rel. RY function	OFF: Serial communication word $F R 5 D$ bit 1 = 1 ON: Serial communication word $F R 5 D$ bit 1 = 0					
42	[Drive run time al] Drive operational run time alarm (see page 130 for more detail on parameter F $E = 2$ 1).	OFF: Run time is $< F \vdash 2 \mid$ time setting ON: Run time is $F \vdash 2 \mid$ time setting					
43	[Inv.drive run time al] Inversion of Drive run time al function	OFF: Run time is <i>F E 2 I</i> time setting ON: Run time is <i>< F E 2 I</i> time setting					
44	[Drive serv. alarm] Drive service alarm (see page <u>144</u> for more detail on parameter F Б Э Ч).	OFF: drive maintenance detected fault not active ON: drive maintenance detected fault active					
45	[Inv. drive serv. alarm] Inversion of Drive serv. alarm function	OFF: drive maintenance detected fault active ON: drive maintenance detected fault not active					
48	[LI F state] Logic input F state	OFF: Logic input F is not active ON: Logic input F is active					
49	[Inv. LI F state] Inversion of LI F state function	OFF: Logic input F is active ON: Logic input F is not active					
50	[LI R state] Logic input R state	OFF: Logic input R is not active ON: Logic input R is active					
51	[Inv. LI R state] Inversion of LI R state function	OFF: Logic input R is active ON: Logic input R is not active					
52	[Speed ref = VIA] Drive speed reference equals VIA sig- nal	OFF: Speed reference from the source identified by [Frequency mode sel] ($F \sqcap \square d$) or the source identified by [Remote spd ref 2] ($F \supseteq \square 7$) \neq VIA signal ON: Speed reference from the source identified by $F \sqcap \square d$ or the source identified by $F \supseteq \square 7$ = VIA signal					
53	[Inv. speed ref = VIA] Inversion of Speed ref = VIA function	OFF: Speed reference from the source identified by [Frequency mode sel] ($F \sqcap \square d$) or the source identified by [Remote spd ref 2] ($F \supseteq \square 7$) = VIA signal ON: Speed reference from the source identified by $F \sqcap \square d$ or the source identified by $F \supseteq \square 7 \neq$ VIA signal					

Fund	tion No. / Description	Action
54	[Undervolt. alarm] Undervoltage alarm	OFF: Undervoltage detected fault is not active ON: Undervoltage detected fault is active
55	[Inv. undervolt. alarm] Inversion of Un- dervolt. al. function	OFF: Undervoltage detected fault is active ON: Undervoltage detected fault is not active
56	[Loc / remote] Local/remote switching	OFF: drive is in remote mode ON: drive is in local mode
57	[Inv. loc / remote] Inversion of Loc / re- mote function	OFF: drive is in local mode ON: drive is in remote mode
58	[PTC alarm] PTC thermal alarm	OFF: Motor temperature as indicated by PTC thermal probes is < 60% of the detected fault level ON: Motor temperature as indicated by PTC thermal probes is 60% of the detected fault level
59	[Inv. PTC alarm] Inversion of PTC alarm function	OFF: Motor temperature as indicated by PTC thermal probes is 60% of the detected fault level ON: Motor temperature as indicated by PTC thermal probes is < 60% of the detected fault level
60	[Speed ref = VIB] Drive speed reference equals VIB sig- nal	OFF: Speed reference from the source identified by [Frequency mode sel] ($F \sqcap \square \dashv$) or the source identified [Remote spd ref 2] ($F \nvDash \square \square$) \neq VIB signal ON: Speed reference from source identified by $F \sqcap \square \dashv$ or the source iden- tified $F \nvDash \square \square \dashv$ = VIB signal
61	[Inv. speed ref = VIB] Inversion of Speed ref = VIB function	OFF: Speed reference from source identified by [Frequency mode sel] ($F \sqcap \square d$) or the source identified [Remote spd ref2] ($F \supseteq \square 7$) = VIB signal ON: Speed reference from the source identified by $F \sqcap \square d$ or the source identified $F \supseteq \square 7 \neq$ VIB signal
62	[VIA detection] Analog VIA detection	ON: The value of VIA is equal to or higher than $F \mid E \mid D + F \mid E \mid I$ OFF: The value of VIA is equal to or lower than $F \mid E \mid D - F \mid E \mid I$
63	[Inv. VIA detection] Inversion of VIA detection function	ON: The value of VIA is equal to or lower than F I 6 0 - F I 6 I OFF: The value of VIA is equal to or higher than F I 6 0 + F I 6 I
64	[VIB detection] Analog VIB detection	ON: The value of VIB is equal to or higher than $F \mid E \mid 2 + F \mid E \mid 3$ OFF: The value of VIB is equal to or lower than $F \mid E \mid 2 - F \mid E \mid 3$
65	[Inv. VIB detection] Inversion of VIB detection function	ON: The value of VIB is equal to or lower than $F \mid E \mid 2 \mid -F \mid E \mid 3$ OFF: The value of VIB is equal to or higher than $F \mid E \mid 2 \mid +F \mid E \mid 3$
66	[Freq. reach hyst] Set frequency attainment signal with hysteresis	ON: The ouptput frequency is equal to or higher than $F \mid \square \mid + F \mid \square \mid 2$ OFF: The ouptput frequency is equal to or lower than $F \mid \square \mid - F \mid \square \mid 2$ (See page <u>125</u> for more detail on parameters $F \mid \square \mid$ and $F \mid \square \mid 2$.)
67	[Inv. freq. reach hyst] Inversion of Freq. reach hyst function	ON: The ouptput frequency is equal to or lower than $F \mid \Box \mid -F \mid \Box \mid 2$ OFF: The ouptput frequency is equal to or higher than $F \mid \Box \mid +F \mid \Box \mid 2$ (See page <u>125</u> for more detail on parameters $F \mid \Box \mid$ and $F \mid \Box \mid 2$.)
68	[Damper] Damper control	ON: The damper is ON. OFF: The damper is OFF (see page <u>127</u>)
69	[Inv. damper] Inversion of Damper function	ON: The damper is OFF. OFF: The damper is ON (see page <u>127</u>)
70	[DisOil Inj PL] Disable oil injection in high speed positive logic	Positive logic
71	[DisOil Inj NL] Disable oil injection in high speed negative logic	Negative logic
254	[Relay OFF] Relay output is OFF	OFF
255	[Relay ON] Relay output is ON	ON

Analog Input Functions

Two analog inputs are supplied with the ATV212 drive. The terminals are designated VIA and VIB.

Analog Input VIA

- VIA can accept the following signal types:
 - Voltage (V): 0–10 V, voltage or potentiometer input
 - Current (I): 0-20 mA or 4-20 mA
 - The signal type (V or I) is selected by setting SW100 on the main control board.
 - For information on wiring, consult the ATV212 Installation manual.
- The slope and bias of the input signal are adjusted with parameters F 2 D I F 2 D 4 and F 4 7 D F 4 7 I. For more information, see page <u>116</u>.
- VIA is configured as the speed reference input in the following macro-configurations:
 - Run permissive
 - 3-wire
 - 4-20 mA.
- Relay output functions 34 and 35 can signal when VIA is being used as the speed reference source. For more
 information, see table on page <u>111</u> and consult "I/O Control Parameters" on page <u>100</u>.
- Relay output functions 52 and 53 can be used to signal the results of a comparison between the signal at VIA and the speed reference commanded by [Frequency mode sel] (F □ □ d) or [Remote spd ref 2] (F 2 □ 7). This function can also be used to send out a signal indicating whether the amount of processing and the amount of feedback agree with each other. For more information, see table on page 108. Also, consult "I/O Control Parameters" on page 100 and review information about parameter F 15 7 on page 126.
- The drive can enter a detected fault state if the VIA signal drops below a specified level for more than 300 mS. For more information, see parameter F 5 3 3 on page <u>141</u> and code E IB on page <u>180</u>.
- VIA can serve as an analog or a logic input, depending on setting of parameter *F I* <u>D</u> g (set to 0 for analog input). Analog input is the factory setting. See page <u>100</u> for more information about parameter *F I* <u>D</u> g.

Analog Input VIB

- VIB can accept the following signal types:
- Voltage (V): 0–10V, voltage or potentiometer input
- PTC motor thermal sensor input. For more information, see parameters F 6 4 5 and F 6 4 6 on page 122.
- Adjust the slope and bias of the input signal with parameters *F 2 I D F 2 I 3* and *F 4 7 2 F 4 7 3*. For more information, see page <u>116</u>.
- Relay output functions 52 and 53 can signal when VIA is being used as the speed reference source. For more
 information, see table on page <u>112</u> and consult "I/O Control Parameters" on page <u>100</u>.
- Relay output functions 60 and 61 can be used to signal the results of a comparison between the signal at VIB and the speed reference commanded by [Frequency mode sel] (F Π □ d) or [Remote spd ref 2] (F 2 □ 7). This function can also be used to send out a signal indicating whether the amount of processing and the amount of feedback agree with each other. For more information, see table on page <u>108</u>. Also, consult "I/O Control Parameters" on page <u>100</u> and review information about parameter F 16 7 on page <u>126</u>.

General

- The selection of VIA or VIB as the speed reference input in remote mode is made through parameters [Frequency mode sel] (F □ □ d) and [Remote spd ref 2] (F □ □ 7). F □ □ d is the primary speed reference source, while F □ □ 7 is the secondary source. Switching between the two is determined by the setting of parameter [Auto/man speed ref] F □ □ 0. For more information, see page <u>118</u>.
- Analog output terminal FM can be configured to provide a signal in proportion to the VIA or VIB signal levels. See parameter F II 5 L, selections 13 and 14, on page <u>118</u>.
- When PID control is enabled, VIA or VIB can serve as the setpoint input. Either VIA or VIB needs to be selected as the feedback input. See page <u>120</u> for more information on parameter F <u>3 6 0</u> and PID control.
- Information can be transferred between the serial communication network and the analog inputs via read and write functions *F B 7 D*, *F B 7 I*, and *F B 7 S F B 7 P*. For more information, see pages <u>150</u> to <u>151</u>.

Analog Output Functions

One analog output is supplied with the ATV212 drive. The terminal is designated FM.

FM is a multifunctional programmable analog output supplying an output frequency signal as the factory default.

The FM terminal can output a voltage or current signal.

- When switch SW101 is set to V (voltage), FM outputs a 0–10 Vdc signal at 1 mA.
- When switch SW101 is set to I (current), FM outputs a 0–20 mA signal up to 24 Vdc. For detail on proper wiring, consult the ATV212 Installation manual.

The drive value represented by the FM analog output signal is determined by the setting of parameter [AO funct. selection] ($F \Pi 5 L$) (see page <u>118</u>).

Calibrating the FM signal output to provide full scale deflection on an analog meter is achieved by adjusting parameter [AO scaling] ($F \Pi$) (see page <u>118</u>).

The slope and bias of the FM analog output signal can be adjusted using parameters F = 5 and F = 5. For more information, see page <u>119</u>.

Analog Input Adjustments

Analog Input Speed Reference and Output Frequency

Do not set the same frequency values for both output frequency levels 1 and 2. This will cause an E - r I detected fault.

When using a 4–20 mA signal, set speed reference level 1 value to 20% (4 ÷ 20 = 20%).



A further refinement of the bias and slope of the analog input signals can be made with parameters $F \neq 7D - F \neq 7B$.

Code	Name / Description		Adjustment range	Factory setting
F 2 O I	[VIA ref point 1]	VIA speed reference level 1	0 to 100%	0%
F 2 O 2	[VIA freq. point 1]	VIA output frequency level 1	0.0 to 200.0 Hz	0.0 Hz
F 2 O 3	[VIA ref point 2]	VIA speed reference level 2	0 to 100%	100%
F 2 0 4	[VIA freq. point 2]	VIA output frequency level 2	0.0 to 200.0 Hz	50.0 Hz
F 160	[VIA rel thresh. logic]	Threshold logic for relay link to VIA	0 to 100%	0%
			1	
F 16 I	[VIA threshold hyst.]	Hysteresis threshold for logic relay link to VIA	0 to 20%	3%
			1	
F 2 1 0	[VIB ref. point 1]	VIB speed reference level 1	0 to 100%	0%
F 2	[VIB freq. point 1]	VIB output frequency level 1	0.0 to 200.0 Hz	0.0 Hz
			1	
F 2 2	[VIB ref. point 2]	VIB speed reference level 2	0 to 100%	100%
			1	
F 2 3	[VIB freq. point 2]	VIB output frequency level 2	0.0 to 200.0 Hz	50.0 Hz
F 162	[VIB rel thresh. logic]	Threshold logic for relay link to VIB	0 to 100%	0%
			1	
F 163	[VIB threshold hyst.]	Hysteresis threshold for logic relay link to VIB	0 to 20%	3%

Code	Name / Description		Adjustment range	Factory setting		
F 4 7 D	[VIA bias]	VIA analog input bias	0 to 255	128		
	A DANGER UNINTENDED EQUIPMENT OPERATION If the input bias level is set too high, the drive will start the motor without a signal present at VIA or VIB. Failure to follow these instructions will result in death or serious injury.					
			T]		
FYTI	[VIA gain]	VIA analog input gain	0 to 255	148		
F 4 7 2	[VIB bias]	VIB analog input bias	0 to 255	128		
	UNINTENDED EQUIPMEN If the input bias level is set f Failure to follow these ins	T OPERATION too high, the drive will start the motor without a signal pre- tructions will result in death or serious injury.	sent at VIA or VIB.			
FYJJ	[VIB gain]	VIB analog input gain	0 to 255	148		



Parameters [VIA bias] (F 4 7 D) and [VIB bias] (F 4 7 D) are factory set so that a minimal signal needs to be applied to VIA or VIB before the drive starts the motor.

- To increase the signal level required to start the motor, decrease the input bias level.
- To reduce the signal level required to start the motor, increase the input bias level.

UNINTENDED EQUIPMENT OPERATION

If the input bias level is set too high, the drive will start the motor without a signal present at VIA or VIB. Failure to follow these instructions will result in death or serious injury.

Parameters [VIA gain] (F 4 7 1) and [VIB gain] (F 4 7 3) are factory set so that the drive output reaches rated voltage and frequency just before the signal to VIA or VIB reaches its maximum level.

- To decrease the signal level required before the drive output reaches rated voltage and frequency, increase the input gain level.
- To increase the signal level required before the drive output reaches rated voltage and frequency, decrease the input gain level.

Note: If the input gain level is set too low, the drive output may never reach rated voltage and frequency.

Code	Name / Description				Factory setting			
F 2 D D	[Auto/ma	n speed ref]	Auto/Manual Speed Refer	ence Switching	0			
D I	[Enable] [Disable] Switching b To use this When the a $(F \square \square d)$ (s When the a $(F \square \square 1)$ (s When param Below 1 Hz	etween two speed r function, you need ssigned logic input i see page <u>87</u>). ssigned logic input see page <u>88</u>). meter $F \ge D \square$ is se , it will follow the F	reference sources by means to assign a logic input to fur is off, the drive will follow the is on, the drive will follow th t to 1, the drive will follow th $2 \ \square \ 7$ speed reference sour	 rence sources by means of a logic input is enabled if parameter <i>F 2 0 0</i> is set to 0. issign a logic input to function 38, Auto/Man speed ref. if, the drive will follow the speed reference source defined by parameter [Frequency mode sel] n, the drive will follow the speed reference source defined by parameter [Remote spd ref 2] 1, the drive will follow the <i>F ∩ 0 d</i> speed reference source when it is operating above 1 Hz. 7 speed reference source. 				
FΠSL	[AO func	t. selection]	Analog Output Function Se	election	0			
	Value		Function	Maximum Signal				
	0	[Motor frequenc	y]: Output frequency	[Max frequency] (F H)				
	1	[Motor current]:	Output current	150 % of [Motor current]				
	2	2 [Speed ref]: Speed reference [Max frequency] (F		[Max frequency] (F H)				
	Э	[DC bus U]: DC	bus voltage	150 % of [DC bus U]				
	Ч	[Motor U]: Outpu	ut motor voltage	150 % of [Motor U]	U]			
	5	[Input power]: Ir	nput power	185 % of [Input power]	t power]			
	6	[Output power]:	Output power	185 % of [Output power]	ower]			
	7	[motor torque]:	Estimated motor torque	250 % of rated motor torque	% of rated motor torque			
	B	[Torque I]: Moto	r torque current	Current at 250 % of rated motor torque				
	9	[Motor thermal]:	: Motor thermal state	100 % of motor's rating				
	10	[Drive thermal]:	drive thermal state	100 %				
	11	[Do not use]: DO	D NOT USE	-				
	12	[Internal referen reference (after	ce] : Internal speed PID)	[Max frequency] (F H)				
	I 3	[VIA]: VIA input	value	Maximum input value				
	14	[VIB]: VIB input	value	Maximum input value				
	15	[Fixed 100%] : Fi (Selection 1 – or	xed output – 100% signal utput current)	-				
	16	[Fixed 50%]: Fix (Selection 1 – or	ed output – 50% signal utput current)	-				
	٦١	[Fixed 100%]: Fi (Selections 0, 2, 8, 9,10, 12, 13,	xed output – 100% signal , 3, 4, 5, 6, 7, 14, 18)	-				
	18	[Com data]: Ser	ial communication data	FRS I = 1000				
	19	[Do not use]: DO	O NOT USE	-				
FП	[AO scali	ng]	Analog Output Scaling		-			
	Parameter ing the slop As you adju the ENT ke adjustment	$F \Pi$ is used to matc e and bias of the an ist the value of $F \Pi$, y on the drive ember has been saved.	h the FM terminal output sig alog output signal. Before a , monitor the display on the dded display terminal. The c	nal with the input requirements of the djusting $F \Pi$, set [AO funct. selection attached panel meter. When the met trive will flash between $F \Pi$ and the active set of the set	attached pane] (<i>F I</i> I 5 L) to e er display reac djusted value, i	el meter by adjust- ither 15 or 17. hes 100%, press ndicating that the		



Code	Name / Description		Adjustment range	Factory set- ting
F 132	[FL Relay Function]	Function for FL Relay	0 to 69, 254, 255	11
	If [Driving Scroll] (F324) page 1 For a complete description of the	160 is set to [yes] (1) the setting is replaced by [Inv he various functions assignable to the FL relay, se	r F101 sp reach] (9) e page <u>108</u> .	
F 147	[FL Relay delay]	Delay for FL Relay	0.0 to 60.0 s	0.0 s
	This parameter introduce a d	elay on FL output signal relay.		
F360	[PID control enable]		-	0
ם ו 2	[No PID]: PID disabled [PID by VIA]: Enabled (feedba [PID by VIB]: Enabled (feedba Parameter F 3 E D is used to e The PID source is defined by th Parameter [Freq band det rang feedback are in agreement (s	ck source is VIA) ick source is VIB) enable PID control and define the source of the fee ne setting of parameter [Frequency mode sel] (<i>F I</i> ge] (<i>F I 5</i> 7) can be adjusted to command a driv see page <u>126</u>).	edback signal. <mark>2 d</mark>) (see page <u>87</u>). /e relay to signal when the	PID setpoint and
F362	[PID Prop Gain]	PID Proportionnal Gain	0.01 to 100.0%	0.30%
	A higher setting of F 3 5 2 pro diagram below illustrates the e Feedback Amount Fast Response (F 3 5 2 = Large Gain)	vides a fast response to a process error but may a ffect produced by adjusting <i>F</i> 3 5 2 . Motor Spectrum Slow Response (<i>F</i> 3 5 2 =	also result in instability such eed Change Small Gain)	as hunting. The
E 3 E 3	[PID Integral Gain]		0.01 to 100.0	0.20
	Parameter <i>F</i> 3 6 3 adjusts the by the proportional gain are cle A higher setting of <i>F</i> 3 6 3 pro diagram below illustrates the e Feedback Amount	integral gain applied during PID control. Any residence of the applied during PID control. Any residence of the approximate the approximate of th	lual process errors that rem n.	ain after correction
	The integral gain value can be a parameters [LI F selection] (F	(F 3 5 3 = Large Gain) Time Set to zero by setting a logic input to function 65. For 1 1), [LI R selection] (F 1 12), [LI RES selection	Speed Change or more information, see tab n] (<i>F 1 13</i>), page <u>100</u> , and	le on page <u>101</u> and

Code	Name / Description				Adjustment range	Factory set- ting
F366	[PID Derivative Gain]	4			0.00 to 2.55	0.00
	Parameter <i>F</i> 3 <i>b b</i> adjusts the changes in the process. Increasing the setting of <i>F</i> 3 <i>b</i> The diagram below illustrates	derivative gain ap <i>b</i> more than nece the effect produce	oplied during PID co ssary may cause gr d by adjusting F 3	ntrol. This gain a reat fluctuations <u>6 6</u> .	in motor speed resulting i	of the drive to rapid
		T				
	(Current Error			-	
		Previous Error			►	
		Feedback Amount		Motor Spee	d Change	
				Large Derivative	Gain	
				Small Derivat	ive Gain	
F 3 5 9	[PID ctrl wait time]	PID Control Wa	aiting Time		0 to 2400 s	0
	If parameter F 3 5 9 is set to a	a value greater that	an 0 seconds. the c	lrive will not imm	ediately enter PID control) upon startup. For
	the time set by $F = 5 = 9$, the dr This function can be used to h erating level.	ive will ignore the elp prevent the dr	feedback signal, ac ive from entering P	celerating the m ID control mode	otor to the speed set by to before the system appro	he reference input. A ches the final op-
F 3 8 0	[PID reverse error]	PI regulator rev	ersal direction corr	ection		0
0 1	[No] [Yes]					
	This function is used to revers If F 3 B D = 0 or No, PI error in If F 3 B D = 1 or Yes, PI error	e the error PI for V nput = reference - input = feedback ·	Water Pump. feedback. The mol - reference. The mo	tor speed increa	ses when the error is pos ases when the error is p	sitive. ositive.
F 2 5 6	[Time limit low spd]				0.0 to 600 s	0.0 s
D I	[Disable]: (0.0) [Enable]: (0.01 to 600 second If parameter <i>F</i> 2 5 6 is enable period equal to the setting of <i>F</i> the drive embedded display te	s) ed and if the drive ² 2 5 6 , the drive v rminal.	operates continuou will ramp the motor	isly at [Low limit to a stop. While	frequency] (<i>L L</i>) (see path the motor is stopped, " <i>L</i>	nge <u>92</u>) for a time <u>5 <i>L P</i>" will flash on</u>
	When the speed reference to t speed reference.	he drive exceeds	the low speed level	LL+F391,t	he drive will accelerate th	e motor to the new
	If parameter <i>F</i> 2 5 6 is enable ing of the motor. See diagram	d, drive operation below.	at or below the low	speed level is al	so monitored during start	up or during revers-
	Outpur freque	t ncy (Hz)				
	LL+F391 LL Run Comma	r256	F 2 5 5	F 2 5 5	ON OFF	Time (s)

Code	Name / Description		Adjustment range	Factory set- ting
F 3 9 1	[Stop on LL hyst]	Stop on LL hysteresis	0.0 to [Max frequency] (F H)	0.2 Hz
	Activated if [Time limit low spd	(256) is not set to [Disable] ((2))		
F 3 9 2	[PID wake up (thres)]	PI wake up threshold on PI error	0.0 to [Max frequency] (F H)	0.0 Hz
	UNINTENDED EQUIPMENT Check that unintended restar	OPERATION ts will not endanger personnel or equipment in any w	/ay.	
	Activated if [Time limit low spd	(256) is not set to [Disable] (D)		
F 3 9 3	[PID wake up, feedb]	PI wake up threshold on PI feedback error	0.0 to [Max frequency] (F H)	0.0 Hz
	UNINTENDED EQUIPMENT Check that unintended restar Failure to follow these instr	OPERATION ts will not endanger personnel or equipment in any vertices will result in death or serious injury.	vay.	
	Activated if [Time limit low spo	I) (2'5'b) is not set to [Disable] (U)		0
2 2 2	[Disabled] [Enabled fault] (detected fault display an [PTC overheating] [Enabled alarm] (alarm mode tected fault and continue oper Setting parameter <i>F</i> <u>6</u> 4 <u>5</u> to lation manual, for wiring detail	t mode). If $F = 5 + 5$ is set to 1 and the PTC probe exc ($D + 2$) code. (D	- eeds a given, threshold, the a given, threshold, the drive thermal probe input. See t	o e drive will trip and e will signal a de- he ATV212 Instal-
F 6 4 6	[PTC resistor value]		100 to 9999 Ω	3000 Ω

Active Logic Function

Two logic input functions can be configured to be active. The logic input functions assigned to parameters [Logic Funct 1 active] ($F \mid D \mid B$) and [Logic Funct 2 active] ($F \mid I \mid D$) will continuously affect drive operation. See table beginning on page 101 for a list of available logic input functions.

Code	Name / Description	Adjustment range	Factory setting
F 108	[Logic Funct 1 active] Active Logic Function 1	0 to 73	0
F D	[Logic Funct 2 active] Active Logic Function 2	0 to 73	1

If *F* / / D is not set to 1 (logic function [Run permissive]), a logic input should be assigned to the [Run permissive] logic function to enable the motor to start.

Preset Speeds

A maximum of seven preset speeds can be selected by 4 logic inputs (F, R, RES, or VIA). Preset speed control is only active when the drive is in logic input control ([Command mode sel] (CMOd) = 0).

For one preset speed, assign a logic input to function 6.

For up to three preset speeds, use two logic inputs for functions 6 and 7.

For up to seven preset speeds, use three logic inputs for functions 6, 7, and 8.

Preset speed commands take priority over speed commands from any other source. For more information on preset speeds, see page <u>101</u>. See page <u>46</u>, for wiring instructions and timing diagram.

Code	Name / Description	Adjustment range	Factory setting
5r 1	[Preset speed 1]	LL to UL Hz	15 Hz
5 r 2	[Preset speed 2]	LL to UL Hz	20 Hz
5 r 3	[Preset speed 3]	LL to UL Hz	25 Hz
5 r 4	[Preset speed 4]	LL to UL Hz	30 Hz
5 r 5	[Preset speed 5]	LL to UL Hz	35 Hz
5 r 6	[Preset speed 6]	LL to UL Hz	40 Hz
5 r 7	[Preset speed 7]	LL to UL Hz	45 Hz

+/- Speed Control Parameters

+/- speed (motorized potentiometer) control is selected by setting parameter [Frequency mode sel] (F $\sqcap \square d$) or [Remote spd ref 2] (F $\supseteq \square$ 7) to 5 (see pages <u>87</u> and <u>88</u>). Two logic inputs are required, one to increase the speed command (logic input function 41) and one to decrease the speed command (logic input function 42). Logic input function 43 clears the speed reference value accumulated by the +/- speed logic inputs.

Parameters F 2 6 4 - F 2 6 9 refine the operation of +/- speed control.

The ratio of parameter *F 2 6 5* to parameter *F 2 6 4* determines the (+) speed command slope:

(+) speed command slope = $F \ge 65 / F \ge 64$

The ratio of parameter $F \ge 6$ 7 to parameter $F \ge 6$ 6 determines the (-) speed command slope.

(-) speed command slope = $F \ge 6 \ 7 \ / \ F \ge 6 \ 6$

For more detail, see page <u>104</u>.

Code	Name / Description		Adjustment range	Factory setting
F 2 6 4	[+speed LI resp time]	+Speed Logic Input Response Time	0.0 to 10.0 s	0.1 s
	Parameter F 2 6 4 sets the max (+) speed, limiting the speed incr input active longer than the time	kimum on-time of the logic input assigned to ease, as defined by parameter [+speed freq. s set by parameter F 2 6 4 will allow multiple s	step] (<i>F </i>	eeping the logic and.
F 2 6 S	[+speed freq. step]	+Speed Frequency Steps	0.0 to [Max frequency] (F H) Hz	0.1 Hz
	Parameter F 2 6 5 sets the freq	uency width in Hz of each (+) speed comman	nd step.	
F 2 6 6	[- speed LI resp time]	-Speed Logic Input Response Time]	0.0 to 10.0 s	0.1 s
	Parameter <i>F 2 6 6</i> sets the max (-) speed, limiting the speed decr input active longer than the time command.	kimum on-time of the logic input assigned to rease, as defined by parameter [-speed freq. s set by parameter [+speed freq. step] (F 2 6 9	tep] (<i>F 2</i> <u>6</u> 7), to only one step. Ke 5) will allow multiple step decrease	eeping the logic as of the speed
F 2 6 7	[- speed freq. step]	-Speed Frequency Steps	0.0 to [Max frequency] (F H) Hz	0.1 Hz
	Parameter F 2 6 7 sets the frequency width in Hz of each (-) speed command step.			
F 2 6 8	[Init +/- Speed]	Initial +/- Speed Command	0.0 to [Max frequency] (F H) Hz	0.0 Hz
	Parameter F 2 6 8 sets the +/- s parameter at its default value will	speed command in Hz that is applied to the di Il result in the drive's output frequency starting	rive when it is first powered up. Lea g at 0 Hz every time it is powered u	aving this ıp.
F 2 6 9	[Init +/- Speed memo]	Change of Initial +/- Speed Frequency	-	1
D I	[Disable] [Enable] The setting parameter F 2 6 9 d er is cycled to the drive. If param the drive before power was remo	etermines whether the value of parameter [Ini neter F 2 6 9 is set to 1, parameter F 2 6 8 v oved.	t +/- Speed] (<i>F 2 5 B</i>) will change vill be set to the last speed comma	every time pow- nd received by
FIJT	[RY Relay Function 2]	RYA-RYC Relay Secondary Function	0 to 61, 254, 255	255
	The RYA-RYC relay can be set t [RY Relay Function 1] ($F \mid J \supseteq$) secondary functions that can be	to signal a secondary condition. The primary l (see page <u>119</u>). See table beginning on page assigned to the RYA-RYC relay.	RYA-RYC relay function is set by p 108 for a complete description of t	parameter he primary and
F 139	[RY logic select.]	RYA-RYC Relay Function Logic Selection	-	0
D I	[Function 1 and 2]: [RY Relay F [Function 1 or 2]: F / 3 [] (prim The RYA-RYC relay can be cont Both the primary AND secondary Only one OR the other is met (tru	function 1] $(F \mid \exists \Box)$ (primary) and [RY Relay hary) or $F \mid \exists \neg$ (secondary) figured to energize when either: y conditions are met (true) ($F \mid \exists \Box = 0$), or ue) ($F \mid \exists \Box = 1$)	Function 2] (F I 3 7) (secondary)	



Code	Name / Description	Adjustment range	Factory setting	
F 16 7	[Freq band det range] Frequency bandwidth detection range	0.0 to [Max frequency] (F H) Hz	2.5 Hz	
	Parameter <i>F</i> 1.6.7 determines the bandwidth around the VIA or VIB speed reference (see below) driving relay output functions 52, 53, 60, and 61 (see page <u>112</u>). This function can be used to signal whether the amount of processing and the amount of feedback agree when the PID function is in use.			
	+ <u>F 15</u> 7 - <u>F 15</u> 7	- Time (S)		
	Relay Output Function 52 + 60 OFF Relay Output Function 53 + 61 OFF			
F 6 0 3	[Ext. fault stop Mode] External detected fault stop mode	-	0	
0 2	[Freewheel]: Freewheel stop [Ramp stop] [DC braking]: DC injection braking The setting of parameter $F = D = 3$ determines how the drive will stop if a logic in table on pages <u>101</u> and <u>104</u>).	nput assigned to function 11 or 46 is	s activated (see	
F 6 0 4	[DC brk time ext flt] External Fault DC braking time	0.0 to 20.0 s	1.0 s	
	If parameter [Ext. fault stop Mode] ($F \in D \exists$) is set to 2, parameter $F \in D \forall$ injected into the motor while the external fault logic input is active.	will determine how long DC curi	ent will be	

Damper control

This function applies to the ventilation ducts. The aim is to control the opening of the duct (shutter device called a "damper") when the fan starts up.

Damper opening command

The opening command can be assigned to a relay via the $F \mid \exists \Box$ or $F \mid \exists \exists \Box$ parameters to the function [Damper] 68 or [Inv. damper] 69 page <u>113</u>. The damper is closed automatically when there is no longer an opening command.

Damper opening feedback

Opening is controlled by a bit or a logic input that can be assigned via the $F \mid I \mid$ or $F \mid I \supseteq$ or $F \mid I \supseteq$ or $F \mid I \supseteq$ parameters to the function [Damper feedBack] 73 page <u>106</u>. The corresponding logic input or bit can be configured via the parameter [Damper fdb type] $F \subseteq B \square$.

When there is an inconsistency, the drive goes on a [Damper fault 1] F d I if the damper does not open and on a [Damper fault 2] F d 2 if it does not close.

The parameter [Time open damper] $F \subseteq B$ / can be used to delay tripping on an opening fault when a run command is sent and the parameter [Time close damper] $F \subseteq B \supseteq$ delays the closing fault when a stop command is sent.



Code	Name / Description	Adjustment range	Factory setting	
F 5 8 0	[Damper fdb type]		0	
0 2 3 4	 [No feedback]: No feedback used (Default value) [L1 L set]: Logical input and active at level 0 (shunt). When setting F 5 B 0 to 7, first assign logic inputs. [LH set]: Logical input and active at level 1 (open). When setting F 5 B 0 to 2, first assign logic inputs. [Com. LL set]: Serial link to communication bit selected by [Com channel choice] (F B 0 7) and active at level 0 (shunt). Please refer to communcation manual. [Com. LH set]: Serial link to communication bit selected by F B 0 7 and active at level 1 (open). Please refer to communcation manual. Setting of F 5 B 0 parameter is independent of the type of command mode. The F B 0 7 parameter allows selecting the communication channel used for communication damper feedback 			
F 5 8 1	[Time open Damper]	0.05 s to 300.00 s	60.00	
	Opening fault monitoring time delay. If the damper is not open at the end of the set time, the drive will lock in [Damper fault 1] $F d$ I detected fault mode. The timer is launch after the run command. The time delay needs to be greater than the normal opening time of the damper.			
F 5 8 2	[Time close Damper]	0.05 s to 300.00 s	60.00	
	Closing fault monitoring time delay. If the damper is not close at the end of the set time $F d a$ detected fault mode. The timer is launch when the motor is stopped. The time delay needs to be greater that the normal closing time of the damper	e, the drive will lock in	[Damper fault 2]	
F 5 8 3	[Damper flt behavior]		1	
0 1 2	[No fault] [Freewheel stop] [Ramp stop] The F 5 B 3 parameter allows defining the behavior when [Damper fault 1] (F d I) or	curs.		

Display Parameters

9

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Display parameters	130

Display parameters

Code	Name / Description	Adjustment range	Factory setting	
F 7 I 0	[Displayed param.] Default graphic display option operational value	0 to 10	0	
0 1 2 9 4 5 6 7 8 9 10	[Motor frequency] Motor operating frequency (Hz or custom display), see [Customized freq val] (F 7 0 2) on page 131. [Reference] Speed reference (Hz or custom display), see F 7 0 2 on page 131. [I Mot] Motor current (% or A), see [Unit value selection] (F 7 0 1) below. [Drive rated I] Drive rated current (A) [Drive therm state] (%) [Motor power] Output power (kW) [Int speed ref] Internal speed reference (after PID function) (Hz or custom display, see F 7 0 2 on page 131. [Com data] Serial communication data [Motor speed] Output speed (rpm, see [Motor rated speed] (F 4 1 7) on page 74) [Com count] Displays the total number of frames received by the communication card since the last power ON The setting of parameter [Displayed param.] (F 7 10) determines the default display on the drive's embedded display terminal upon power up. Status alarms C, P, L, and H can only be displayed on the graphic display option if [Displayed param.] (F 7 10) is set to 0. See "Build on the graphic display option if [Displayed param.] (F 7 10) is set to 0. See			
F 7 D I	[Unit value selection] Unit value selection	-	1	
D I	 [%] [Amp or Volt] The setting of parameter <i>F</i> 70 / determines how certain values will be displayed on the drive embedded display terminal, either as a percentage of the drive rating or as a value of amperes or volts as appropriate. The setting of <i>F</i> 70 / will only affect parameters and display values that can be represented in amperes or volts. This includes the following parameters: [Motor thermal prot.] (<i>E</i> H_F) and <i>F</i> 173: motor rated current <i>F</i> 25 1: DC braking current level <i>F</i> 185 and <i>F</i> 50 1: motor current limit <i>F</i> 5 1 1: underload detection level 			
FIDB	[Display ref. resol.] graphic display option Frequency Resolution	-	0	
0 / to 255	Disabled - 0.1 Hz steps See the formula below Parameter <i>F</i> 7 <i>D B</i> works along with parameter [Loc. speed ref. step] (<i>F</i> 7 <i>D</i> 7) (see page <u>87</u>) to adjust the incremental steps of the drive embedded display terminal frequency display. At its factory setting, parameter <i>F</i> 7 <i>D B</i> is disabled and the embedded display terminal increments or decrements frequency dis- plays in 0.1 Hz steps. If parameter <i>F</i> 7 <i>D B</i> is set to a value other than 0, then the embedded display terminal frequency display is determined as fol-			
	For example, if both $F \uparrow D \uparrow$ and $F \uparrow D B$ are equal to 1, the embedded display termin 1 Hz steps.	nal frequency display v	vill increase only in	
F621	[Run time alarm]	0.0 to 999.9	610.0 (6100 hours)	
	Parameter <i>F</i> <u>6</u> 2 <i>I</i> is used in conjunction with a relay output set to functions 42 or 43 specified by the setting of <i>F</i> <u>6</u> 2 <i>I</i> has accumulated. 0.1 = 1 hour, 100 = 1000 hours	(see page <u>112</u>) to sign	al that the run time	
F 7 4 8	[Power cons. memo] Accumulated power consumption memory	-	1	
D I	[Disable] [Enable] The setting of parameter <i>F</i> 7 4 <i>B</i> determines whether the drive's accumulated power co hours (kWh), is cleared when the line power is cycled. If <i>F</i> 7 4 <i>B</i> is set to 0, the memory is retained.	onsumption memory, d ry is cleared. If set to 1	isplayed in kilowatt- , the kWh memory	

Code	Name / Description	Adjustment range	Factory setting	
F 7 4 9	[Power cons. unit]	-	According to drive rating (1)	
ם ב פ	[1 kWh] [0.1 = 1 kWh] [0.01 = 1 kWh] [0.001 = 1 kWh] The setting of parameter F 749 determines the scaling of the kWh display on the en	nbedded display termir	nal.	
F 7 D 2	[Customized freq val] Customized freq val	0.00 to 200.00	0.00	
	Parameters <i>F</i> 102, <i>F</i> 105, and <i>F</i> 706 can be used to customize a speed display on the drive embedded display terminal to match the application's operational speed, for example, feet per minute or units per hour. 0.00: Frequency displayed in Hz 0.0 If parameter <i>F</i> 102 is set to a value other than 0.00, the frequency value displayed will be calculated as follows: Value displayed = display or parameter frequency x <i>F</i> 702. See example below. 1 to 200.0: Conversion factor			
		70 800		
	60.0 Hz 50.0 F102=0.00 Hz 100			
FIDJ	[Frequency convert.] Frequency free unit conversion selection]		0	
	[AII] Frequencies display free unit [PID only] PID frequencies free unit conversion			
F 7 0 5	[Custom freq. slope] Custom Frequency Display Conversion Slope] - 1			
0 	[Negative slope] [Positive slope] Parameter <i>F</i> 7 <u>D</u> <u>5</u> sets the slope of the custom frequency display conversion. See the eration of this function.	e diagrams below for e	examples of the op-	
F 7 0 6	[Customize unit bias] Custom Frequency Display Conversion Bias	0.00 to <i>F H</i> Hz	0.00 Hz	
	Parameter F 706 adds a bias to the custom frequency display conversion process.			
	F 7 0 I=I, F 7 0 6 = 0.00 F 7 0 5 = I, F 7 0 6 = 2 0.00			
	graphic display graphic display option			
	800 1000 F 7 D 2			
	0 Output Frequency 80 (Hz) 200 Output Frequ	ency 80 (Hz)		
	$F 7 \square 5 = \square, F 7 \square 6 = B \square . \square \square$ graphic display option			
	800 FID2			
	0 U Output Frequency 80 (Hz)			

(1) See table page 199.

Detected Fault Management Parameters

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Time delay	136
Catch On The Fly (F301)	137
Overtorque Detection	143
Nuisance Overvoltage And Input Phase Detected Fault Avoidance	144
Motor Overload Characteristics	145

F 4 0 0	[Auto-tuning drive] - 0			
	 During auto-tuning, the motor operates at rated current. Do not service the motor during auto-tuning. Failure to follow these instructions will result in death or serious injury. 			
	A WARNING			
	 LOSS OF CONTROL It is essential that the following parameters <u>u L u</u>, <u>u L</u>, <u>F 4 15</u> and <u>F 4 17</u> are correctly configured before starting autotuning. When one or more of these parameters have been changed after auto-tuning has been performed. <u>E H R R</u> will return R 			
	and the procedure will have to be repeated. Failure to follow these instructions can result in death or serious injury.			
	NOTICE			
	 RISK OF DAMAGE TO THE MOTOR Conduct auto-tuning only after the motor has been connected and operation completely stopped. If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in abnormal tuning. Failure to follow these instructions can result in equipment damage. 			
٥	Auto tuning enable [Disabled]			
1	[Initialize constant]: Factory setting of [Auto Torque Boost] (F 4 D 2) for asynchronous motor. Factory setting of [Auto Torque Boost] (F 4 D 2), [Autotune L q-axis] (F 9 1 2), and [Autotune L q-axis] (F 9 1 3), and [Motor Rated Voltage] (vlv) for synchronous motor.			
e	[Tun Dyn. 1] :Tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), and [Autotune L q-axis] (F 9 13) for synchronous motor.			
E	[Tun Dyn. 2] : Complete tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), [Autotune L q-axis] (F 9 13), and [Motor Rated Voltage] (vlv) for synchronous motor.			
4	4 [Tun Static 1]: Tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 1 2), and [Autotune L q-axis] (F 9 1 3) for synchronous motor.			
5	[Tun Static 2] : Complete tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (<i>F</i> 4 0 2), [Autotune L q-axis] (<i>F</i> 9 12), and [Autotune L q-axis] (<i>F</i> 9 13), and [Motor Rated Voltage] (viv) for synchronous motor.			
	Parameter <i>F</i> 4 0 0 is reset to "0" after the auto tuning is performed.			

Code	Name / Description	Factory setting	
F 3 D 3	[Number auto reset]	0	
	 UNINTENDED EQUIPMENT OPERATION The automatic restart can only be used on machines or installations which do not pose any danger to either personnel or 		
	 equipment. If the automatic restart is activated, the fault relay will only indicate a fault has been detected once the restart sequence has expired. 	ne time-out period for the	
	• The equipment must be used in compliance with national and regional safety regulations Failure to follow these instructions will result in death or serious injury.		
٥	Disabled.		
/ to / 🛙	Number of clear attempts.		

Description

The table below lists the detected faults that can be cleared with Auto clear. If parameter $F \exists D \exists$ is set to a value greater than 0 and one of these detected faults occurs, the drive will attempt to automatically clear the detected fault, allowing it to be restarted:

Fault detection codes that can be cleared with the automatic restart function after the cause has disappeared

Code	Description	Code	Description
EPEF	External Process Threshold error detected	0 H	Drive overheating
5 4 1	Damper detected fault 1 (closed damper)	0 H 2	External overheating
101		OL I	Drive overload
001	Overcurrent during acceleration	<u> </u>	Motor overload
<u> </u>	Overcurrent during deceleration	0 P I	Overvoltage during acceleration
0 C 3	Overcurrent during constant speed	0 P 2	Overvoltage during deceleration
0C IP	Short-circuit or ground detected fault during acceleration	OP 3	Overvoltage during constant state operation
0 C 2 P	Short-circuit or ground detected fault during deceleration	PSrF	Prestart Speed not reached error detected
OC 3P	Short-circuit or ground detected fault during constant speed operation	5 0 U E	Permanent magnet motor step-out

Auto clear attempts will continue until the number of attempts set by parameter *F* 3 0 3 has been exhausted.

If these attempts do not clear the detected fault condition, the drive will stop and a manual clear will be required.

If another type of detected fault occurs during the auto clear process, the drive will stop and a manual clear will be required.

A successful auto clear means that the drive accelerates the motor to the commanded speed without another detected fault occurring.

If an unspecified period of time elapses after a successful auto clear attempt without another detected fault occurring, the reset attempt counter will clear allowing another full set of reset attempts to be made during a future detected fault occurrence.

During the auto clear process, the drive embedded display terminal alternately displays r E r 4 and the display value selected by parameter [Displayed param.] (F 7 1 D), page <u>130</u>.

Conditions permitting auto clear

An auto clear attempt will not be made if the cause of the detected fault persists.

In the case of an DL I or DL 2 overload detected fault, the drive will calculate the cooling time necessary to clear the detected fault.

In the event of an D H detected fault, the heatsink temperature probe will indicate when the detected fault can be cleared.

DC bus voltage measurements will indicate when an DP I, DP 2, or DP 3 detected fault can be cleared.

Time delay

The first clear is attempted 1 second after the detected fault occurs. Each subsequent clear attempt adds 1 second to the time interval, as illustrated in the table below.

Clear detected fault attempts

Attempt number	Time delay between detected fault reset attempt and most recent fault
1	1 second
2	2 seconds
3	3 seconds
4	4 seconds
5	5 seconds
6	6 seconds
7	7 seconds
8	8 seconds
9	9 seconds
10	10 seconds

Fault relay action

An output relay set to functions 10 and 11 (see table on page <u>108</u>) will not indicate a detected fault until all clear attempts have been exhausted.

Output relay functions 28 and 29 can be used to indicate that an auto-resetable detected fault has occurred.

Output relay functions 36 and 37 can be used to signal any kind of drive detected fault, even during auto clear attempts.

Drive fault memory

If parameter [Drive fault memory] ($F \in D 2$) is set to 1 and power to the drive is cycled while an auto-resetable detected fault is active, the auto clear action will be cancelled (see page <u>138</u>).

Catch On The Fly (F 3 0 1)

If catch-on-the-fly motor starting is enabled (parameter $F \exists D I$ is not set to 0), the drive will detect the motor's rotating direction and speed before applying power. This will result in a smooth reapplication of power to a coasting motor without high current or torque pulses.

If $F \ni D$ I is disabled and the drive is started into a spinning motor, it will apply a low starting frequency to the motor, operating in current limit until the motor almost stops. Then, the drive will accelerate the motor to the commanded speed.

Catch-on-the-fly motor starting will be applied if *F* **3 D** *I* is set to 1 or 3 and:

- There is a brief power loss (the embedded display terminal does not go blank) that results in the drive removing power from the motor,
- and, there is a continuous run command to the drive (2-wire control)

F 3 0 / Set to 1 or 3



Catch-on-the-fly motor starting will be applied if *F* **J D** *I* is set to 2 or 3 and:

- The run permissive (logic input assigned to functions 1 or 54) is removed and restored,
- and, there is a continuous run command to the drive (2-wire control)

F 3 0 / Set to 2 or 3



If F 3 D I is set to 4, the drive will perform a motor speed and direction search each time it receives a run command.

Note: Enabling catch-on-the-fly adds about 300 milliseconds to implementation of each start command to the drive.

Do not use catch-on-the-fly if there is more than one motor supplied by the drive.

Code	Name / Description	Factory setting	
F 3 O I	[Catch on fly]	3 (1)	
0 1 2 9 4	[Disable] [Brief power loss] After brief power loss [Run restored] After run permissive is restored [Power loss, run] After brief power loss or run permissive is restored [Each start] During every startup		
F 6 3 2	[Mot overload memo] Motor Overload Memory	0	
0 1	 [Disabled] Cleared If parameter <i>F</i> 6 3 2 is set to 0, the drive's memory of the motor's thermal state (used for overload calculation) is cleared when ever the power is cycled. [Enabled] Retained If parameter <i>F</i> 6 3 2 is set to 1, the drive's memory of the motor's thermal state is retained even when power is removed. If the drive is tripped on an Motor Overload detected fault 0 L 2, a cooling time (as calculated by the drive) needs to expire before the motor can be restarted 		
(1) Catch-on-the-fly motor starting after a drive detected fault is active if auto clear is enabled (parameter [Number auto reset] (F 3 D 3) is not set to 0, see page <u>135</u>)			

S1A53838 11/2014
Code	Name / Description	Factory setting
F 6 0 2	[Drive fault memory]	0
1	[Cleared] If parameter $F \subseteq D \supseteq$ is set to 0 and the drive is powered after a detected fault: If the cause of the detected fault has been removed, the drive will reset and can be started. Inform just cleared will be transferred to the detected fault history. If the cause of the detected fault has not been removed, the detected fault will be displayed again operational information associated with the detected fault will be transferred to the detected fault Information about the 4th most recent detected fault will be removed from the detected fault histor [Retained] If parameter $F \subseteq D \supseteq$ is set to 1 and the drive is powered after a detected fault: If the cause of the detected fault has been removed, the drive will reset and can be started. Inform just cleared will be transferred to the detected fault history. If the cause of the detected fault has not been removed, the original detected fault and all of its op for viewing as the current detected fault in the monitoring mode. Information about the 4th most recent detected fault will be retained in the detected fault history. Auto clear will be disabled.	nation about the detected fault but the drive's memory of the history. ry. nation about the detected fault erational data will be available
F608	[Input phase loss] Input phase loss detection mode	1
	[Disable] : Disabled If parameter <i>F</i> <u>6</u> <u>0</u> <u>8</u> is set to 0, input phase loss detection is disabled. Loss of one input phase w [Enable] : Enabled If parameter <i>F</i> <u>6</u> <u>0</u> <u>8</u> is set to 1, the loss of one input phase will cause an <u>E</u> <u>P</u> <u>H</u> <u>1</u> detected fault.	vill not cause the drive to trip.
F 3 D 2	[Supply loss behav.]	0
0 1 2	[Disabled] If parameter $F \exists D a$ is set to 0 and the drive briefly loses input power, it may not trip but may ins reduction of motor voltage and/or current and then resume normal operation once nominal input p [Do not use]: DO NOT SELECT [Freewheel] If parameter $F \exists D a$ is set to 2 and the drive briefly loses input power, the drive will remove power coast to a stop. The embedded display terminal will flash $5 \models D P$. The drive can only be restarted mand. Input Voltage Motor Speed	tead experience a momentary power is restored. r from the motor and allow it to d by providing a new run com-
F627	[Undervolt detect.] Undervoltage Fault Operation Mode	- 0
0 2	[Alarm (0.6U)]: Alarm only (detection level below 60 %) If parameter $F \subseteq 2$ 7 is set to 0 and the supply voltage drops below 60% of its rated value, the dr tected fault code on the embedded display terminal, but it will not activate a fault relay. If the supplits rated value, the detected fault code on the embedded display terminal will be cleared without a be ready to operate. [Fault (0.6U)]: Fault (detection level below 60 %) If parameter $F \subseteq 2$ 7 is set to 1 and the supply voltage drops below 60% of its rated value, the dr reset action to clear the detected fault before it can be restarted. [Alarm (0.5U)]: Alarm only (detection level below 50 %) If parameter $F \subseteq 2$ 7 is set to 2 and the supply voltage drops below 50% of its rated value, the dr tected fault code on the embedded display terminal, but it will not activate a fault relay. If the supplits rated value, the detected fault code on the embedded display terminal will be cleared without a be ready to operate. [Alarm (0.5U)]: Alarm only (detection level below 50 %) If parameter $F \subseteq 2$ 7 is set to 2 and the supply voltage drops below 50% of its rated value, the dr tected fault code on the embedded display terminal, but it will not activate a fault relay. If the supplits rated value, the detected fault code on the embedded display terminal will be cleared without a be ready to operate.	ive will stop and indicate a de- oly voltage rises above 60% of a clear action and the drive will ive will trip and will require a ive will stop and indicate a de- oly voltage rises above 50% of a clear action and the drive will
	RISK OF DAMAGE TO DRIVE When F 6 2 7 = 2, use a line choke. Failure to follow these instructions can result in death, serious injury, or equipment damage	ge.

F 3 0 S	[Overvoltage fault] Overvoltage protection	-	2	
٥	[Enable] If parameter <i>F</i> 3 D 5 is set to 0, and the drive detects an impending DC b lowing actions: Increase the deceleration time Keep the motor at a steady speed Increase the motor speed	bus overvoltage, it will automatica	Ily take one of the fol-	
	Output Frequency			
	DC Bus Voltage	: Over-Voltage detected fault Operation Lev	ve	
1	[Disabled] If parameter $F = 0.5$ is set to 1, the drive will take no action to avoid a D	C bus overvoltage.		
2	[Quick deceleration]: Enabled (quick deceleration mode) If parameter F 3 0 5 is set to 2, and the drive detects an impending DC I power applied to the motor. Motor over-excitation is used to dissipate rec	ous overvoltage, it will increase th enerative energy into the motor i	ie V/Hz ratio of the nstead of the drive.	
Э	[Dyn. deceleration]: Enabled (dynamic quick deceleration mode) If parameter 5 2 / 5 is set to 3, the drive will increase the V/Hz ratio of the power applied to the motor as soon as slow down			
	begins instead of waiting for the DC bus voltage to approach the detected	d fault level.		
	When motor speed is being reduced, a DC bus overvoltage can often be drive from the load and motor.	caused by regenerated energy b	eing absorbed by the	
F 6 2 6	[Overvoltage level]	100 to 150 % of nominal DC bus voltage	140%	
	Parameter F 6 2 6 sets the DC bus voltage level at which the actions diagram above for more details.	s defined by parameter F 3 0 5	take place. See	

Code	Name / Description	Factory setting						
F 6 0 5	[Output phase loss] Output phase loss detection Mode	3						
	A A DANGER							
	HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH							
	 If F 6 0 5 = 1 or 2, loss of cable is only detected at the startup of the motor 							
	 Check this action will not endanger personnel or equipment in any way Failure to follow these instructions will result in death or serious injury. 							
	Note: If [Mot cont. mode sel.] (Pt) is set to 6 (Permanent Magnet Motor Control Law) and [Output 3, 4 and 5, the output phase loss check is done every time the motor is started.	phase loss] (F605) is set to 1,						
	A A DANGER							
	HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH If [Mot cont, mode sel.] (Pt) is set to 6 (Permanent Magnet Motor Control Law), output phase loss	s monitoring, while the motor						
	is running, is disabled. Phase loss and, by implication, accidental disconnection of cables, are no Verify that this behavior does not result in unsafe conditions and implement alternative monitorin Failure to follow these instructions will result in death or serious injury.	ot detected. ng function if required.						
	If output phase loss detection is enabled and an output phase loss persists for more than 1 secon the <i>E P H D</i> code.	d, the drive will trip and display						
٥	[Disabled]							
1	If parameter <i>F</i> <u>6</u> <u>0</u> <u>5</u> is set to 0, output phase loss detection is disabled.							
	If parameter $F = 0.5$ is set to 1, an output phase loss check is made only during the first motor start-up after power is applied to the drive							
2	[Each start]: At every start-up.							
Е	If parameter F 6 0 5 is set to 2, an output phase loss check is made every time the motor is star [During run]: During operation.	ted.						
	If parameter $F \in D \subseteq S$ is set to 3, continuous output phase loss monitoring is performed while the	motor is running.						
4	[Permanent]: At start-up and during operation, If parameter F <u>5</u> 0 <u>5</u> is set to 4, monitoring for an output phase loss is performed at motor start-up and continuously during op- eration.							
5	[Output contactor]: Load side disconnect mode, Setting 5 for parameter <i>F 6 0</i> 5 is for applications with a load side disconnect. The drive will automatically restart the motor if the following are true:							
	 An all-phase loss has been detected (an output contactor or a load side disconnect has ope The drive detects that a 3-phase connection has been reestablished (the output contactor or closed). It is necessary to wait 1 s between disconnection and connection. See following so loss of output contactor. 	ened) r load side disconnect has heme to have an example of						
	Speed							
	t							
	Ouput contactor t1 t2							
	0 t							
	t1: deceleration without ramp (freewheel) t2: acceleration with ramp							
	- A valid run command exists.							
	An output phase loss detection sweep is made as part of the auto-tuning process, regardless of the High-speed motors and other special motors may cause nuisance output phase losss.	e setting of parameter F 6 0 5.						

Code	Name / Description		Adjustment range	Factory setting
F6 10	[Underload det.]	Underload / alarm selection	-	0
D I	[Alarm] If parameter $F \in I \square$ is set to without the drive faulting. [Fault] If parameter $F \in I \square$ is set to by $F \in I \square$, the drive will trip, 11, see page <u>108</u>). A relay as The drive's response to an u The setting of parameter $F \in$ drive. The sum of parameters $F \in \square$ Parameter $F \in I \square$ determin See parameters $F \in \square \square$, $F \square$	b 0, relay output functions 24 or 25 (see page $\underline{14}$ or 1 and the loading level drops below the setting displaying code $U \subseteq$. The fault relay will be set if ssigned to signal an underloaded condition (function inderload condition is set by parameters $F \subseteq D =$ 6 10 determines whether an underload condition gives how long the drive can be under load before a 5 10, $F \subseteq I I$ and $F \subseteq I Z$ diagram below for n	<u>1</u>) can be used to signal an under of $F = I$ for a period of time lo one has been defined (relay output tions 24 or 25, see page <u>109</u>) wi F = I = I, $F = I = I$, and $F = I = I$. In signals an alarm with an output wel that will clear an underload al- an alarm or detected fault is signa- nore details.	rload condition nger than that set out functions 10 or I also be set. relay or faults the arm/detected fault. aled.
	F 	nly)	ON	
	Low Current			
	Signal Output Output Current (%) F Б I I + F Б [] Я F Б I I –	F 5 12 or Les	s F 6 12	
			Time [Sec]	
F 6	[Underload level]	Underload Detection Level	0 to 100% (1)	0%
	Parameter F 6 / / sets the	e underload detection level.		
F609	[Underload band]	Underload Detection Level Bandwidth	1 to 20% (2)	10%
F 6 1 2	[Underload det. time]	Underload Detection Time	0 to 255 s	0 s
F 6 3 3	[Loss of VIA]	Loss of VIA Analog Signal	0 to 100% (3)	0%
0 to 0 0	[Disabled] Disabled. If parameter <i>F</i> <u>6</u> <u>3</u> <u>3</u> is set to [Fault detection level] If parameter <i>F</i> <u>6</u> <u>3</u> <u>3</u> is set to The signal at VIA drops below and, the low signal level person the drive will trip and the emile (1) Parcentage of the drively	b 0, the drive will not monitor for loss of signal at b a value greater than 0 and: w the detection level selected, sists for 300 milliseconds or longer, bedded display terminal will display the code E -	analog input terminal VIA	

Percentage of the drive's current rating. Display ca [Unit value selection] (F 7 D I) (see page <u>130</u>).
 Percentage of [Underload level] (F E I I) setting.
 Percentage of maximum VIA signal level

Code	Name / Description		Adjustment range	Factory setting
F 6 4 4	[4-20 mA loss]	Drive behavior on 4-20 event	L	0
0	[No]: No			
I.	[Freewheel] Freewheel.			
2	[Set speed] Fallback speed.			
	Switch to fallback speed. Mai	ntained as long as the trip cause is present and	the run command is not disabled	l. See parameter
_	[4-20mA fallback sp] (F E 4 9	 for fallback speed. 		
3	The drive maintains the speed	n. d being applied when the trip occurred as long a	as the trip cause is present and th	e run command is
	not disabled.			
4	[Ramp stop] Ramp stop.			
F 6 4 9	[4-20mA fallback sp]	Fallback speed	0.0 to [Max frequency] (F H)	0.0 Hz
	See parameter [4-20 mA loss](FБЧЧ).		
F6 13	[Short circuit det.]	Output short-circuit detection mode	-	0
0	[Each time (std)]: Each time	a RUN command is given (standard pulse)		
1	[One time (std)]: Only one til	me after power is turned on (standard pulse)		
2	[Each time (short)]: Each tin	ne a RUN command is given (short-time pulse)		
3	[Une time (short)]: Only one	time after power is turned on (short-time pulse)		
	The setting of parameter F 6	1 3 determines how the drive determines an ou	utput short-circuit during start-up.	
	Select the short-time pulse if	the drive is powering a low impedance motor.	· · ·	

Overtorque Detection



Code Name / Description Adjustment range **Factory setting** F6 15 [Overtorque det.] Overtorque detected fault/Alarm Selection 0 ۵ [Alarm] If parameter F 6 3 3 is set to 0, the drive will not monitor for loss of signal at analog input terminal VIA. 1 [Fault] If parameter F 6 15 is set to 1 and the drive faults, the overtorque signal output will remain latched on until the detected fault is cleared Depending on the setting of parameter F 5, the drive can use output relay function 12 or 13 (see table on pages 108) to signal an overtorque alarm or detected fault ([] L code). F6 16 [Overtorque level] **Overtorque Detection Level** 0 to 250 % of nominal 130% rated motor torque The setting of parameter F 6 1 6 determines the level at which the drive will act upon a motor overtorque condition (see diagrams above and below). OFF ON OFF ON Overtorque Pre-Alarm Signal Output F6 16 x 0.7 F6 16×0.7 - F6 19 Output Frequency level 2 Torque Current (%) Time (Sec) Output relay functions 20 or 21 can be used to signal a overtorque pre-alarm when the calculated motor torque reaches 70% of the value set by parameter F 6 16. [OvTorque det time] Overtorque Detection Time F6 18 0.0 to 10 s 0.5 s The setting of parameter F 6 1 B determines how long the drive needs to detect a motor overtorque condition before it signals an alarm or detected fault (see above diagram). F6 19 [Overtorque band] Overtorque Detection Level Bandwidth 0 to 100 % of F 6 16 10% level While the setting of parameter F 6 16 determines the level at which a motor overtorque alarm or detected fault will be signaled, the setting of parameter F 5 / 9 determines how far the calculated motor torque needs to drop before the alarm or detected fault is cleared (see above diagram).

Code	Name / Description	Factory setting
F 6 3 4	[Amb. temp. alarm] Ambient Temperature For drive Service Alarm	3
1	[- 10 to 10 °C]	
2	[11 to 20 °C]	
Э	[21 to 30 °C]	
4	[31 to 40 °C]	
5	[41 to 50 °C]	
6	[51 to 60 °C]	
	The drive can be programmed to signal a service alarm using output relay functions 44 or 45 (se service alarm can be displayed on the embedded display terminal (see page <u>21</u>).	e page <u>112</u>). The status of the
	At initial start-up, set parameter $F = 3 + 4$ to the drive's average ambient operating temperature. S annual temperature or changing the value after drive operation has begun may result in an early	Setting F <u>5</u> 3 4 to the highest drive service alarm.

Nuisance Overvoltage And Input Phase Detected Fault Avoidance

Parameters F 4 B I to F 4 B 3 can be used to avoid nuisance overvoltage and input phase faults caused by:

- High input impedance: line reactor
- Low input impedance: high kVA distribution network
- · Voltage instability: generator power source

If nuisance faults occur, increase the value of parameter $F \lor B \downarrow$. If increasing the value of $F \lor B \downarrow$ over 1000 does not remove nuisance faults, increase the values of parameters $F \lor B \downarrow$ and $F \lor B \downarrow$ as needed.

Code	Name / Description	Adjustment range	Factory setting
F 4 8 I	[In noise comp. filter] Line noise compensation filter	0 to 9999 μs	0 µs
F482	[In noise Inhibit filter] Line noise Inhibitor filter	0 to 9999 μs	442 μs
F483	[In noise inhibit gain] Line noise Inhibitor gain	0 to 300 %	100%
F 4 8 4	[Pwr supply adj. gain] Power supply adjustment gain	0.0 to 2.0 s	0.0

When the using machine has specific resonance, the following phenomena are happened:

- the machine occurs vibration,
- unusual noise of machine or peripheral.

If these phenomena are occurred, the following parameters should be adjusted:

- at first, set [Pwr supply adj. gain] (F 4 B 4) to 0.5,
- next, set F 4 B 4 as another value when no effect by setting F 4 B 4 to 0.5,
- if [Motor rated freq.] ($_{u}$ L) = 50 Hz, set F 4 B I to the following value 531,
- if $\Box L = 60$ Hz, set $F \lor B I$ to the following value 442.

Note: F 4 B 1 and F 4 B 3 are invalid when F 4 B 4 has a value excluding 0.0.

Motor Overload Characteristics

Motor Type

Set $\square \square \square$ to \square , \square , \square , or \exists if a self-cooled motor is being powered by the drive. The diagram below illustrates the overload protection level for the self-cooled motor as a function of motor frequency.

Overload Protection for a Self-Cooled Motor



Set *DL* n to *4*, *5*, *b*, or *7* if a forced-cooled motor is being powered by the drive. The diagram below illustrates the overload protection level for the forced-cooled motor as a function of motor frequency.

Overload Protection for a Forced-Cooled Motor

Output Current Reduction Factor [%] / [A]



Overload Protection

To enable motor overload protection, set **D** L **n** to **D**, **1**, **4**, or **5**.

NOTICE

RISK OF DAMAGE TO THE MOTOR

When $\Box L \Pi$ is set to 2, 3, 6 or 7 motor thermal protection is no longuer provided by the drive. Provide an alternative means of thermal protection.

Failure to follow these instructions can result in equipment damage.

To disable motor overload protection, set $\Box L \sqcap$ to 2, 3, 6, or 7. In this case, a separate overload protective device, external to the ATV212 drive, needs to be wired between the drive and the motor.

Overload Stall

The overload stall function is only compatible with variable torque loads where the load on the motor and drive is dependent on the operating frequency and where the load can be reduced by slowing the motor.

If overload stall is enabled, the drive will reduce its output frequency if it detects an impending overload. As the overload condition of the motor is dissipated, the drive will return its output frequency to the commanded value.

To enable overload stall, set $\Box L \sqcap$ to $I, \exists, 5, \text{ or } 7$.

To disable overload stall, set $\Box \sqcup \Box$ to \Box , 2, 4, or 6.

e	Name / De	escription					Factory setting				
ΟΓΠ	[Motor o	0									
	NOTICE										
	RISK OF When D alternativ Failure t	DAMAGE L n is set to we means of to follow the	TO THE MC 2, 3, 6 o thermal pro ese instruc	DTOR r 7 mot otection. tions c	or thermal protection is n an result in equipment o	o longuer provided by	y the drive. Provide an				
	This - -	This parameter value depends on:the motor type (self cool or forced cooled),and the protection.									
	Matan	Prote	ction								
	type	Overload protection	Overload stall	value	Description	Behavior					
		enabled	disabled	٥	[Std mot. protect.]	In case of overload [Motor thermal prot.] drive trips in D L 2 a	defined by (<i>L H r</i>)parameter, the and the letter <i>L</i> is flashing				
	Self cooled	enabled	enabled	1	[Std & stall mot. prot]	In case of overload [Motor thermal prot.] drive reduces autom follows a fallback sp frequency $_L$) (1). If the overload rei speed, the drive trip is flashing.	defined by (L H r) parameter, the natically the speed and eed (80 % of Motor rated mains during the fallbac s in $\Box L Z$ and the letter of				
		disabled	disabled	2	[Self cool]	-					
		disabled	enabled	Э	[Sif cool stall ov.load]	In case of overload [Motor thermal prot.] drive reduces autom follows a fallback sp frequency <u>u</u> L) (1). The drive will not trip	defined by (L H r) parameter, the hatically the speed and eed (80 % of Motor rated to in $D L 2$.				
		enabled	disabled	ч	[Forced cool prot]	In case of overload [Motor thermal prot.] drive trips in D L 2 a	defined by (<i>L H -</i>)parameter, the and the letter <i>L</i> is flashing				
	Forced cooled	enabled	enabled	5	[Forc cool stall prot]	In case of overload [Motor thermal prot. drive reduces autom follows a fallback sp frequency $_L$) (1). If the overload rei speed, the drive trip is flashing.	defined by (L H r) parameter, the hatically the speed and eed (80 % of Motor rated mains during the fallbac s in $DL = 2$ and the letter				
		disabled	disabled	6	[Forced cool]	-					
		disabled	enabled	7	[F cool & stall ov load]	In case of overload [Motor thermal prot.] drive reduces autom follows a fallback sp frequency ωL) (1). The drive will not trip	defined by (L H r) parameter, the natically the speed and eed (80 % of Motor rated to in $\Box L Z$.				

(1) If the speed is lower than the fallback speed, the drive will keep the same speed.

Serial Communication Parameters

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Network communication between the ATV212 drive and a master controller	148
Data structure parameters	150

Network communication between the ATV212 drive and a master controller

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- · Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link (1).

Failure to follow these instructions can result in death, serious injury, or equipment damage.

(1) For additional information, refer to NEMA ICS 1.1 (latest edition), "Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control" and to NEMA ICS 7.1 (latest edition), "Safety Standards for Construction and Guide for Selection, Installation and Operation of Adjustable-Speed Drive Systems."

Network communication between the ATV212 drive and a master controller is possible through five protocols selectable through the embedded display terminal:

- Modbus[®] RTU
- Metasys[®] N2
- Apogee[®] P1 FLN
- BACnet
- LonWorks[®]

Three types of data exchange are possible:

- Monitoring: monitoring values such as output frequency, voltage, and current
- Programming: reading, editing, and writing drive parameters
- Control: starting and stopping the drive and controlling the frequency reference

For operation on a network containing multiple drives, each ATV212 drive needs to be assigned a unique address using parameter $F B \square 2$.

For operation on a network where all drives are slaves responding to a central control system:

- Parameters [Command mode sel] ([[]]]) (see page 87) and [Frequency mode sel] (F []]) (see page 87) needs to be set correctly:
 - Setting [] d to 2 enables start/stop control of the drive via network communication
 - Setting *F I D d* to 4 enables the frequency reference to be controlled by network communication
 - Setting either [II] d to 2 or F II] d to 4 enables serial communication error detection. The setting of
 - parameter F B 5 I determines the drive's response in case of a loss of communication.

Control of the ATV212 drive can be established by a master controller over a serial communication network regardless of the setting of $[\ \Pi \ \Box \ d]$ or $[\ \Pi \ \Box \ d]$ (see diagram on page 50). Control can be restored to the source defined by $[\ \Pi \ \Box \ d]$ and $[\ \Pi \ \Box \ d]$ if the serial communication network relinquishes control or a logic input assigned to function 48 (forced local) is enabled.

Code	Name / Description		Adjustment range	Factory setting
F800	[Mdb RJ45 baud]	Modbus RJ45 baud rate	-	1
0 1	[9600 bps] [19200 bps]			
F801	[Mdb RJ45 parity]	Modbus RJ45 parity	-	1
0 1 2	[No]: No parity [Even]: Even parity [Odd]: Odd parity			
F802	[Modbus address]		0 to 247	1
	This address is used whatev	er the port used.		

Code	Name / Description	Adjustment range	Factory
F803	[Com. time out]	-	3
	LOSS OF CONTROL • If F B D 3 is set to 0, communication control will be inhibited. • For safety reasons, inhibiting the communication interruption detection should be restricted to applications. Failure to follow these instructions can result in death, serious injury, or equipment dama	the debug phase age.	or to special
0 / to / 0 0	Communication error detection disabled 1 to 100 seconds		
F820	[Mdb network baud] Modbus network baud rate	-	1
0 1	[9600] [19200]		
F821	[Mdb network parity] Modbus network parity	-	1
0 2	[No]: No parity [Even]: Even parity [Odd]: Odd parity		
F829	[Network protocol] Network protocol selection	-	1
2 3 4 5	[Metasys N2] [Apogee P1] [BACnet] [LonWorks] F B 2 9 is enable if F B D 7 is set to 1 previously. Note: On the ATV21. Lonworks configuration corresponded to value /.		
F851	[Com. fault setting] Communication fault setting	-	4
	A WARNING		
	LOSS OF CONTROL If F 8 5 1 is set to 1, communication control will be inhibited. For safety reasons, inhibiting the communication interruption detection should be restricted to th phase or to special application. Failure to follow these instructions can result in death, serious injury, or equipment dama	e debug age.	
	A WARNING		
	LOSS OF CONTROL Know and understand the setting of parameter <i>F</i> B 5 /. This parameter controls the behavior of network communication loss. If the value of <i>F</i> B 5 / is D, I, Z, or B, the drive will not trip on a Failure to follow these instructions can result in death, serious injury, or equipment dama	the drive in the e n בררם . a ge.	event of a
٥	Ramp stp (F/Cmod): Drive ramps to a stop. Serial control is relinquished to the sources defined by and [Command mode sel] (<i>L</i> $\sqcap \square d$). This function is only used with the Lonworks terminal board.	[Frequency mode	e sel] (F П 🛛 d)
 2 3 4	 [No active]: Last commanded operation continues. [Ramp stop]: Drive ramps to a stop. Serial control is maintained. [Freewheel]: Drive removes power from the motor which coasts to a stop. Serial control is maintain [Err5 or Err8]: Drive faults with either a communication detected fault E r r 5 or a network detected 	ned. ed fault <i>E r r B</i> .	
	Note: For Modbus connection, only the function 1 is taken into account. The other function make d	rive trip in Err E	or Err 5.
FBD7	[Com channel choice] Communication channel choice	-	1
	 [RJ45]: command Modbus via RJ45 port. [Open style]: Modbus, BACnet, Apogee P1, Metasys N2 and Lonworks defined by [Network proto F B D 7 can only be adjusted while the drive is stopped. 	col] <i>F B 2 9</i> via op	oen style port.

Data structure parameters

Parameters F = 5 - F = 2 - F = 2 - 2 define the structure of data transmitted between the drive and the data communication network

Code	Name / Description	Factory setting
F856	[Mot. poles (comm.)] Number of motor poles for communication	2
1	[2 poles]	
2	[4 poles]	
Э	[6 poles]	
4	[8 poles]	
5	[10 poles]	
6	[12 poles]	
1	[14 poles]	
FBIU	[Block write data 1]	0
0	[No select]: No selection	
1	[Command word 1]	
2	[Command word 2]	
E	[Frequency Setpoint]	
4	[Relay command]: Ouput data on the terminal board	
5	[FW command]: Analog output for communication	
FBTI	[Block write data 2]	0
0	[No select]: No selection	
1	[Command word 1]	
2	[Command word 2]	
3	[Frequency Setpoint]	
4	[Relay command]: Ouput data on the terminal board	
5	[FM command]: Analog output for communication	
Ь	[Speed Setpoint]	1
F875	[Block read data 1]	0
0	[No select]: No selection	
1	[Status info]	
2	[Freq. out]: Output frequency	
3	[Motor current]: Ouput current	
4	[Ouput volt]: Ouput voltage	
5	[Alarm info]: Alarm information	
6	[PID feedback value]	
/	[Input term, mon]: Input terminal board monitor	
	[Out term, mon]. Output terminal board monitor	
10	[VIB monitor]: VIB terminal board monitor	
11	[Mot speed mon.]: Ouput motor speed monitor	
F 8 7 6	IBlock read data 21	0
	No select: No selection	-
	[No select]. No selection	
, ,	[Freq. out]: Output frequency	
3	[Motor current]: Ouput current	
4	[Ouput volt]: Ouput voltage	
5	[Alarm info]: Alarm information	
6	[PID feedback value]	
7	[Input term. mon]: Input terminal board monitor	
B	[Out term. mon]: Output terminal board monitor	
9	[VIA monitor]: VIA terminal board monitor	
10	[VIB monitor]: VIB terminal board monitor	
11	Liviot speed mon.j : Ouput motor speed monitor	

Code	Name / Description	Factory setting
FBJJ	[Block read data 3]	0
0 2 3 4 5 5 6 7 8 9 10 1	[No select]: No selection [Status info] [Freq. out]: Output frequency [Motor current]: Ouput current [Ouput volt]: Ouput voltage [Alarm info]: Alarm information [PID feedback value] [Input term. mon]: Input terminal board monitor [Out term. mon]: Output terminal board monitor [VIA monitor]: VIA terminal board monitor [VIB monitor]: VIB terminal board monitor [VIB monitor]: VIB terminal board monitor	
F 8 7 8	[Block read data 4]	0
0 2 3 4 5 5 7 8 9 10 1	[No select]: No selection [Status info] [Freq. out]: Output frequency [Motor current]: Ouput current [Ouput volt]: Ouput voltage [Alarm info]: Alarm information [PID feedback value] [Input term. mon]: Input terminal board monitor [Out term. mon]: Output terminal board monitor [VIA monitor]: VIA terminal board monitor [VIB monitor]: VIB terminal board monitor [VIB monitor]: VIB terminal board monitor [Mot speed mon.]: Ouput motor speed monitor	
F879	[Block read data 5]	0
0 2 4 5 6 1 1 1	[No select]: No selection [Status info] [Freq. out]: Output frequency [Motor current]: Ouput current [Ouput volt]: Ouput voltage [Alarm info]: Alarm information [PID feedback value] [Input term. mon]: Input terminal board monitor [Out term. mon]: Output terminal board monitor [VIA monitor]: VIA terminal board monitor [VIB monitor]: VIB terminal board monitor [VIB monitor]: VIB terminal board monitor [Mot speed mon.]: Ouput motor speed monitor	

Code	Name / Description	Adjustment range	Factory setting
F880	[Free ID parameter] Free Notes	0 to 65535	0
	The free notes parameter can be used to set a unique value to identify the drive on a network.		

Parameters F B 9 D - F B 9 E should be adjusted only if the corresponding optional equipment has been installed. See the ATV212 catalog for more detail.

Code	Name / Description
F890	[Network adress]
F891	[Network baud rate]
F 8 9 2	[Network time out]
F 8 9 3	[Instance number H]
F894	[Instance number L]
F895	[Max master]
F896	[Max info frames]

When the value of $F \square 2 \square$ parameter is changed, the adjustment range and factory setting of $F \square \square \square$ to $F \square \square \square$ are automatically setted.

	Mod	lbus	APOGEE	E FLN P1	META	SYS N2	BAC	NET
	Setting Range	Factory setting	Setting Range	Factory setting	Setting Range	Factory set- ting	Setting Range	Factory setting
F829	-	1	3	3	2	2	4	4
F890	0 to 65535	0	1 to 99	99	1 to 255	1	0 to 127	0
F891			0 to 6	0	1 to 5	5	1 to 5	5
F892			20 to 600	100	20 to 600	100	20 to 600	100
F893			0 to 4194	0	0 to 4194	0	0 to 4194	0
F 8 9 4			0 to 999	0	0 to 999	0	0 to 999	0
F895			0 to 127	0	0 to 127	0	0 to 127	127
F896			0 to 100	0	0 to 100	0	1 to 100	1

There are 2 connection port witch support different communication protocol, embedded or using option board. The two channels could communicate simultaneously with the product, but only one could send the logical or frequency command to the drive:

- The two channel used for monitoring
- One channel used for command (run order and speed) and the second for monitoring.

	Description	RJ45 Modbus	Network Modbus	Network Apogee P1	Network Metasys N2	Network BACnet	Network LonWorks
F829	Network selection	-	•	•	•	•	•
F800	Modbus RJ45 Baud rate	•	-	-	-	-	-
F80 I	Modbus RJ45 Parity	•	-	-	-	-	-
F802	Modbus address	•	•	-	-	-	-
F803	Modbus time out	•	•	-	-	-	(1)
F851	Com fault behavior	•	•	•	•	•	•
F820	Modbus Net Baud rate	-	•	-	-	-	-
F821	Modbus Net Parity	-	•	-	-	-	-
F890	Network parameter	-	-	•	•	•	-
F891	Network parameter	-	-	•	-	•	-
F892	Network parameter	-	-	•	•	•	-
F893	Network parameter	-	-	-	-	•	-
F 8 9 4	Network parameter	-	-	-	-	•	-
F895	Network parameter	-	-	-	-	•	-
F896	Network parameter	-	-	-	-	•	-

The configuration parameters of communication are taking account at next power up of the product.

(1) Time out disconnection board, internal default value (3s)

Start/Stop Control By Speed Reference Level

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Overview	154

Overview

Use parameters [Freq. pedestal] (F 2 4 1) and [Freq. pedestal hyst.] (F 2 4 2) to enable start/stop control of the drive based on the speed reference level.



Code	Name / Description		Adjustment range	Factory setting
F 2 4 1	[Freq. pedestal]	Operating starting frequency]	0.0 to [Max frequency] (F H) Hz	0.0 Hz
F 2 4 2	[Freq. pedestal hyst.]	Operating starting frequency hysteresis	0.0 to [Max frequency] (F H) Hz	0.0 Hz

Droop Control

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Droop control principle	156

Droop control principle

The use of droop control (or negative slip compensation) can help balance the load between multiple motors in a load sharing application. The amount of slip or speed droop allowed in the motor powering the load is determined by the load current level and the setting of parameters $F \exists 2 \Box$ and $F \exists 2 \exists$.

During motoring, droop control decreases the drive output frequency. During regenerative braking, droop control increases the drive output frequency.

When enabled, droop control is active when:

- The load current exceeds the level set by parameter F 3 2 3.
- The drive output frequency is between the [Mot start freq.] F 2 4 D (see page 92) and [Max frequency] (F H) (see page <u>92</u>).



The amount of speed droop allowed (f) can be calculated by this equation: $f = \bigcup_{L} L(1) \times F \exists 2 \Box \times (load current - F \exists 2 \exists)(2)$

Example:

⊔ *L* = 60 Hz *F ∃ 2 0* = 10% $F \exists 2 \exists = 30\%$ (of drive's rated current) Load current = 100% of drive's rating $f = 60 \times 0.1 \times (1 - 0.3)$ f = 60 x 0.07

f = 4.2

Assuming the speed reference is set to 60 Hz, the output frequency will be: f1 = f0 - f = 60 - 4.2 = 55.8 (Hz).

Code	Name / Description	Adjustment range	Factory setting
F 3 2 D	[Load gain]	0 to 100%	0%
F 3 2 3	[Load gain offset]	0 to 100% (3)	10%
			+

(1) Parameter [Motor Rated freq] (U L) (see page 74). The value entered for U L in this formula should not exceed 100, regardless of the actual setting of parameter U L.
(2) Speed droop is zero if (load current - F 3 2 3 = 0).

(3) Percent of the drive's rated current.

Functions for Scroll

14

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Driving Scroll (F324)	160
Pre-start Scroll (F325)	170
Std Oiling Cycle (F330)	172
Low Speed Oiling (F334)	173
Scroll Protection (F338)	174
Discharge gas (F349)	175
Crankcase heating (F355)	176

Scroll sub menu ([SCROLL MENU] (5 [r))

ATV212 have 7 specific functions dedicated to the management of a scroll compressor with variable speed operation integrated into an HVAC production system. The main purpose of these functions is to help protect the compressor, the engine, and the system against the risk of mechanical damage inherent to the operating conditions.



- General setting of the motor control of a Scroll compressor:
- [Driving Scroll] (F324) Driving a Scroll Compressor. (See page <u>160</u>)
 When this function is activated, default value of some parameters change (see the table page <u>159</u>).
 This function also allows taking into account the characteristics of the motor for optimum control.
- Scroll Compressor Operating Functions:
- [Pre-start Scroll] (F325) Scroll Compressor Pre-start Management. (See page <u>170</u>)
 On each run order, the variable speed drive ensures that the scroll compressor starts under good conditions.
- [Std Oiling Cycle] (F330) Periodic Oiling Cycle Management. (See page <u>172</u>)
 The variable speed drive manages the lubrication cycle of the Scroll Compressor during normal operation.
- [Low Speed Oiling] (F334) Oiling management for Low Speed Running. (See page <u>173</u>)
 The variable speed drive initiates a cycle of the scroll compressor lubrication after a continuous period of operation below a threshold speed.
- Scroll compressor and refrigerant loop protection functions:
- [Scroll Protection] (F338) Avoid Overloading or Cavitations Effects. (See page <u>174</u>)
 By monitoring thresholds of current and output frequency, the variable speed drive stops the motor in case of overcharging or cavitations.
- [Discharge Gas] (F349) Avoid high temperature or high pressure through sensor input. (See page <u>175</u>) By monitoring an analog threshold (pressure sensor and temperature on the refrigerant circuit), the drive stops the motor.
- [Crankcase Heating] (F355) Keep the system warm after motor sopped. (See page <u>176</u>)
 To avoid internal condensation effects, the variable speed drive maintains the temperature of the compressor by injecting current into the motor. This replaces an external heating system for compressors with built-in motor.

Activation of functions

[Driving Scroll] (F324) must be set to (1) to activate the 7 specific functions. (See below) Example: (F325) [Pre-start Scroll] can be set (0) to (1), if $F \exists 2 4 = (0)$ then $F \exists 2 5$ is deactivated.

Code	Name	Adjustment range	Automatic values
F 3 2 S	[Pre-start Scroll]	0 - 1	0
F 3 3 0	[Std Oiling Cycle]	0 - 1	0
F 3 3 4	[Low Speed Oiling]	0 - 1	0
F 3 3 8	[Scroll Protection]	0 - 1	0
F 3 4 9	[Discharge Gas]	0 - 1	0
F 3 5 5	[Crankcase Heating]	0 - 1	0

Automatic values of parameters

These parameters will be changed automatically when [Driving Scroll] (F324) changes from [No] (0) to (1) [Yes].

Code	Name	Factory setting	Automatic values
FJII	[Motor direction]	1 [FW only]	1 [FW only]
PE	[Mot cont. mode sel.]	1 [Variable Torque]	3 [SVC]
υL	[Motor rated freq.]	50 Hz	50 Hz
F601	[Motor Current Limit]	110 %	110 %
LL	[Low limit frequency]	0.0 Hz	30 Hz
UL	[Upper limit freq]	50 Hz	90 HZ
FH	[Max frequency]	50 Hz	90 Hz
F401	[Slip Compensation]	50 %	0 %
d E C	[Deceleration time 1]	According to drive rating (1)	0.9 s
ACC	[Acceleration time 1]	According to drive rating (1)	0.9 s
F 130	[RY Relay Function 1]	4 [F100 speed reach]	70 [DisOil Inj PL]
F 132	[FL Relay Function]	11 [No drive fault]	9 [Inv F101 sp reach]
F 10 I	[Freq. 2 reached]	0.0 [0.0 Hz]	65 [65 Hz]
F 102	[Freq.2 bandw.]	2.5 [2.5 Hz]	0.65 [0.65 Hz]
FIIJ	[LI RES selection]	10 [Fault reset]	54 [Inverse Run permis.]
F250	[DC brake start freq.]	0 Hz	0 Hz
F251	[DC braking current]	50 %	10 %
F 3 D I	[Catch on fly]	3 [Power loss, run]	0 [Disable]

(1) see table page 199

Note: When (F324) changes from [Yes] (1) to [No] (0), linked parameters values are not changed.

Driving Scroll (F324)

This section will regroup basics parameters to ensure a good control and performance for the [Driving Scroll] (F324).

UNINTENDED EQUIPMENT OPERATION

Enabling Driving Scroll parameter (F324) will modify the setting of some parameters (see page <u>159</u>). All previous setting of these parameters will be lost.

• Modify only these parameters after activation of Driving Scroll parameter (F324).

Failure to follow these instructions will result in death or serious injury.

Code	Name / Description	Adjustment range	Factory setting	
F 3 2 4	[Driving Scroll] Driving a Scroll Compressor	-	0	
0 1	Motor characteristics and control parameters. [No] [Yes] Automatic values of parameters changes when <i>F</i> ∃ 2 4 changes from <i>D</i> to <i>1</i> , see the	table page <u>159</u>		
FJII	[Motor direction]	-	1 [FW only]	
(1)	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by [FW only]. Use parameter $F = I I$ to permit only forward or reverse operation.	(1).		
	[Fw & Rev.] [Fw only]			
e e	[Rev. only]	1	1	
PE	[Mot cont. mode sel.] Motor control mode	-	1	
(1)	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by [SVC] (3)			
0 1 2 3 4 5 6	[Constant V/Hz]: Constant V/Hz [Variable Torque]: Variable torque [Cst V/Hz+Boost]: Constant V/Hz with automatic torque boost [SVC]: Sensorless vector control [Economy]: Energy saving [Do not use]: Reserved [PM Control]: Permanent Magnet Motor Control Law			
	A DANGER HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH If [Mot cont. mode sel.] (Pt) is set to (6) (Permanent Magnet Motor Control Law), output phase loss monitoring, while the motor is running, is disabled. Phase loss and, by implication, accidental disconnection of cables, are not detected. • Verify that this behavior does not result in unsafe conditions and implement alternative monitoring function if required. Failure to follow these instructions will result in death or serious injury.			
υLυ	[Motor Rated Voltage]	According to drive rating (2)	According to drive rating (2)	
	Set parameter $\mu L \mu$ (vLv) to the motor's rated voltage as indicated on the motor nam ATV212eeeM3X: 50330 V. ATV212eeeM4: 50660 V Note: Drive output voltage cannot be set to exceed the input line voltage level.	eplate.		
	(1) When (F324) changes from [No] (0) to [Yes] (1), some of linked parameters are set When (F324) changes from [Yes] (1) to [No] (0), linked parameters value are not ch	to a new value. anged.		

⁽²⁾ See table page 199

υL	[Motor rated freq.]	25400 Hz	50.0 Hz		
(1)	If [Driving Scroll] (F324) page 160 is set to [yes] (1) the setting is replaced by 50.0 Hz.				
	Set parameter μ <i>L</i> (vL) to the motor's rated frequency as indicated on the motor nameplate. Note: It is possible to set the drive's various motor control frequencies to 50 Hz by setting [Parameter reset] (<i>L</i> \mathcal{P}) to 1, the 50 Hz reset. For more information, see page <u>66</u> .				
F 4 15	[Motor rated current]	0.1 to 200.0 A	According to drive rating (2)		
	Set parameter F 4 15 to the motor rated current in amperes as indicated on the motor	or's nameplate.	1		
FYIT	[Motor rated speed]	100.0 to 15000 rpm	According to drive rating (2)		
	Set parameter F 4 1 7 to the motor rated speed in rpm as indicated on the motor's na	meplate.			
F 6 0 I	[Motor Current Limit]	10 to 110% of the drive's output cur- rent rating	110%		
(1)	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 110%.				
	NOTICE				
	 RISK OF DAMAGE TO THE MOTOR AND THE DRIVE Check that the motor will withstand this current. Check that the profile mission complies with the derating curve given in the insta 	llation manual			
Failure to follow this instruction can result in equipment damage. Parameter F E D I can be adjusted to limit current during motoring or braking.					
	Display the letter C and the output frequency flashing on the embedded software term	inal, ex: [5]			
	If parameter [Unit value selection] (F 7 D I) is set to 1 (see page 130), parameter F 5 D I will be adjusted in amperes. If peter F 7 D I is set to 0, parameter F 5 D I will be adjusted as a percentage of the drive's output rated current as listed on nameplate.				
	The setting of parameter [Switch. freq. level] (<i>F</i> $\exists \Box \Box$) (see page <u>95</u>) does not chang this calculation.	e the drive's rated curre	ent for the sake of		
	Do not set parameter <i>F</i> <u>E</u> <u>D</u> <i>I</i> below the no-load current rating of the motor.				
LL	[Low limit frequency] Low speed	0.0 to [Upper limit freq] (<i>U L</i>) Hz	0.0 Hz		
(1)	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 30%.				
	Parameter <i>L</i> sets the minimum frequency that can be commanded to the drive by the local or remote speed reference source. See diagram above.				
UL	[Upper limit freq] High speed	0.5 to [Max fre- quency] (F H) Hz	50 Hz		
(1)	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 90%.				
	Parameter UL sets the maximum frequency that can be commanded to the drive by the local or remote speed reference source. The top end of its range is limited by the setting of Maximum frequency [Max frequency] (<i>F H</i>). See diagram above.				
	(4) When (EQ24) changes from [N=1 (0) to D(c=1 (4)) some of linked permeters or				

When (F324) changes from [No] (0) to [Yes] (1), some of linked parameters are set to a new value. When (F324) changes from [Yes] (1) to [No] (0), linked parameters value are not changed.
 See table page <u>199</u>

Code	Name / Description	Adjustment range	Factory setting			
F H	[Max frequency] Maximum Frequency	30.0 Hz to 400.0 Hz	50.0 Hz			
(1)	If [Driving Scroll] (F324) page 160 is set to [yes] (1) the setting is replaced by 90%.					
	The setting of parameter <i>F H</i> determines the maximum output frequency of the drive.					
	<i>F H</i> limits the setting of parameter [Upper limit freq] (<i>U L</i>) (see page <u>92</u>), which can be adjusted while the drive is operating. Acceleration and deceleration rates are also affected by the setting of <i>F H</i> , as the definition of [Acceleration time 1] ($H \ L \ L$) or [Deceleration time 1] ($d \ E \ L$) (see page <u>162</u>) is the time it takes for the drive to ramp the motor up or down between zero speed and the setting of <i>F H</i> .					
	Output frequency (Hz) Output frequency (Hz)					
	<u>Ен</u>					
	UL 0 Speed reference 100% 0 Spe	eed reference 100%				
<u>ЕЧПІ</u>	[Slip Compensation]	0 to 150%	50 %			
(1)	If [Driving Scroll] (E324) page 160 is set to [ves] (1) the setting is replaced by 0%	010100/0	30 //			
	Before adjusting parameter $F \neq D$, verify that parameter [Motor rated speed] ($F \neq I$ 7) (see page <u>161</u>) is set to the rated speed of the motor in rpm. Parameter $F \neq D$ I can be used to fine-tune the drive's slip compensation feature. Increasing the value of parameter $F \neq D$ L increases the drive's compensation of motor slip					
F 4 0 2	[Auto Torque Boost] 0.0 to 30.0% According to drive rating (2)					
	Use parameter F 4 D 2 to adjust the amount of automatic torque boost that is applied.					
	Motor rated voltage (k) $(k$					
	Motor Rated Frequency UL Ou	tput Frequency (Hz)				
d E C	[Deceleration time 1]	0.0 to 3200 s	According to drive rating (2)			
(1)	If [Driving Scroll] (F324) page 160 is set to [yes] (1) the setting is replaced by 0.9 s.					
	The setting of parameter $d \in C$ determines the slope of the deceleration ramp and the time it takes for the output frequency of the drive to decrease from the setting of [Max frequency] (<i>F H</i>) to 0 Hz.					
	depending on the amount of load on the motor during ramp down. See diagram above.		. - ,			
	If two different deceleration rates are needed, see parameter [Deceleration time 2] (F 5 0 1) on page 93.					
 (1) When (F324) changes from [No] (0) to [Yes] (1), some of linked parameters are set to a new value. When (F324) changes from [Yes] (1) to [No] (0), linked parameters value are not changed. (2) See table page <u>199</u> 						





Driving Scroll (F324) (continued)

Code	Name / Description	Adjustment range	Factory setting			
F 4 0 0	[Auto-tuning drive]	-	0			
	 HAZARD OF ELECTRIC SHOCK OR ARC FLASH During auto-tuning, the motor operates at rated current. 					
	Do not service the motor during auto-tuning. Failure to follow these instructions will result in death or serious injury.					
	A WARNING					
	 LOSS OF CONTROL It is essential that the following parameters <u>u L u</u>, <u>u L</u>, <u>F 4 15</u> and <u>F 4 17</u> are cutuning. 	orrectly configured befo	ore starting auto-			
	 When one or more of these parameters have been changed after auto-tuning has been performed, F 4 0 0 will return 0 and the procedure will have to be repeated. Failure to follow these instructions can result in death or serious injury. 					
	NOTICE					
	 RISK OF DAMAGE TO THE MOTOR Conduct auto-tuning only after the motor has been connected and operation completely stopped. If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in abnormal tuning. Failure to follow these instructions can result in equipment damage. 					
٥	Auto tuning enable [Disabled]					
1	[Initialize constant]: Factory setting of [Auto Torque Boost] (F 4 D 2) for asynchronous motor. Factory setting of [Auto Torque Boost] (F 4 D 2), [Autotune L q-axis] (F 9 1 2), and [Autotune L q-axis] (F 9 1 3), and [Motor Rated Voltage] (vIv) for synchronous motor.					
2	[Tun Static] :Tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), a synchronous motor.	Static]:Tune Dynamic, with driving run after the tuning. ation settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. ation settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 12), and [Autotune L q-axis] (F 9 13) for ronous motor.				
Э	[Tun Dyn.] : Complete tune Dynamic, with driving run after the tuning. Application settings of [Auto Torque Boost] (<i>F</i> 4 0 2), [Autotune L q-axis] (<i>F</i> 9 12), [A [Motor Rated Voltage] (VIV) for synchronous motor.	Autotune L q-axis] (F 9	<i>I I ∃</i>), and			
ч	 (Tun Prst 1): Tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2) for asynchronous motor. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 1 2), and [Autotune L q-axis] (F 9 1 3) for synchronous motor. (Tun Prst 2): Complete tune Static, without driving run after the tuning. Application settings of [Auto Torque Boost] (F 4 0 2), [Autotune L q-axis] (F 9 1 2), and [Autotune L q-axis] (F 9 1 3), and [Motor Rated Voltage] (vlv) for synchronous motor. 					
5						
	Parameter F 4 D D is reset to "0" after the auto tuning is performed					
F 4 5 8	[Current loop gain]	0100 Hz	0 Hz			
	Parameter F 4 5 B is set to the response gain of current loop					
	Note: Contact Schneider electric product support to confirm the modification of this par	ameter.				

F 4 18	[Frequency loop gain]		1 to 150	40
	Parameters $F + IB$ and [Freq. loop stability] ($F + IB$) reduce the speed of the drive's response to a change in speed command. The factory setting of these two parameters assumes that the inertia of the load is three times as large as that of the motor shaft. Adjust these two parameters if the factory setting is not appropriate for the application. Note: It is possible for the drive's output frequency to exceed its upper limit (parameter [Max frequency] ($F + I$)) if the acceleration parameter ($R \subseteq C \text{ or } F \subseteq D$ 7) is set to its minimum value. Increasing the setting of parameter $F + IB$ reduces the drive's response time to changes in the speed reference.			
F 4 19	[Freq. loop stability] Fr	requency loop stability	1 to 100	20
	Increasing the setting of parameter	er F 4 19 further reduces the drive's response to cha	inges in the speed refe	rence.
F495	[Motor voltage coef.] M	laximum voltage adjustment coefficient	90 to 120%	104%
	Use parameter <i>F</i> 495 to limit the drive's maximum output voltage. Increasing this setting increases torque when the motor is operated above its rated frequency, but may also cause motor vibration. Do not increase the value of <i>F</i> 495 if motor vibrations occur.			
F 9 / S	[PM mode selection] PI	M control mode selection	-	3
0 	 [0]: basic control [1]: control type 1 (for IPM) [2]: control type 2 (for IPM) [3]: control type 3 (for IPM / SPM) [4]: control type 4 (for IPM / SPM) For more details see the chapter Motor Control Parameters "F915" on page 84 			
F912	[Autotune L q-axis] Q	-axis self-inductance	0.01 to 650 mH	10
	Axis "q" stator inductance in mH The setting is replaced by the res	ult of the auto-tuning operation, if it has been perform	ed.	
F 9 3	[Autotune L d-axis] D-	-axis self-inductance	0.01 to 650 mH	10
	Axis "d" stator inductance in mH The setting is replaced by the resu	ult of the auto-tuning operation, if it has been performe	ed.	
F916	[PM Align cur. Level] St	tabilization at the starting and low speed (for PM)	0 to 100 %	25 %
	It might be able to stabilize the m	notor rotation behavior by the current in D axis at no lo	ad when starting or lov	<i>w</i> -speed
	For a complete description, see	e page <u>85</u> .		
F 9 2 1	[Init. Pos. Current] Ci	urrent for initial position estimation	10 to 150	100 %
	During the auto-tuning for d-axis	/ q-axis inductance, the maximum current level can be	e adjusted by this para	meter setting.
F 4 2 0	[Torque Boost Coef] Co	ompensation coefficient of torque boost	0 to 200%	90 %
	If synchronous or asynchronous n	notor is used F 4 2 D [Torque Boost Coef] is set to 90	0%.	
	Note: If <i>E</i> - <i>2</i> D [Excess torque boost fl	t] trip occurs at the start, it is recommended to be dec	reased the setting of F	:420





When (F324) changes from [No] (0) to [Yes] (1), some of linked parameters are set to a new value. When (F324) changes from [Yes] (1) to [No] (0), linked parameters value are not changed
 See table on <u>101</u> for a complete list of RES logic inputs assignment

F 3 0 3	[Number auto reset]	0		
UNINTENDED EQUIPMENT OPERATION				
 The automatic restart can only be used on machines or installations which do not pose any danger to e equipment. 				
	 If the automatic restart is activated, the fault relay will only indicate a fault has been detected once the time-out per the restart sequence has expired. 			
	• The equipment must be used in compliance with national and regional safety regulations Failure to follow these instructions will result in death or serious injury.			
0	Disabled.			
/ to / 🛙	Number of clear attempts.			
	F \exists \Box \exists is common and single for all functions The fault detection codes, which permit this function, are listed on page <u>135</u> .			

Pre-start Scroll (F325)

This function is to help protect the compressor. The Drive must reach [Low limit Freq] (LL) within 2 s max. If not, FreeWheel stop the drive and do an automatic restart after a preset delay [Pre-start delay] (F329). Once [Low limit Freq] (LL) speed is reached in less than 2 s [LL speed time] (F328) the motor should run at [Pre-Start speed] (F327) for a [Pre-Start time] (F326) before taking into account the reference frequency.



If the [Pre-Start speed] (F327) is never reach, the amount of attempt should be limited at 10, and the alarm code [Auto reset] (rtrY) should be raised (see alarm codes page <u>184</u>). After activating this function, [Pre-start Scroll] (F235) must be achieved at every run order.



Code	Name / Description		Adjustment range	Factory setting
F 3 2 S	[Pre-start Scroll]	Scroll Compressor Pre-start Management	-	0
0 1	At every Run Order the Drive must r to avoid mechanical issues. [No] [Yes]	each a preset Low Limit Frequency within a preset time	and a limited number c	f attempts in order
F 3 2 6	[Pre-Start time]	Time to reach the pre-start speed	06000 s	10 s
	Time during the motor turn to the p	re-start speed		

F327	[Pre-Start speed]	0.0 Hz to [Upper limit freq] (<i>U L</i>)	50 Hz	
	Speed to reach within the pre-start cycle			
F 3 2 8	[LL speed time] Time to reach LL Freq on pre-start order	010 s	2 s	
	Time which needs to be respected for reaching the low limit frequency. If the motor does not reach the [Low limit frequency] (LL) during this time the motor must stop.			
F 3 2 9	[Pre-start delay]	0120 s	3 s	
	Delay between two pre-start cycles			

Std Oiling Cycle (F330)

This function helps to prevent the damage to the installation by lubricating it after a period of running. The drive manages to re-oil the Scroll pump by running the ($F \exists \exists \Box = [Yes] (1)$) motor at the optimal [Std Oiling Speed] (F331) for a settable [Std Oiling Time] (F332).

The [Std Oiling Speed] (F331) must be reached at least one time within the [Std Oil. Cycle Frq.] (F333) of run order.



Code	Name / Description		Adjustment range	Factory setting
F 3 3 0	[Std Oiling Cycle]	Periodic Oiling Cycle management	-	0
	After a preset period of service and/or a preset time of running at a low speed, the drive must manage an oiling boost cycle by running at a preset oiling speed during a preset oiling time.			
0 1	[No] [Yes]			
F 3 3 1	[Std Oiling Speed]	Oiling Speed for Std Oiling Cycle	0 Hz to (UL) [Upper limit freq]	70 Hz
	Oiling is done at this frequency.			
F 3 3 2	[Std Oiling Time]	Time to maintain Oiling Speed in Std Cycle	0 s to 6000 s	30 s
	Time to maintain oiling speed in standard cycle			
F 3 3 3	[Std Oil. Cycle Frq.]	Frequency (time) of Standard Oiling Cycle	0 to 24 Hours (of run oder)	24 hrs
	Time during the motor which tur	n without lubrication since the first Run order.		•

Low Speed Oiling (F334)

This function helps to protect the installation of low lubrification that occurs at low speed. The [Std Oiling Speed] (F331) must be reach during a time [Oiling Time at LLS] (F337) if the motor speed stayed under a [LL Speed for Oiling] (F335) during a cycle limit [LLS Time for Oiling] (F336).



Code	Name / Description		Adjustment range	Factory setting
F 3 3 4	[Low Speed Oiling] Oiling management for	or low speed running	-	0
	A preset oiling speed must be reached during a preset time every time the motor stayed under a preset speed during a preset time to compensate a too low lubrication due to low speed.			
 _/	[No] [Yes]			
FJJI	[Std Oiling Speed] Oiling Speed for Std O	Diling Cycle	0 Hz to (UL) [Upper limit freq]	70 Hz
	Oiling Speed for Standard Oiling Cycle.			
F 3 3 5	[LL Speed for Oiling]		0 Hz to (UL) [Upper limit freq]	50 Hz
	Low speed threshold to start Oiling control.			
	If the system never reach it after time [LLS Time for Oiling] (F336) the system will go in lu	brification.	
F 3 3 6	[LLS Time for Oiling]		0360 minutes	60 minutes
	Time during the motor turn under the threshold of [LL Speed for Oiling] (F335).			
F337	[Oiling Time at LLS]		06000 s	30 s
	Time to maintain oiling injection in the installation.			
Scroll Protection (F338)

This function is active only out of the acceleration phase to helps protect the Scroll pump about overloading and cavitations effect, if the motor current limit is over passed and if the speed is under the [Cavitation Frq.] (F339) the drive will stop in Freewheel and the alarm signal will be displayed [Cavitation Error] (CAPF).

Code	Name / Description		Adjustment range	Factory setting
F 3 3 8	[Scroll Protection]	Avoid overloading or cavitation effects	-	0
	Scroll compressor protection ag	gainst the effects of overload and cavitation		
	If Fire function mode (53) is activated and F 3 3 B = (1), [Cavitation Error] (CAPF) alarm signal is inhibited, see Logic input Functions page 53			
0 1	[No] [Yes]			
F 3 3 9	[Cavitation Frq.]		[Low limit frequency] (L L) to [Upper limit freq] (u L)	30 Hz
	Cavitation Frequency Threshole	d.		·

Discharge gas (F349)

This function enables to helps to protect the installation avoiding high temperature or high pressure, the speed will automatically reduced the speed or stop the Scroll pump depending on temperature level [High Thd] (F350) and [High high Thd] (F353).

The time [Re-Start Delay] (F354) before automatic restart (see [Number auto reset] (F303) page <u>169</u>) is settable and the number of maximum attempt is limited to 10. The restart will come [Re-Start Delay] (F354) after the temperature gets under \leq [High high Thd] (F353).



Code	Name / Description		Adjustment range	Factory setting
F 3 4 9	[Discharge gas] Avoid high temp. or press	ure on sensor input	-	0
0 1 2	This function helps to protect the installation avoiding high temperature or high pressure in the refrigerant loop. [No] Function unactive [VIA] Function is active and uses analog input VIA [Ref source VIA] [VIB] Function is active and uses analog input VIB: [Ref source VIB]			
F 3 5 D	[High Thd]		0 - 100	65 %
	High Process Threshold Note : 100% means analog input ports VIA or VIB applied full s	cale value.		
F 3 S I	[Cooling Frq.]		[Low limit frequency] (L L) to [Upper limit freq] (U L)	50 Hz
	Cooling system Frequency.			
F 3 5 2	[Cooling Time]		0 - 30	3 minutes
	Time to maintain cooling system frequency.			
F 3 5 3	[High high Thd]		0 - 100	70 %
	High high Process Threshold. Note : 100% means analog input ports VIA or VIB applied full s	cale value.		
F 3 5 4	[Re-Start Delay]		030 minutes	5 minutes
	Delay before restart after emergency stop.			

Crankcase heating (F355)

Replace crankcase heaters by using a current injection in motor to generate resistance heating.

Note: Before using the Function [Crankcase heating] (F355), to stop the current injection you should assign a logic input to Freewheel stop, you can also stop the injection by a power off.

Code	Name / Description	Adjustment range	Factory setting	
F 3 5 5	[Crankcase heating] Keep the system warm after motor stopped	-	0	
	Heating by current injection in the motor in order to prevent the emission of gas due to the condensation of the refrigerant into the compressor.			
0 1	[No] [Yes]			
F 2 S D	Image: DC brake start freq.] 0.0 Hz to [Max frequency](FH) 0.0 Hz		0.0 Hz	
(1)	If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 0.0 Hz.			
	A WARNING			
	 NO HOLDING TORQUE DC injection braking does not provide holding torque at zero speed. DC injection braking does not work when there is a loss of power or when the drive detects a fault. When necessary, use a separate brake to maintain torque levels. Failure to follow these instructions can result in death, serious injury, or equipment damage. 			
	When stopping the motor, the drive will apply DC injection braking once the output frequer $F \ge 5 D$.	ncy drops below the leve	l set by parameter	
F 2 5 1	[DC braking current]	0 to 100 %	50%	
(1)) If [Driving Scroll] (F324) page <u>160</u> is set to [yes] (1) the setting is replaced by 10%.			
	NOTICE			
	RISK OF DAMAGE TO THE MOTOR Check that the motor will withstand this current without overheating. Failure to follow this instruction can result in equipment damage.			
	Parameter <i>F</i> $\stackrel{?}{_{-}}$ $\stackrel{?}{_{-}}$ <i>I</i> sets the level of current applied to the motor during DC injection brak peres, is set by parameter [Unit value selection] (<i>F</i> $\stackrel{?}{_{-}}$ $\stackrel{D}{_{-}}$) (see page <u>130</u>). During DC injection braking, the drive's overload protection sensitivity increases. The drive rent to avoid an overload detected fault.	ing. The displayed value e automatically lowers t	e, percent or am- he applied DC cur-	

(1) When (F324) changes from [No] (0) to [Yes] (1), some of linked parameters are set to a new value. When (F324) changes from [Yes] (1) to [No] (0), linked parameters value are not changed.

Diagnostics and troubleshooting

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
14	Diagnostics and troubleshooting	

Diagnostics and troubleshooting

15

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Detected fault conditions	180
Alarm Conditions	184
Pre-alarm Conditions	186
Clearing the detected fault	187

Detected fault conditions

Refer to tables on pages hereafter to diagnose and solve troubles when there is a fault detection, or when an alarm, or pre-alarm condition occurs.

If the trouble cannot be solved by the actions described in the tables, contact your Schneider Electric representative.

A A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

• Read and understand the instructions in «Before you begin» chapter, before performing the procedure in this section.

Failure to follow these instructions will result in death or serious injury.

Alarm Codes

Code	Name	Possible causes	Remedies
CAPF	[Cavitation Error]	Loss of speed due to overload or / and too much torque.	Reduce the load
CFIZ	[Download transfer fault]	 Invalid configuration. The configuration loaded in the drive via the bus or communication network is inconsistent. 	 Check the configuration loaded previously. Load a compatible configuration.
		 Transfer using PC soft has not been successful due to rating differences (for example upload of an ATV212eeeN4 configuration to an ATV212eeeM3) 	 To perform download, uncheck "Display communication error" (in Tool / Environnement option / Startup/Comm.)
E - 18	[VIA signal fault]	• The VIA analog signal is below the level set by parameter <i>F</i> b g g .	 Check the signal at VIA and rectify the cause of the signal loss. Verify that parameter <i>F E J J</i> is set correctly.
E - 19	[CPU communica- tions err.]	Communication error between control CPUs	 Check the environment (electromagnetic Compatibility) Turn off and restart product. Contact Schneider electric product support.
E - 20	[Excess torque boost flt]	 Torque boost parameter [Auto Torque Boost] (F 4 D 2) is set too high. The motor impedance is too low. During deceleration when [Mot cont. mode sel.] (P E) = (1) [Quadr. U/F] with 3 conditions: Processing for stop Load current value > 88% x [Motor Current Limitation] (F E D 1) Too slow deceleration, [Max frequency] (F H) /[Deceleration time 1] (d E C) x 2 msec < 0.01Hz 	 Repeat the Auto-tuning drive and reduce [Auto Torque Boost] (F 4 0 2). Set [Auto ramp] (R U 1) = (0) [Disabled] Decrease the deceleration ramp with [Deceleration time 2] (F 5 0 1) and [Commut. ramp freq.] (F 5 0 5).
E-21	[CPU error 2 fault]	The control board CPU is inoperable.	Contact Schneider Electric to repair the drive.
E - 38	[EEprom pwr incom- pat.]	 Eeprom power incompatible. Product hardware detected fault. 	 Contact Schneider Electric to repair the drive.
E - 39	[InitPos Det]	 An Error is detected at the starting: The measured current at initial position detection at the starting is too small or large according to the inductance of motor or output phase loss. 	 Check the motor phases and the maximum current allowed by the drive. To check that the inductance of motor is too small or too large.
EEPI	[EEPROM error 1 fault]	 A data writing error has occurred. 	Cycle power to clear the detected fault.
EEP2	[EEPROM error 2 fault]	 Power was removed from the drive during a parameter reset operation resulting in a data writing error. The measured current at initial position detection at the auto-tuning is too small or large according to the inductance of motor or output phase loss 	 Cycle power to clear the detected fault and try the parameter reset operation again. If the detected fault does not clear, contact Schneider Electric to repair the drive.
ЕЕРЭ	[EEPROM error 3 fault]	 A data reading error has occurred. 	Cycle power to clear the detected fault.

Code	Name	Possible causes	Remedies
EF2	[Ground fault]	Ground fault in motor or motor cables	Check the motor and motor cables for ground faults.
EPHD	[Output phase loss fault]	Loss of one or more output phases	 Determine the cause of the missing output phase (such as a bad connection, an output disconnect, or an open winding in the motor) and clear it. Check parameter <i>E 6 D 5</i>.
EPHI	[Input phase loss fault]	Loss of one input phase	 Determine the cause of the missing input phase and clear it. Check parameter <i>F 6 D B</i>.
EPEF	[Threshold Error]	 Condition for overheating reached, exceeded Treshold F 3 5 3 	Check the system.
Errl	[Speed ref. error fault]	• Parameters F 2 0 2, F 2 0 3, F 2 1 0, or F 2 1 2 are set improperly.	• Set the parameters to the correct settings.
Err2	[RAM fault]	The control board RAM is inoperable.	Contact Schneider Electric to repair the drive.
Err3	[ROM fault]	• The control board ROM is inoperable.	Contact Schneider Electric to repair the drive.
Err4	[CPU fault 1]	The control board CPU is inoperable.	Contact Schneider Electric to repair the drive.
Err5	[Com RJ45 fault]	Serial communication error	 Check network control devices and cables. Check the setting of the communication timeout parameter, <i>F</i> B D 3. Check the remote graphic display option cable. Check the setting of <i>F</i> B 2 9 parameters.
Err7	[Current sensor fault]	• A motor current sensor is inoperable.	Replace the drive.
ErrB	[Network error fault]	Network communication error	Check the network control devices and cables.
Err9	[Remote keypad fault]	Graphic display option cable disconnected	Check the RJ45 cable.
Etnl	[Auto-tuning fault]	 Parameters F 4 D I to F 4 D 4 are incorrectly set. The motor is too large for the drive. The motor cable gauge is too small. The motor is still rotating at the start of the auto-tune. The drive is not powering a 3-phase induction motor. The measured current at initial position detection at the auto-tuning is too small or large according to the inductance of motor or output phase loss 	 Set parameters F 4 D 1-F 4 9 4 correctly. Use a larger drive. Use a larger gauge motor cable. Verify that the motor is stopped before starting an auto-tune. Use the drive to power only a 3-phase induction motor.
ELYP	[Drive fault]	 The main control board is inoperable. 	 Set parameter [Parameter reset] (<i>L Y P</i>) to 6. If this does not clear the detected error, replace the drive.
FdI	[Closed damper 1 fault]	Damper is locked in closed position.	 Set [Damper flt behavior] (F 5 B 3) to 0. Check the FL relay connection (F L R/F L B). Check the relay configuration (F I 3 D/F I 3 2).
FdZ	[Closed damper 2 fault]	Damper blocked open or soldered.	 Set [Damper fdb type] (F 5 B D) to 0 or 1.Check the FL relay connection (F L R/F L B). Check the relay configuration (F I 3 D/F I 3 2).
n o z o	[Total input power]	• The accumulated input power value is more than 999.999 kWh.	• Clear the accumulated input power value using logic input function 51, or parameter F 748.

Code	Name	Possible causes	Remedies
001	[Overcurrent acceleration]	 The acceleration time is too short. The setting of parameter [Mot cont. mode sel.] (<i>P L</i>) is incorrect. The drive is starting into a rotating load. The drive is powering a low impedance motor. Ground fault 	 Increase the acceleration time parameters (<i>R L L</i> or <i>F</i> 5 <i>D D</i>). Select the correct setting for parameter [Mot cont. mode sel.] (<i>P L</i>). Enable catch on the fly, parameter <i>F B D</i>. Adjust the switching frequency parameter <i>F B D D</i>. Set parameter <i>F B I E</i> to 1 or 3.
0C IP	[SC or ground fault acc.]	 Short circuit or ground fault during acceleration 	 Using a 1000 V testing tool megger, check the motor and motor cables for ground faults
002	[Overcurrent deceleration]	 The deceleration time is too short. Ground fault	 Increase the deceleration time parameters (<i>d E [</i> or <i>F</i> 5 <i>D I</i>). Set parameter <i>F</i> 3 <i>I</i> 5 to 1 or 3.
0C2P	[SC or ground fault dec.]	 Short circuit or ground fault during deceleration 	 Using a 1000 V megger, check the motor and motor cables for ground faults.
003	[Overcurrent cont. speed]	Abrupt fluctuations in loadAbnormal load condition	 Reduce the load fluctuations. Check the load. Set parameter F 3 1 5 to 1 or 3.
OC 3P	[SC/ground flt cont. spd]	Short circuit or ground fault during constant speed operation	Using a 1000 V megger, check the motor and motor cables for ground faults.
		• The drive cooling fan is not working.	Check the fan operation
068	[SC inverter at start]	Ground fault	 Using a 1000 V megger, check the motor and motor cables for ground faults.
0 C L	[SC mot. cable at start]	Phase to phase output short circuitThe motor impedance is too low.	 Using a 1000 V megger, check the motor and motor cables for ground faults.
DH	[Drive overtemperature]	 The drive cooling fan is not working. The ambient temperature is too high. An enclosure air vent is blocked. A heat source is too close to the drive. The drive heatsink temperature sensor is malfunctioning. 	 Restart operation by resetting the drive detected fault after cool-off. Decrease the ambient temperature by increasing the free space around the drive and removing any heat generating source from the proximity of the drive. Check the fan operation
0 H 2	[PTC overheating]	• The external PTC embedded in the motor windings indicates a motor overtemperature condition.	 Correct the motor overload condition. Check the PTC for correct operation.
OL I	[Drive overload]	 The acceleration time is too short. The DC injection current level is too high. The setting of parameter [Mot cont. mode sel.] (<i>P L</i>) is incorrect. The drive is starting into a rotating load. The load is too large. 	 Increase the acceleration time parameters (<i>R L L</i> or <i>F S D D</i>). Reduce the setting of parameters <i>F 2 S I</i> and/or <i>F 2 S 2</i>. Select the correct setting for parameter [Mot cont. mode sel.] (<i>P E</i>). Enable catch on the fly, parameter <i>F 3 D I</i>. Set parameter <i>F 3 D 2</i> to 2. Use a drive with a higher power rating.
OL 2	[Motor overload]	 The setting of parameter [Mot cont. mode sel.] (<i>P L</i>) is incorrect. The motor is jammed. Low-speed operation is performed continuously Excessive load is applied to the motor. 	 Select the correct setting for parameter [Mot cont. mode sel.] (<i>P L</i>). Check the load. Adjust parameter <i>D L Π</i> to the overload level that the motor can withstand during low speed operation.
OP I	[Overvoltage acceleration]	 The input voltage is fluctuating abnormally. Power network is greater than 200 kVA. Power factor capacitor switching SCR switching on power network The drive is starting into a rotating load. Intermittent output phase fault 	 Install a line reactor. Enable catch on the fly, parameter F 3 0 1. Set parameter F 3 0 2 to 2. Determine the cause of the missing output phase (such as a bad connection, an output disconnect, or an open winding in the motor) and rectify the trouble.
OP 2	[Overvolt. deceleration]	 The deceleration time is too short. Overhauling load The input voltage is fluctuating abnormally. Power network is greater than 200 kVA Power factor capacitor switching SCR switching on power network The drive is starting into a rotating load. Intermittent output phase fault 	 Increase the deceleration time parameters (D E C or F 5 D I). Enable parameter F 3 D 5. Install a line reactor. Check the input and output circuits for phase loss detection and rectify. Enable catch on the fly, parameter F 3 D I.

Code	Name	Possible causes	Remedies
0 P 3	[Overvoltage cont. speed]	 The input voltage is fluctuating abnormally. Power network is greater than 200 kVA Power factor capacitor switching SCR switching on power network The drive is regenerating - the load causes the motor to run at a frequency higher than drive output frequency. Intermittent output phase fault 	 Install a line reactor. Check the input and output circuits for phase loss detection and rectify.
0 E	[Overtorque]	• The calculated motor torque has reached the level set by parameter <i>F B I B</i> .	 Adjust the settings of parameters <i>F 6 15</i> and <i>F 6 16</i> as needed. Verify machine operation.
PSrF	[Prst Spd Error]	Prestart speed not reached.The load is too high.	Reduce the load
SOUE	[PM motor step-out] (permanent magnet motor pulls out of synchronism)	The motor is jammed.Output phase lossImpact load	 Check the load and correct the jammed condition. Check the condition of the motor and load wiring.
UC	[Underload]	• The measured motor current has dropped below the level set by parameter <i>F E I I</i> .	• Check parameters <i>F</i> b <i>l</i> D - b <i>l</i> 2 for the correct settings.
UPI	[Undervoltage]	The input voltage is too low.	 Check the input voltage and rectify the trouble. Select the correct setting for parameter <i>F</i> 6 2 7. Enable catch on the fly, parameter <i>F</i> 3 0 1. Set parameter <i>F</i> 3 0 2 to 2.

Alarm Conditions

Alarms do not cause the drive to enter a fault condition.

Alarm Codes

Code	Description	Possible causes	Remedies
Atn I	[Auto tune]	Auto-tuning in process	 Normal if it the message disappears after a few seconds.
[Lr	[Reset active]	• This message is displayed after the STOP key is pressed while an detected fault is displayed.	Press the STOP key again to clear the detected fault.
d b	[DC braking]	DC braking in process	 The alarm code goes off in several seconds if no trouble occurs.
d 6 0 n	[dbOn]	• DC braking in process, when [Crankcase heating] (F355) is activated.	 Normal behavior (if [Crankcase heating] (F355) is activated, and the motor is stopped)
E - I 7	[HMI error]	 A graphic display option key has been held down for more than 20 seconds. A graphic display option key may not be operating properly. 	 Release the graphic display option key. If this does not clear the error, replace the drive.
EI	[Excess value] The number of digits that can be displayed has been exceeded	• The number of digits entered for values such as frequencies is more than 4 (the upper digits have priority).	 Lower the frequency free-unit magnification [Customized freq val] (F 7 D 2).
EOFF	[Loc. Stop en.]	• The operation panel is used to stop the operation in automatic control or remote control mode.	• Press the STOP key for an emergency stop. To cancel the emergency stop, press any other key.
Errl	[Speed ref alarm]	• The frequency setting signals at points 1 and 2 are set too close to each other.	 Set the frequency setting signals at points 1 and 2 apart from each other.
h999	[Pin&1MWh] Integral input power	• Integral input power is more than 999.99 kWh.	 Press and hold down the ENT key for 3 s or more when power is off or when the input terminal function CKWH is turned on or displayed.
H999	[Pout&1MWh] Integral output power	Integral output power is more than 999.99 kWh.	 Press and hold down the ENT key for 3 s or more when power is off or when the input terminal function CKWH is turned on or displayed.
HEAd End	[Head] [End] Display of first/last data items	 The first and last data item in the auh data group is displayed. 	 Press MODE key to exit the data group.
H I L D	[High] [Low] Parameter adjustment error	• During programming, a value was entered that exceeds the maximum or minimum value of the parameter.	Enter a value within the bounds of the parameter
Init	[Initialization]	 Parameters are being initialized to default values. 	 Normal if the message disappears after several seconds.
LSEP	[Low speed stop] Auto-stop because of continuous operation at the lower-limit frequency	 The automatic stop function selected with F 2 5 5 was activated. 	• To deactivate the automatic stop function, increase the frequency command above the lower-limit frequency <i>L L</i> + <i>F ∃ 𝔅 I</i> or turn off the operation command.
ΠΟΓΓ	[Line undervolt flt]	The phase-to-phase input voltage is too low.	• Measure the main circuit supply voltage. If the voltage is at a normal level, the drive requires repair.
OFF	[Drive stop]	The ST-CC (run permissive) circuit is open.	Close the ST-CC circuit.
nSt	[Lock State]	 The Li is already active when the function is validated. The Li is already active when a configuration transfer is done with the function is validated. 	Deactivate the active Li configured.
rtry	[Auto reset]	The drive is in the process of restart.A momentary stop occurred.	 The drive is operating normally if it restarts after several seconds.

		·	L
SEUP	[Stop supply] Momentary	 The slowdown stop prohibition function 	• To restart operation, reset the drive or
	power loss slowdown stop	set with F 3 0 2 (momentary power loss	input an operation signal again.
	prohibition function	ride-through operation) is activated.	
	activated.		

Pre-alarm Conditions

Pre-alarm Codes

Code	Pre-alarm	Description
Ľ	[Current alarm]	 The drive is at current limit. For more information, refer to parameter F 6 0 / (see page 73) and F / 8 5 (see page 79).
P	[DC bus alarm]	 The drive is approaching an overvoltage detected fault due to a high supply line, regenerative motor braking, or a combination of these. For more information, refer to parameters F 3 D 5 (see page 139) and F 6 2 6 (see page 139).
L	[Motor overload al]	• The motor overload timer has reached or exceeded 50% of its detected fault level.
Н	[Drv overheat alrm]	The drive is approaching an overheating fault detection.

The pre-alarm codes are displayed, flashing on the embedded HMI, in the following order from left to right: L, P, L, H.

If two or more troubles arise simultaneously, one of the following pre-alarm codes appears and flashes: *L* P, P L, *L* P L.

Clearing the detected fault

In the event of a non resettable detected fault:

- 1 Disconnect all power, including external control power that may be present.
- 2 Lock all power disconnects in the open position.
- 3 Wait 15 minutes to allow the DC bus capacitors to discharge (the drive LEDs are not indicators of the absence of DC bus voltage).
- 4 Measure the voltage of the DC bus between the PA/+ and PC/– terminals to ensure that the voltage is less than 42 Vdc.
- **5** If the DC bus capacitors do not discharge completely, contact your local Schneider Electric representative. Do not repair or operate the drive.
 - Find and correct the detected fault.
 - Restore power to the drive to confirm the detected fault has been rectified.

When any overload function ($\Box L$ I or $\Box L 2$) is active, the drive cannot be reset by inputting a reset signal from an external device or with the Stop key on the display terminal if the calculated cooling time has not expired. Calculated cooling time:

- DL 1: 30 seconds after the detected fault has occurred
- DL 2: 120 seconds after the detected fault has occurred

NOTICE

RISK OF DAMAGE TO THE MOTOR

- Repeated reset of the thermal state after a thermal overload can result in thermal stress to the motor.
- When trips occur, promptly inspect the motor and driven equipment for problems (such as a locked shaft or mechanical overload) before restarting. Also check the power supplied to the motor for abnormal conditions (such as a phase loss or phase imbalance).

Failure to follow these instructions can result in equipment damage.

Annex

IV

What's in this Part?

This part contains the following chapters:

Chapter	Chapter Name	Page
15	Migration	191
17	Parameters Reset Tables	193
18	User Settings Tables	203

Migration

16

What's in this Chapter?

This chapter contains the following topics:

Торіс	Page
Migration ATV21 - ATV212	192

Migration ATV21 - ATV212

General

The ATV212 is compatible with the ATV21

Migration Modbus ATV21 to ATV212: When controlling ATV21 using Modbus RJ45, parameter [Network protocol] (*F* B 2 9) should be set to 1.

With ATV212, parameter *F* B 2 9 should also be set to *I* and parameter [Com channel choice] (*F* B D 7) set to [RJ45] (D). Factory setting is [Open style] (*I*).

Settings of other communication parameters described from page <u>148</u> remain the same as on ATV21.

Note: For LonWorks, parameter F 8 2 9 needs to be set to / for ATV21 and needs to be set to 5 for ATV212.

A configuration transfer from ATV21 to ATV212 is possible.

For example:

You can upload a configuration from an ATV21 via PC Soft (and selected the inverter Type : ATV21) and download it into ATV212.

After a transfer from ATV21 to ATV212, the new parameters stay at their factory setting:

[Damper fdb type] ($F \leq B \square$), [Time open Damper] ($F \leq B \square$), [Time close Damper] ($F \leq B \square$), [Damper flt behavior] ($F \leq B \square$), [Forced fire control] ($F \leq S \square$), [Forced fire function] ($F \leq S \square$), [Com channel choice] ($F \mid B \mid \square \square$), [Mdb network baud] ($F \mid B \supseteq \square$), [Mdb network parity] ($F \mid B \supseteq \square$) and [LL for ov.cur. prev.] ($F \mid \exists \mid \square \square$).

The download configuration is not allowed if the drive is running.

In case of an interruption of download configuration transfer to the drive and detected fault, the *L F I 2* is set. This detected fault code keeps also present even after power off of the drive.

To reset the download transfer detected fault code [F 12:

- Make a new successful transfer
- Make a factory setting on the drive (using <u>L</u> <u>Y</u> <u>P</u> parameter)

At the end of download transfer, the drive cannot run if a logic input configured to a function is active. To use the function and run the motor, it's necessary to disable and enable the logic input.

Commissioning

Compatible loader tools with ATV212:

- SoMove V1.7.1.1 and higher,
- Multi-Loader V3.2 and higher,
- SoMoveMobile V2.2.7 and higher,
- PC soft is not compliant, since the software version V5.2 of the products ATV212.

LOSS OF CONTROL

Since the software version V5.2 of the products ATV212, PC soft is not compliant.

Do not use PC soft with the products ATV212 V5.2 and at and above.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Parameters Reset Tables

Parameter Reset

Refer to Menu navigation diagram page $\underline{66}$ to know how to reach [Parameter reset] (\underline{F}) parameter. The Altivar 212 drive offers three parameter reset options:

- Factory reset: [Parameter reset] (L Y P) = 3
- 50 Hz reset: [Parameter reset] (L Y P) = 1
- 60 Hz reset: [Parameter reset] (L Y P) = 2

This appendix describes parameter values after these reset operations.

The following tables identify:

- Parameters whose values after a reset do not vary by reset type, see page 194.
- Parameters whose values after a reset vary by reset type, see page <u>198</u>.
- Parameters whose values after a reset are drive model dependant but do not vary by reset type, see page <u>199</u>.
- Parameters whose values after a reset are drive model and reset type dependant, see page 200.
- Parameters whose values do not change if a reset is performed, see page 201.

Parameter values that do not vary by reset type

The table below lists the parameters whose values, after a reset, do not vary by the reset type.

Parameters whose values after a reset do not vary by reset type

Parameter	Description	Unit	Default Value
AU 1	[Auto ramp]	_	1
A U Y	[Auto set function]	-	0
FNSL	[AO funct. selection]	-	0
FП	[AO scaling]	-	_
ŁУP	[Parameter reset]	-	0
Fr	[Local mot. direction]	-	0
FC	[Local speed ref.]	Hz	0.0
LL	[Low limit frequency]	Hz	0.0
PE	[Mot cont. mode sel.]	-	1
0 L N	[Motor overload prot]	_	0
Sr I	[Preset speed 1]	Hz	15
Sr 2	[Preset speed 2]	Hz	20
5 r 3	[Preset speed 3]	Hz	25
5-4	[Preset speed 4]	Hz	30
5 r 5	[Preset speed 5]	Hz	35
5 r 6	[Preset speed 6]	Hz	40
5-7	[Preset speed 7]	Hz	45
F 100	[Freq. 1 reached]	Hz	0.0
F 10 1	[Freq. 2 reached]	Hz	0.0
F 102	[Freq.2 bandw.]	Hz	2.5
F 108	[Logic Funct 1 active]	-	0
F 109	[VIA selection]	-	0
F 0	[Logic Funct 2 active]	-	1
FIII	[LI F selection]	-	2
F 1 12	[LI R selection]	_	6
F 3	[LI RES selection]	-	10
F 8	[VIA LI selection]	-	7
F 130	[RY Relay Function 1]	_	4
F 132	[FL Relay Function]	-	11
F 137	[RY Relay Function 2]	-	255
F 139	[RY logic select.]	-	0
F 16 7	[Freq band det range]	Hz	2.5
F 2 0 0	[Auto/man speed ref]f	-	0
F201	[VIB ref. point 1]	%	0
F 2 0 2	[VIA freq. point 1]	Hz	0.0
F 2 O 3	[VIA freq. point 2]	%	100
F207	[Remote spd ref 2]	-	2
F 2 10	[VIB ref. point 1]	%	0

Parameter	Description	Unit	Default Value
FZII	[VIB freq. point 1]	Hz	0.0
F 2 1 2	[VIB ref. point 2]	%	100
F 2 4 0	[Mot start freq.]	Hz	0.5
F241	[Freq. pedestal]	Hz	0.0
F242	[Freq. pedestal hyst.]	Hz	0.0
F250	[DC brake start freq.]	Hz	0.0
F251	[DC braking current]	А	50
F 2 5 2	[DC braking time]	S	1.0
F256	[Time limit low spd]	s	0.0
F 2 6 4	[+speed LI resp time]	s	0.1
F265	[+speed freq. step]	Hz	0.1
F266	[- speed LI resp time]	s	0.1
F267	[- speed freq. step]	Hz	0.1
F268	[Init +/- Speed]	Hz	0.0
F269	[Init +/- Speed memo]	-	1
F270	[Jump frequency 1]	Hz	0.0
FZTI	[Jump bandwidth 1]	Hz	0.0
F272	[Jump frequency 2]	Hz	0.0
F273	[Jump bandwidth 2]	Hz	0.0
FZTY	[Jump frequency 3]	Hz	0.0
F275	[Jump bandwidth 3]	Hz	0.0
F 2 9 4	[Forced speed freq.]	Hz	50
F295	[Switch rem/Local]	-	1
F 3 O I	[Catch on fly]	-	3
F 3 0 2	[Supply loss behav.]	-	0
F 3 0 S	[Overvoltage fault]	-	2
FJOJ	[Mot volt limitation]	-	3
FJII	[Motor direction]	-	1
F 3 1 2	[Noise reduction]	-	0
F 3 16	[Switch. freq. mode]	-	1
F 3 2 0	[Load gain]	%	0
F 3 2 3	[Load gain offset]	%	10
F 3 5 9	[PID ctrl wait time]	S	0
F 360	[PID control enable]	-	0
F 362	[PID Prop Gain]	-	0.30
r 363	[PID Integral Gain]	-	0.20
r 300 6400		-	0.00
		- 0/	50
		70	50
F 4 19	[Freq. loop stability]	_	20
<u>.</u> ЕЧ ТП	[/ rod, loop stability]	_	128
FHTI			148
EHIZ	[VIB bias]	_	128
FYTE	IVIB gain]	_	148
F482	In noise Inhibit filter]	118	442
	for states and the states of t	μO	• •=

Parameter	Description	Unit	Default Value
F 4 8 3	[In noise inhibit gain]	-	100
F 4 8 4	[Pwr supply adj. gain]	-	0.0
F 4 8 5	[Stall control coef. 1]	-	100
F 4 9 2	[Stall control coef. 2]	-	100
F495	[Motor voltage coef.]	%	104
F496	[PWM adj. coef.]	kHz	14.0
F 5 0 2	[Acc/dec 1 pattern]	-	0
F 5 0 3	[Acc/dec 2 pattern]	-	0
F 5 0 4	[Ramp switching]	-	1
F 5 0 5	[Commut. ramp freq.]	Hz	0.0
F 5 0 6	[Acc/Dec S-pat start]	%	10
F 5 0 7	[Acc/Dec S-pat end]	%	10
F 6 0 2	[Drive fault memory]	-	0
F 6 0 3	[Ext. fault stop Mode]	-	0
F 6 0 4	[DC brk time ext flt]	s	1.0
F605	[Output phase loss]	-	3
F607	[Mot overload time]	s	300
F608	[Input phase loss]	-	1
F609	[Underload band]	%	10
F6 10	[Underload det.]	-	0
F 6	[Underload level]	% / A	0
F612	[Underload det. time]	S	0
F613	[Short circuit det.]	-	0
F6 /5	[Overtorque det.]	-	0
F 6 1 6	[Overtorque level]	%	130
F6 18	[OvTorque det time]	S	0.5
F6 19	[Overtorque band]	%	10
F621	[Run time alarm]	h	610.0 (6100 h)
F627	[Undervolt detect.]	-	0
F 6 3 2	[Mot overload memo]	-	0
F 6 3 3	[Loss of VIA]	%	0
F634	[Amb. temp. alarm]	-	3
F 6 4 5	[Mot PTC selection]	-	0
F 6 4 6	[PTC resistor value]	Ω	3000
F650	[Forced fire control]	-	0
F 6 9 1		-	1
F 6 9 2		%	0
F 100		-	0
r 10 1	[Unit value selection]	-	1
F 10C		-	U
F 103	[Frequency convert.]	-	U
6 7 0 7		HŻ	0.0
5 7 0 0		ΠZ	0.0
F 108	[Display rel. [ES0].]	-	0
F 1 1U	[Displayed param.]	-	U
FIEI	[Loc. mot stop mode]	-	U

Parameter	Description	Unit	Default Value
F 7 3 0	[Up/down key ref]	-	0
FT32	[Loc/rem key]	-	0
FIJJ	[Run/stop key]	-	0
FT34	[Priority stop]	-	0
F 7 3 5	[HMI reset button]	-	1
FIJB	[Quick menu AUF]	-	0
FTYB	[Power cons. memo]	-	1
F800	[Mdb RJ45 baud]	-	1
F80 I	[Mdb RJ45 parity]	-	1
F802	[Modbus address]	-	1
F803	[Com. time out]	s	3
F829	[Network protocol]	-	1
F851	[Com. fault setting]	-	4
F856	[Mot. poles (comm.)]	-	2
FB7D	[Block write data 1]	-	0
FBTI	[Block write data 2]	-	0
F875	[Block read data 1]	-	0
F876	[Block read data 2]	-	0
FBJJ	[Block read data 3]	-	0
FBTB	[Block read data 4]	-	0
F879	[Block read data 5]	-	0
F880	[Free ID parameter]	-	0
F890	[Network adress]	-	(1)
F891	[Network baud rate]	-	(1)
F892	[Network time out]	-	(1)
F893	[Instance number H]	-	(1)
F894	[Instance number L]	-	(1)
F895	[Max master]	-	(1)
F896	[Max info frames]	-	(1)

(1) See table page 199.

Parameter values that vary according to reset type

The table below lists the parameters whose values, after a reset, depend on the reset type ([Parameter reset] ($L \ \square P$) = 1, [Parameter reset] ($L \ \square P$) = 2, or [Parameter reset] ($L \ \square P$) = 3).

To determine the value of a parameter after a reset, locate the parameter in the first column and read across the row to the column that corresponds to the reset type. The number that appears at the intersection of the parameter and the reset type is the parameter's value after a reset of the corresponding type.

Parameters whose values after a reset vary by reset type

Parameter	Description	Unit	Factory Reset	50 Hz Reset <i>L </i>	60 Hz Reset <i>L Y P</i> = 2
C N D d	[Command mode sel]	-	0	0	0
FNDd	[Frequency mode sel]	_	1	1	1
F H	[Max frequency]	Hz	50	50	60
UL	[Upper limit freq]	Hz	50	50	60
υL	[Motor rated freq.]	Hz	50	50	60
F 170	[Mot 2 rated Freq.]	Hz	50	50	60
F 2 0 4	[VIA freq. point 2]	Hz	50	50	60
F 2 I 3	[VIB freq. point 2]	Hz	50	50	60
F 3 O 3	[Number auto reset]	_	0	0	0
F 4 8 0	[No load cur. coef]	%	100	0	100
F 4 8 1	[In noise comp. filter]	micro-seconds	0	100	0

Parameter values that vary According to drive rating, but not reset type

The table below lists the parameters whose values, after a reset, depend on the drive model.

To determine the value of a parameter after a reset, locate the drive model number in first column and read across the row to the column that corresponds to the parameter code. The number that appears at the intersection of the model number and the parameter code is the parameter's value after a reset. These values are the same for every reset types ([Parameter reset] ($L \ \ P$) = 1, [Parameter reset] ($L \ \ P$) = 2, or [Parameter reset] ($L \ \ P$) = 3).

Parameters whose values after a reset are drive model dependant but do not vary by reset type

	Parameter											
Reference	ACC	dEC	vLv	ub	F171	F172	F300	F402	F494	F626	F749	
	S	S	V	%	V	%	kHz	%	-	%	-	
ATV212H075M3X	10	10	200	6	200	6	12	5.8	80	140	0	
ATV212HU15M3X	10	10	200	6	200	6	12	4.3	70	140	0	
ATV212HU22M3X	10	10	200	5	200	5	12	4.1	70	140	0	
ATV212HU30M3X	10	10	200	5	200	5	12	3.7	70	140	0	
ATV212HU40M3X	10	10	200	5	200	5	12	3.4	70	140	1	
ATV212HU55M3X	10	10	200	4	200	4	12	3.0	70	140	1	
ATV212HU75M3X	10	10	200	3	200	3	12	2.5	70	140	1	
ATV212HD11M3X	10	10	200	2	200	2	12	2.3	60	140	1	
ATV212HD15M3X	10	10	200	2	200	2	12	2.0	50	140	1	
ATV212HD18M3X	30	30	200	2	200	2	8	2.0	50	140	1	
ATV212HD22M3X	30	30	200	2	200	2	8	1.8	50	140	1	
ATV212HD30M3X	30	30	200	2	200	2	8	1.8	50	140	1	
ATV212H075N4	10	10	400	6	400	6	12	5.8	80	140	0	
ATV212HU15N4	10	10	400	6	400	6	12	4.3	70	140	0	
ATV212HU22N4	10	10	400	5	400	5	12	4.1	70	140	0	
ATV212HU30N4	10	10	400	5	400	5	12	3.7	70	140	0	
ATV212HU40N4	10	10	400	5	400	5	12	3.4	70	140	1	
ATV212HU55N4	10	10	400	4	400	4	12	2.6	70	140	1	
ATV212HU75N4	10	10	400	3	400	3	12	2.3	70	140	1	
ATV212HD11N4	10	10	400	2	400	2	12	2.2	60	140	1	
ATV212HD15N4	10	10	400	2	400	2	12	1.9	50	140	1	
ATV212HD18N4	30	30	400	2	400	2	8	1.9	50	140	1	
ATV212HD22N4S	30	30	400	2	400	2	6	1.8	50	140	1	
ATV212HD22N4	30	30	400	2	400	2	8	1.8	50	140	1	
ATV212HD30N4	30	30	400	2	400	2	8	1.8	50	140	1	
ATV212HD37N4	30	30	400	2	400	2	8	1.8	50	140	2	
ATV212HD45N4	30	30	400	2	400	2	8	1.7	50	140	2	
ATV212HD55N4	30	30	400	2	400	2	8	1.6	40	140	2	
ATV212HD75N4	30	30	400	2	400	2	8	1.5	40	140	2	

F601

%

%

rpm

Parameter values that vary According to drive rating and reset type

The table below lists lists the parameters whose values, after a reset, depend on the drive model and the reset determine the value of a parameter after a reset:

- 1. Locate the drive model number in the first column.
- 2. Read across the row to the group of columns that corresponds to the reset type ([Parameter reset] $(L \ \Box P)$ =
- 1, [Parameter reset] $(L \ \ P) = 2$, or [Parameter reset] $(L \ \ P) = 3$).
- 3. Locate the parameter code in the columns corresponding to the reset type.

The number that appears at the intersection of the drive model number and the parameter code is the parameter's value after a reset of the specified type.

Factory reset L YP = 3 50 Hz reset *L Y P* = 1 60 Hz reset *L Y P* = 2 Reference tHr F173 F185 F601 tHr F173 F185 F415 F416 F417 F601 tHr F173 F185 F415 F416 F417 % % % % % % % А % % % % % А rpm ATV212H075M3X ATV212HU15M3X 6.1 5.8 ATV212HU22M3X 12.5 ATV212HU30M3X 12.4 ATV212HU40M3X 15.8 15.2 ATV212HU55M3X 20.6 22.0 ATV212HU75M3X 26.3 28.0 ATV212HD11M3X 36.9 36.0 ATV212HD15M3X 49.5 48.0 ATV212HD18M3X 61.0 61.0 ATV212HD22M3X 68.0 68.0 ATV212HD30M3X 93.0 93.0 ATV212H075N4 2.0 1.5 ATV212HU15N4 3.5 2.9 ATV212HU22N4 5.1 4.0 ATV212HU30N4 6.2

Parameters whose values after a reset are drive model and reset type dependant

ATV212HU40N4

ATV212HU55N4

ATV212HU75N4

ATV212HD11N4

ATV212HD15N4

ATV212HD18N4

ATV212HD22N4S

ATV212HD22N4

ATV212HD30N4

ATV212HD37N4

ATV212HD45N4

ATV212HD55N4

ATV212HD75N4

11.9

15.2

21.3

28.6

35.1

41.7

41.7

55.0

11.0

14.0

21.0

27.0

35.1

41.7

41.7

55.0

Parameter values that do not change if reset

The parameters listed in the table below cannot be reset. The table lists the default settings of these parameters.

Parameters whose values do not change if a reset is performed

Parameter	Description	Default Value
FΠ	[AO scaling]	-
FNSL	[AO funct. selection]	0
F 109	[VIA selection]	0
F 4 7 D	[VIA bias]	128
F 4 7 1	[VIA gain]	148
F 4 7 2	[VIB bias]	128
F 4 7 3	[VIB gain]	148
F 8 8 0	[Free ID parameter]	0

User Settings Tables

Use the Configuration Setting Table to look up parameter default settings, to record customized parameter settings, and to look up sections of the manual, by page number, that contain detailed parameter descriptions.

Configuration Setting Table

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
F C	<u>87</u>	[Local speed ref.]	Hz	-	[Low limit frequency] (L L) to [Upper limit freq] (UL)	0.0	
				٥	[Disabled]		
AU I	<u>95</u>	[Auto ramp]	-	1	[Enable]	1	
			-	2	[ACC only]		
				0	[Factory set]		
			-	1	[Run permissive]		
A U Y	<u>67</u>	[Auto set function]	-	2	[3-wire]	0	
			-	Э	[+/- Speed]		
			-	Ч	[4-20mA speed ref]		
				۵	[Logic inputs]		
6003	<u>87</u>	[Command mode sel]	-	1	[HMI]	0	
			-	2	[Communication]		
				1	[Ref source VIA]		
		Z [Ref source VIB] Image: Constraint of the set of t	2	[Ref source VIB]			
FNDd	<u>87</u>		[HMI reference]	1			
			4 [S	[Serial com ref.]			
			-	5	[+/- Speed]		
			Image: Description [Motor frequency] Image: Image: Description [Motor current] Image: Description Image: Description Image: Description Image: Description<	۵	[Motor frequency]		
				1	[Motor current]		
				2	[Speed ref]		
				[DC bus U]			
		4 [Motor U] 5 [Input power] 6 [Output power] 7 [motor torque]	[Motor U]				
			[Input power]				
			[Output power]				
			[motor torque]				
			-	8	[Torque I]	1	
6 0 6 1	110	9 [Motor thermal]	[Motor thermal]	0			
FIISL	110	[AO lunct. selection]	_	10	[Drive thermal]	0	
			-	11	[Do not use]		
			-	12	[Internal reference]		
			-	13	[VIA]		
			-	14	[VIB]		
				15	[Fixed 100%]	1	
				16	[Fixed 50%]	1	
				17	[Fixed 100%]	1	
				18	[Com data]	-	
				19	[Do not use]	7	
FΠ	<u>118</u>	[AO scaling]	-	_	-	-	

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
				٥	[No action]	J	J
				1	[50 Hz reset]		
				2	[60 Hz reset]		
				3	[Factory set]	_	
ĿУP	<u>66</u>	[Parameter reset]	-	4	[I rip cleared]	0	-
				5	[Cumul time clear]	_	
				7	[Save parameters]		
				8	[Recall parameters]	_	
				9	[Elapse time reset]	-	
				0	[Run FW]		
Er	87	[local mot_direction]	_	- 1	[Run rev.]	0	
	<u></u>			2	[Run FW+rev]		
				3	[Run rev+FW]	Madal	
A C C	<u>93</u> <u>163</u>	[Acceleration time 1]	s	_	0.0 – 3200	depen- dent	
d E C	<u>93</u> <u>162</u>	[Deceleration time 1]	s	-	0.0 – 3200	depen- dent	
F H	<u>92</u> <u>162</u>	[Max frequency]	Hz	-	30.0 – 400.0	50.0	
UL	<u>92</u> <u>161</u>	[Upper limit freq]	Hz	-	0.5 – [Max frequency] (F H)	50.0	
LL	<u>92</u> <u>161</u>	[Low limit frequency]	Hz	-	0.0 – [Upper limit freq] (<i>U L</i>)	0.0	
υL	<u>74</u> <u>161</u>	[Motor rated freq.]	Hz	_	25.0 – 200.00	50.0	
uLu ,		[Motor Rated Voltage]	v	230 V	50 – 330	230	
	<u>74</u>						
	160			460 V	50 – 660	400	
				1	[Variable Torque]	_	
				2	[Cst V/Hz+Boost]	_	
PE	7 <u>1</u>	[Mot cont. mode sel.]	-	Э	[SVC]	1	
	02			4	[Economy]		
				5	[Do not use]		
				6	[PM control]		
υb	<u>73</u>	[Motor Voltage Boost]	%	_	0.0 – 30.0	Model depen- dent	
EHr	<u>74</u>	[Motor thermal prot.]	%/A	_	10 – 100% of drive's output current rating	100%	
				0 1	[Std mot. protect.] [Std & stall mot. prot]		
				2	[Self cool]		
оги	146	[Motor overload prot]	-	3	[Slf cool stall ov.load]	0	
				4	[Forced cool prot]	_	
				5		-	
				7	[F cool & stall ov load]	-	
5-1	<u>123</u>	[Preset speed 1]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (U L)	15	
5 - 2	<u>123</u>	[Preset speed 2]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (U L)	20	
5 r 3	<u>123</u>	[Preset speed 3]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (UL)	25	
5r4	<u>123</u>	[Preset speed 4]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (UL)	30	
5 r 5	<u>123</u>	[Preset speed 5]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (UL)	35	
5 r 6	<u>123</u>	[Preset speed 6]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (UL)	40	
5 r 7	<u>123</u>	[Preset speed 7]	Hz	1	[Low limit frequency] (L L) to [Upper limit freq] (UL)	45	
F 100	<u>125</u>	[Freq. 1 reached]	Hz	-	0.0 to [Max frequency] (F H)	0.0	

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
F 10 1	<u>125</u>	[Freq. 2 reached]	Hz	-	0.0 to [Max frequency] (F H)	0.0	
F 102	<u>125</u>	[Freq.2 bandw.]	Hz	-	0.0 to [Max frequency] (F H)	2.5	
F 108	<u>122</u>	[Logic Funct 1 active]	-	0 – 73	See table on page 101	0	
				0	Al	_	
F 109	<u>100</u>	[VIA selection]	-	1	LI sink	0	
5	122	[Logic Funct 2 active]	_	2 0 - 73	Li source See table page 191	1	
F 1 10	100			0 - 73	See table page 194	2	
F 1 1 1	100			0 - 72	See table page 194	6	
r 1 12	100		-	0 72	See table page 194	10	
r 1 13	100		_	0 72	See table page 194	7	
F 1 18	100		_	0 - 73 0 - 61		,	
F 130	<u>119</u>	[RY Relay Function 1]	-	254, 255	See table page <u>194</u>	4	
F 132	<u>120</u>	[FL Relay Function]	-	0 – 61, 254, 255	See table page <u>194</u>	11	
F 137	<u>124</u>	[RY Relay Function 2]	-	0 – 61, 254, 255	See table page <u>194</u>	255	
F 139	124	(RY logic select]	_	0	Function 1and 2	0	
	12-1			1	Function 1 or 2	•	
F 146	<u>119</u>	[RY delay]	S	-	0.0 – 60.0 s	0.0	
F 147	<u>120</u>	[FL Relay delay]	S	-	0.0 – 60.0 s	0.0	
F 160	<u>116</u>	[VIA rel thresh. logic]	%	-	0 – 100	0	
F 16 I	<u>116</u>	[VIA threshold hyst.]	%	-	0 – 20	3	
F 162	<u>116</u>	[VIB rel thresh. logic]	%	-	0 – 100	0	
F 163	<u>116</u>	[VIB threshold hyst.]	%	-	0 – 20	3	
F 16 7	<u>126</u>	[Freq band det range]	Hz	-	0.0 to [Max frequency] (F H)	2.5	
םרו F	<u>79</u>	[Mot 2 rated Freq.]	Hz	-	25.0 to 200.0	50.0	
FITI	<u>79</u>	[Motor 2 rated Volt]	v	230V model 460V	50 to 330	230	
				model	50 to 660	400	
F דרו	<u>79</u>	[Motor 2 Volt Boost]	%	-	0 – 30	Model depen- dant	
F 173	<u>79</u>	[Motor 2 Overload]	%/A	-	10 – 100% of drive rating	100	
F 185	<u>79</u>	[Mot. 2 current limit]	%/A	-	10 – 110%	110	
F 2 N N	118	[Auto/man speed ref]	_	٥	[Enable]	0	
				1	[Disable]		
F 2 O I	<u>116</u>	[VIA ref point 1]	%	-	0 – 100	0	
F 2 O 2	<u>116</u>	[VIA freq. point 1]	Hz	-	0.0 – 200.0	0.0	
F 2 O 3	<u>116</u>	[VIA freq. point 2]	%		0 – 100	100	
F 2 0 4	<u>116</u>	[VIA freq. point 2]	Hz		0.0 – 200.0	50.0	
				2			
F207	<u>88</u>	[Remote spd ref 2]	-	3	[HMI]	2	
				5	[Communication] [+/- Speed]		
F 2 10	<u>116</u>	[VIB ref. point 1]	%	-	0 - 100	0	
F 2 I I	<u>116</u>	[VIB freq. point 1]	Hz		0.0 – 200.0	0.0	
F 2 1 2	<u>116</u>	[VIB ref. point 2]	%		0 – 100	100	
F 2 1 3	<u>116</u>	[VIB freq. point 2]	Hz		0.0 – 200.0	50.0	
F 2 4 0	<u>92</u>	[Mot start freq.]	Hz	-	0.5 – 10.0	0.5	
F 2 4 1	<u>154</u>	[Freq. pedestal]	Hz	-	0.0 – [Max frequency] (F H)	0.0	<u> </u>

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
F 2 4 2	<u>154</u>	[Freq. pedestal hyst.]	Hz	-	0.0 – [Max frequency] (F H)	0.0	
F 2 5 0	<u>98</u>	[DC brake start freq.]	Hz	-	0.0 – [Max frequency] (F H)	0.0	
F 2 5 1	<u>98</u>	[DC braking current]	%/A	-	0 – 100%	50	
F 2 5 2	<u>98</u>	[DC braking time]	S	-	0.0 – 20.0	1.0	
E 2 5 6	88	[Time limit low and]	s	۵	[Disable]	0.0	
F C 3 0	00		3	1	[Enable]	0.0	
F 2 6 4	<u>124</u>	[+speed LI resp time]	S	-	0.0 – 10.0	0.1	
F265	<u>124</u>	[+speed freq. step]	Hz	-	0.0 – [Max frequency] (F H)	0.1	
F266	<u>124</u>	[- speed LI resp time]	S	-	0.0 – 10.0	0.1	
F 2 6 7	<u>124</u>	[- speed freq. step]	Hz	-	0.0 – [Max frequency] (F H)	0.1	
F268	<u>124</u>	[Init +/- Speed]	Hz	-	0.0 – [Max frequency] (F H)	0.0	
F 2 6 9	<u>124</u>	[Init +/- Speed memo]	-	0	[Disable]	1	
E 2 1 N	97	[lump frequency 1]	Hz		0.0 - [Max frequency] (EH)	0.0	
	97	[lump handwidth 1]	Hz	_	0.0 - 30.0	0.0	
	<u>97</u> 07	[Jump frequency 2]	Hz	_	0.0 - Max frequencyl (EH)	0.0	
	07	[Jump handwidth 2]	Hz			0.0	
<i>FE</i> 13	<u>97</u> 07			-		0.0	
F E 1 7	<u>97</u>	[Jump headwidth 2]		-		0.0	
F 2 15	97	[Jump bandwidth 3]		-		50.0	
F 2 9 4	<u>89</u>	[Forcea speed freq.]	пг	-	[Low limit frequency] (L L) – [Upper limit freq] (U L)	50.0	
F 2 9 5	<u>88</u>	[Switch rem/Local]	-		[No bumpless]	1	
F 3 0 0	<u>95</u>	[Switch. freq. level]	kHz	-	6.0 – 16.0	Model depen- dent	
	<u>137</u>	[Catch on fly]	-	۵	[Disable]	3	
5 3 7 1				1	[Brief power loss]		
1 30 1				3	[Power loss, run]		
				Ч	[Each start]		
e a n a	<u>138</u>	[Supply loss behav.]	-		[Disabled]	0	
F 302				2	[Freewheel]		
5 3 7 3	<u>135</u>	[Number auto reset]	_	٥	[Disabled]	0	
	<u>169</u>			1-10	[Number of fault reset attempts]		
		[Overvoltage fault]	-		[Enable]	2	
F 3 0 5	<u>139</u>			2	[Quick deceleration]		
				Э	[Dyn. deceleration]		
		[Mot volt limitation]	-	0	[Motor volt limit]	3	
FJD7	<u>78</u>			2	[No action]		
				Э	[U Line correction]	-	
6 3 1 1	<u>96</u> 160	[Motor direction]	-		[Fw & Rev.]	1	
F 3 I I				2	[Rev. only]		
E 3 12	96	[Noise reduction]	-	٥	[Disable]	0	
	<u></u>	L'inclue readonnil		1	[Enable]		
F 3 16	<u>96</u>	[Switch. freq. mode]	-		[Auto]	1	
				2	[460 V fixed]		
				Э	[460 V Auto]		
F 3 2 0	<u>156</u>	[Load gain]	%	-	0 - 100	U	
F 3 2 3	<u>156</u>	[Load gain offset]	%	-	0 – 100	10	
F 3 2 4	<u>160</u>	[Driving Scroll]	-	 	[Yes]	0	
L						1	1

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
F 3 2 5	<u>170</u>	[Pre-start Scroll]	-		[No] [Yes]	0	
F 3 2 6	<u>170</u>	[Pre-Start time]	S	-	0 - 6000	10	
F327	<u>171</u>	[Pre-Start speed]	Hz	-	0.0 – [Upper limit freq] (<i>U L</i>)	50	
F 3 2 8	<u>171</u>	[LL speed time]	s	-	0 – 10	2	
F 3 2 9	<u>171</u>	[Pre-start delay]	s	-	0 – 120	3	
F 3 3 0	<u>172</u>	[Std Oiling Cycle]	-	0 1	[No] [Yes]	0	
F 3 3 1	<u>172</u> 173	[Std Oiling Speed]	Hz	-	0.0 – [Upper limit freq] (<i>U L</i>)	70	
F 3 3 2	<u>172</u>	[Std Oiling Time]	s		0 – 6000	30	
F 3 3 3	<u>172</u>	[Std Oil. Cycle Frq.]		Hours	0 – 24	24	
F 3 3 4	<u>173</u>	[Low Speed Oiling]	-	0	[No]	0	
F 3 3 5	173	[LL Speed for Oiling]	Hz	-	0.0 – [Upper limit freq] (<i>UL</i>)	50	
F 3 3 6	173	[LLS Time for Oiling]	mn	-	0.0 - 360	60	
FBBT	173	[Oiling Time at LLS]	S	-	0.0 - 6000	30	
				٥	[No]		
F33B	<u>174</u>	[Scroll Protection]	-	1	[Yes]	0	
F 3 3 9	<u>174</u>	[Cavitation Frq.]	Hz	-	[Low limit frequency] $(L L) - [Upper limit freq] (UL)$	30	
				٥	[No]		
F 3 4 9	<u>175</u>	[Discharge gas]	-	ו ק		0	
F 3 5 0	175	[High Thd]	%	-	0 - 100	65	
F 3 5 1	175	[Cooling Frg.]	Hz	-	[Low limit frequency] $(L L) = [Upper limit freq] (UL)$	50	
F 3 5 2	175	[Cooling Time]	mn	-	0 - 30	3	
F 3 5 3	175	[High high Thd]	%	-	0 – 100	70	
F 3 5 4	<u>175</u>	[Re-Start Delay]	mn	-	0 - 30	5	
C 7 C C	176	[Crankagaa baating]		۵	[No]	0	
	170		-	1	[Yes]	0	
F 3 5 9	<u>121</u>	[PID ctrl wait time]	S	-	0 – 2400	0	
<u> Е Э Б П</u>	120	[PID control enable]	_		[No PID] [PID by VIA]	0	
	120			2	[PID by VIB]	_	
F 362	<u>120</u>	[PID Prop Gain]	-	-	0.01 – 100.0	0.30	
F 3 6 3	<u>120</u>	[PID Integral Gain]	-	-	0.01 – 100.0	0.20	
F 366	<u>121</u>	[PID Derivative Gain]	-	-	0.00 - 2.55	0.00	
F 380	<u>121</u>	[PID reverse error]	-		[No] [Yes]	0	
F 3 9 I	<u>122</u>	[Stop on LL hyst]	Hz	-	0.0 – [Max frequency] (F H)	0.2	
F 3 9 2	<u>122</u>	[PID wake up (thres)]	Hz	-	0.0 – [Max frequency] (F H)	0.0	
F 3 9 3	<u>122</u>	[PID wake up, feedb]	Hz	-	0.0 – [Max frequency] (F H)	0.0	
				۵	[Disabled]	_	
	76			1 2	[Initialize constant]	_	
F 4 0 0	<u>165</u>	[Auto-tuning drive]	-	3	[Tun Dyn.]	0	
				4	[Tun Prst 1]	_	
	79			2			
F 4 0 1	<u>162</u>	[Slip Compensation]	%	-	0 – 150	50	
FUND	<u>79</u>		%	_	0.0 - 30.0	Model	
, , , , , , , , , , , , , , , , , , , ,	<u>162</u>		/0			dent	

Code	Page	Name	Unit		Adjustment Range / Function	Factory	User
						Model	Setting
EYNS	82	[Motor rated freg]	kW	-	0 01 – 75	depen-	
	<u></u>	[Motor rated ried.]				dent	
	74					Model	
F415	<u>74</u> 161	[Motor rated current]	Α	-	0.1 – 200.0	depen-	
						dent	
	74	[Mot no-load current]	%		10.0 100.0	Model	
F 7 16	<u>74</u>			-	10.0 – 100.0	depen-	
						Model	
FHIT	<u>74</u>	[Motor rated speed]	rpm	-	100 – 15000	depen-	
	101					dent	
FYIB	<u>80</u>	[Frequency loop gain]	-	-	1 – 150	40	
	<u>166</u>	[····]					
F419	<u>80</u>	[Freq. loop stability]	-	-	1 – 100	20	
	166					Madal	
e u a n	<u>85</u>	ITorque Boost Coeff	%	-	0 – 200	depen-	
1 120	<u>166</u>	[Torque Boost Coer]	70		0 - 200	dent	
F 4 5 8	<u>165</u>	[Current loop gain]	Hz	_	0 – 100	0	
FYTO	117	[VIA bias]	-	-	0 – 255	128	
FYJ	117		-	_	0 - 255	148	
	117			_	0 255	128	
F 7 1E	117		_	-	0 - 255	120	
F413	<u>117</u>	[VIB gain]	-	-	0 – 255	148	
F480	<u>77</u>	[No load cur. coef]	-	-	100 – 130	100	
F 4 8 1	<u>144</u>	[In noise comp. filter]	μS	-	0 – 9999	0	
F482	<u>144</u>	[In noise Inhibit filter]	μS	-	0 – 9999	442	
F 4 8 3	<u>144</u>	[In noise inhibit gain]	-	-	0.0 – 300.0	100.0	
F 4 8 4	<u>144</u>	[Pwr supply adj. gain]	-	-	0.0 to 2.0	0.0	
F 4 8 5	<u>77</u>	[Stall control coef. 1]	-	-	10 – 250	100	
F492	77	[Stall control coef. 2]	-	-	50 – 150	100	
						Model	
F 4 9 4	77	[Mot. adj coefficient]	-	-	DO NOT ADJUST	depen-	
						dant	
F 4 9 5	<u>77</u>	[Motor voltage coef]	%	-	90 - 120	104	
	<u>166</u>	[,				
F496	<u>77</u>	[PWM adj. coef.]	kHz	-	0.1 – 14.0	14.0	
F 5 0 0	<u>93</u>	[Acceleration time 2]	S	1	0.0 – 3200	20.0	
F 5 0 1	<u>93</u>	[Deceleration time 2]	S	1	0.0 – 3200	20.0	
		[Acc/dec 1 pattern]	-	۵	[Linear]	0	
F 5 0 2	<u>94</u>				[S-ramp 1]		
				2	[S-ramp 2]		
F 5 0 3	94	[Acc/dec 2 pattern]	cc/dec 2 pattern] - / [S-pattern 1] 2 [S-pattern 2]		[S-pattern 1]	0	
				[S-pattern 2]			
FSD4	95	[Ramp switching]	-	1	[Ramp 1]	1	
			<u> </u>	2	[Ramp 2]	0.0	
+505	<u>95</u>	[Commut. ramp freq.]	HZ	-		0.0	
F 5 0 6	<u>94</u>	[Acc/Dec S-pat start]	%	-	0 – 50	10	
F 5 0 7	<u>94</u>	[Acc/Dec S-pat end]	-	-	0 – 50	10	
F 5 8 D	<u>128</u>	[Damper fdb type]	-	٥	[No feedback]		
				1	[LIH set]	0	
				2	[LIL Set]		
				3 U			
					Loom ric ood	1	

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
F 5 8 /	<u>128</u>	[Time open Damper]	-	-	0.05 to 300.00 s	60.00	
F 5 8 2	<u>128</u>	[Time close Damper]	-	-	0.05 to 300.00 s	60.00	
				۵	[No fault]		
F 5 8 3	<u>128</u>	[Damper flt behavior]	-	1	[Freewheel stop]	1	
				2	[Ramp stop]		
F 6 0 I	<u>73</u> <u>161</u>	[Motor Current Limit]	%/A	-	10 – 110%	110%	
F 6 0 2	<u>138</u>	[Drive fault memory]	-	0	[Cleared]	0	
				<u>,</u> П	[Retained]		
F 6 0 3	<u>126</u>	[Ext. fault stop Mode]	-		[Ramp stop]	0	
				2	[DC braking]		
F 6 0 4	<u>126</u>	[DC brk time ext flt]	S	-	0.0 – 20.0	1.0	
				0	[Disabled]		
				ו ב	[First start] [Fach start]		
F605	<u>140</u>	[Output phase loss]	-	3	[During run]	3	
				Ч	[Permanent]		
				5	[Catch on fly]		
F607	<u>74</u>	[Mot overload time]	S	-	10 – 2400	300	
F 6 0 8	<u>138</u>	[Input phase loss]	-		[Disable]	1	
	1/1	[Underload band]	0/2			10	
r 8 U 3	141		70	-		10	
F6 10	<u>141</u>	[Underload det.]	-		[Fault]	0	
F 6	<u>141</u>	[Underload level]	%/A	-	0 – 100%	0	
F6 12	141	[Underload det. time]	S	-	0 – 255	0	
				0	[Each time (std)]		
E E E I H	142	[Short circuit det]	_	I	[One time (std)]	0	
	174	[Onore circuit det.]		2	[Each time (short)]		
				<u> </u>			
F6 /5	<u>143</u>	[Overtorque det.]	-		[Fault]	0	
F6 16	<u>143</u>	[Overtorque level]	%	-	0 – 250	130	
F6 18	<u>143</u>	[OvTorque det time]	S	-	0.0 – 10.0	0.5	
F6 19	143	[Overtorque band]	%	-	0 – 100%	10	
F621	130	IRun time alarm	h	-	0.0 – 999.9 (0.1 = 1 hour. 100 = 1000 hours)	610.0	
E 6 2 6	139	Overvoltage level	%	1	[100 – 150% of nominal DC bus voltage]	140	
	100			0	[Alarm (0.6U)]		
F627	<u>138</u>	[Undervolt detect.]	-	1	[Fault (0.6U)]	0	
				2	[Alarm (0.5U)]		
F632	<u>137</u>	[Mot overload memo]	-			0	
		n () ((A)	0/	0	[Disabled]		
F 6 3 3	<u>141</u>	[Loss of VIA]	%	1-100	[Fault detection level]	0	
				1	[-10 to 10°C]		
				د ع	[11 to 20°C]		
F634	<u>144</u>	[Amb. temp. alarm]	-		[31 to 40°C]	3	
				5	[41 to 50°C]		
				6	[51 to 60°C]		
				<u> </u>	[NO] [Freewheel]		
F 6 4 4	<u>142</u>	[4-20 mA loss]	-	2	[Set speed]	0	
	_			3	[Keep speed]		
				4	[Ramp stop]		
FR45	122	[Mot PTC selection]	_	<u> </u>	[Disabled] [Enabled fault]	0	
	<u></u>	, the concentration		2	[Enabled alarm]		
Code	Page	Name	Unit	Adjustment Range / Function		Factory Setting	User Setting
---------	------------	------------------------	------	-----------------------------	------------------------------	--------------------	-----------------
F 6 4 6	<u>122</u>	[PTC resistor value]	Ω	-	100 – 9999	3000	
F649	<u>142</u>	[4-20mA fallback sp]	Hz	-	0 – [Max frequency] (F H) Hz	0	
				0	[Disable]		
F650	<u>89</u>	[Forced fire control]	-	I.	[Enable forward]	0	
				2	[Enable Reverse]		
				0	[Enable transition "0->1"]		
F659	<u>89</u>	[Forced fire function]	-	1		0	
				-			
F691	<u>119</u>	[AO slope]	-		[Positive slope]	1	
F692	<u>119</u>	[Analog output bias]	%	-	0 - 100%	0	
F 6 9 4	<u>119</u>	[Freq. for AO = 0V]	Hz	-	0 – [Max frequency] (F H) Hz	0	
F 6 9 5	<u>119</u>	[Freq. for AO = 10V]	Hz	-	0 – [Max frequency] (F H) Hz	0	
5 7 0 0	68	[Parameter lock]		0	[Unlocked]	0	
- 100	00		-	- 1	[Locked]	0	
וסרז	130	[Unit value selection]	-	0	[%]	1	
				1	[Amp or Volt]		
6 7 8 7	101	Customized frequell		0.01	Frequency displayed in Hz	0	
FIUE	<u>131</u>		-	200.0	Conversion factor	U	
	404	(F		0	[All]	0	
FIUJ	<u>131</u>	[Frequency convert.]	-	- 1	[PID only]	0	
E 7 0 5	131	[Custom freq_slope]	_	۵	[Negative slope]	1	
	101			1	[Positive slope]		
F 706	<u>131</u>	[Customize unit bias]	Hz	-	0.00 – [Max frequency] (F H)	0.00	
FIDI	<u>87</u>	[Loc. speed ref. step]	Hz		[Disable]	0.00	
				0	Disabled – 0.1 Hz steps		
F 708	<u>130</u>	[Display ref. resol.]	-	1 – 255	See formula on page 130	0	
				0	[Motor frequency]		
				- 1	[Reference]		
				2	[I Mot]		
				3	[Drive rated I]	_	
6 7 10	120	[Displayed percent]		4	[Drive therm state]	0	
F 1 10	130		-	5	[Int speed ref]	U	
				7	[Com data]	_	
				8	[Motor speed]		
				9	[Com count]		
				10	[Com count norm st.]		
FIZI	<u>88</u>	[Loc. mot stop mode]	-	0	[Ramp stop]	0	
				, П			
F 7 3 0	<u>90</u>	[Up/down key ref]	-	1	[Disable]	0	
				0	[Permitted memo]		
F 7 3 2	<u>90</u>	[Loc/rem key]	-	- 1	[Prohibited]	0	
				2	[Permitted no memo]		
F 7 3 3	<u>90</u>	[Run/stop key]	-	U		0	
				, П			
F 7 3 4	<u>90</u>	[Priority stop]	-	1	[Disable]	0	
6735	00	[HMI reset butten]	_	0	[Disable]	1	
- 135	<u>90</u>		-	1	[Enable]		
F 7 3 8	68	[Quick menu AUF]	-	0	[AUF displayed]	0	
		- · · ·		1		Model	
FJYR	130	[Power cons, memo]	-	0	[Disable]	depen-	
	<u> </u>			1	[Enable]	dant	

Code	Page	Name	Unit	Adjustment Range / Function		Factory Setting	User Setting
				٥	[1 kWh]	Model	
F 7 4 9	<u>131</u>	[Power cons. unit]	kWh	1	[0.1 kWh]	depen-	
						dant	
	4.40			0	[9600 bps]	4	
F 8 U U	<u>148</u>	[Mdb RJ45 baud]	-	1	[19200 bps]	1	
				۵	[No]		
FBDI	<u>148</u>	[Mdb RJ45 parity]	-	1	[Even]	1	
6003	1/10	[Modbus address]	_	-	0 247	1	
FBUE	140			-	0 – 247	1	
F803	<u>149</u>	[Com. time out]	s	1-100	1 to 100 seconds	3	
					[RJ45]		
FBDT	<u>149</u>	[Com channel choice]	-	1	[Open style]	1	
EB2D	149	[Mdb network baud]	-	٥	[9600]	1	
		[1	[19200]		
FRZI	149	[Mdb network parity]	s	<u> </u>		1	
1 02 1	140		Ŭ	2	[Odd]	-	
				1	[Mdb RTU]		
				2	[Metasys N2]	-	
F829	<u>149</u>	[Network protocol]	-	3	[Apogee P1]	-	
				9		-	
				0	[Ramp stp (F/Cmod)]		
				1	[No active]		
F851	<u>149</u>	[Com. fault setting]	-	2	[Ramp stop]	4	
				3	[Freewheel]	-	
				4			
				2	[4 poles]	-	
				Э	[6 poles]	-	
FBS6	150	[Mot. poles (comm.)]	-	Ч	[8 poles]	2	
				5	[10 poles]	-	
					[12 poles]	-	
				8	[16 poles]		
				۵	[No select]		
				1	[Command word 1]	_	
6970	150	[Block write data 1]	_	2	[Command word 2]	0	
1010	150			4	[Relay command]	Ŭ	
				5	[FM command]	-	
				6	[Speed Setpoint]		
					[No select]	-	
				2	[Command word 1]	-	
FBTI	<u>150</u>	[Block write data 2]	-	3	[Frequency Setpoint]	0	
				Ч	[Relay command]	-	
				5	[FM command]	=	
				6	[Speed Setpoint]		
				1	[Command 1]	-	
				2	[Freq. out]	=	
				Э	[Motor current]		
				4	[Output volt]	-	
F875	<u>150</u>	[Block read data 1]	-	5	[PID feedback value]	0	
				7	[Input term. mon]	-	
				8	[Out term. mon]	1	
				9	[VIA monitor]	-	
				10	[VIB monitor]	-	
				11	[mor speed mon.]		

Code	Page	Name	Unit	Adjustment Range / Function		Factory Setting	User Setting
				۵	[No select]		
				1	[Command 1]	-	
				2	[Freq. out]	-	
				Э	[Motor current]		
				4	[Output volt]		
F 8 7 6	150	[Block read data 2]	-	5	[Alarm info]	0	
				6	[PID feedback value]	-	
					[Input term. mon]	-	
				-		-	
				10		-	
				11	[Mot speed mon.]	-	
				0	[No select]		
				1	[Status info]	-	
				2	[Freq. out]	-	
				Э	[Motor current]		
				Ч	[Output volt]	_	
FBJJ	151	[Block read data 3]	-	5	[Alarm info]	0	
				6	[PID feedback value]	-	
					[Input term, mon]	-	
				 		-	
					[VIB monitor]	-	
				11	[Mot speed mon.]	-	
				۵	[No select]		
				1	[Status info]	-	
				2	[Freq. out]		
				Э	[Motor current]		
				4	[Output volt]	-	
F 8 7 8	<u>151</u>	[Block read data 4]	-	5	[Alarm Info]	0	
				-		-	
				8		-	
				9	[VIA monitor]	-	
				10	[VIB monitor]	-	
				11	[Mot speed mon.]		
				٥	[No select]		
					[Status info]	-	
				2	[Freq. out]	-	
						-	
				5	[Alarm info]	-	
F879	<u>151</u>	[Block read data 5]	-	6	[PID feedback value]	0	
				٦	[Input term. mon]	-	
				8	[Out term. mon]	1	
				9	[VIA monitor]		
				10	[VIB monitor]	-	
	454		-	11		0	
	<u>151</u>	[Free ID parameter]	-	-	0 - 00000	U	
F890	<u>152</u>	[Network adress]	-	-	0 – 65535	(1)	
F891	<u>152</u>	[Network baud rate]	-	-	0 – 65535	(1)	
F892	<u>152</u>	[Network time out]	-	-	20 - 600	(1)	
F893	<u>152</u>	[Instance number H]		-	0 – 4194	(1)	
F 8 9 4	<u>152</u>	[Instance number L]	-	-	0 – 999	(1)	
F895	<u>152</u>	[Max master]	-	-	0 – 127	(1)	
F896	<u>152</u>	[Max info frames]	-	-	0 – 100	(1)	
F 9 12	<u>85</u>	[Autotune L q-axis]	-	-	0 - 650	10	
F 9 I 3	<u>85</u>	[Autotune L d-axis]	-	-	0 – 650	10	
Fqiy	86	[N-S direction]	_	۵	[0]	0	
	50			1	[1]	5	

Code	Page	Name	Unit		Adjustment Range / Function	Factory Setting	User Setting
				۵	[0]		
				1	[1]	3	
F915	<u>166</u>	[PM mode selection]	-	2	[2]		
				Э	[3]		
				Ч	[4]		
F 9 16	<u>85</u>	[PM Align cur. Level]	%	-	0 – 100	25	
E 9 1 7	F 9 / 7 86 [PM Max torq. Ctrl]	-	۵	[0]	1		
			1	[1]			
F918	<u>86</u>	[Cur. phase adjt]	-	-	-45 – 45.0	0.0	
F 9 2 0	<u>86</u>	[Position Adjust]	%	-	0 – 150	0	
F 9 2 1	<u>85</u>	[Init. Pos. Current]	%	-	10 – 150	0.0	
F936	<u>84</u>	[Saliency Level]	-	-	0 – 2.55	0	

(1) See table page <u>152</u>.

APPENDIX A to user's manual - title: "Filtering device UFO-A-N(/R)"



KLIMAWENT S.A. Poland

Chwaszczynska 194 street, 81-571 Gdynia phone: +48 58 629 64 80 fax: +48 58 629 64 19 e-mail: klimawent@klimawent.com.pl website: www.klimawent.com.pl

klimawent@klimawent.com.pl

Copyright © by KLIMAWENT S.A. Gdynia 2023-11-15



Filtering device UFO-A-N and UFO-A-N/R



EN

The appendix is valid for the following device models:

Catalog No.	Product name	
805U20	UFO-A-5000-N	
805U21	UFO-A-10000-N	
805U22	UFO-A-15000-N	
805U23	UFO-A-20000-N	
805U24	UFO-A-5000-N/R	
805U25	UFO-A-10000-N/R	
805U26	UFO-A-15000-N/R	
805U27	UFO-A-20000-N/R	



Sequencer E1T 4÷16 Output Channels



Use and Maintenance Instructions



Description	
Electrical Specifications	
Dimensions and Constrains	5
Warning symbols used in this manual	6
Installation regulations and warnings	6
Electrical wirings	
Terminals Table	9
Recommended cable cross-section	
Fuse Table & replacing	10
Jumper Configuration for Power Supply Input	
Jumper Configuration for Output Voltage	11
Display and pushbuttons	
Accessing the programming menu	
List of Parameters	
Description of the operations	
Operating Modes	15
Other functions	15
Hour Counters	
Inputs & Outputs	17
Alarms	18
Troubleshooting	19
Maintenance	20
Disposal	20
Warranty	20
Warranty Exclusions	20



Description

The E1T control unit is an electronic device designed to drive pneumatic cleaning of industrial dust collector systems.

The construction technology of the control unit allows to connect up to 16 solenoids valves.

The control unit is equipped with a powerful microcontroller that, thanks to an innovative software, makes the instrument easy to use even by inexperienced users.

The control unit control unit is equipped with a seven-segment display, through which the user can monitor the entire cleaning process and make the settings by means of a series of buttons placed on the front panel of the device.

Main features:

- 2 digital free-voltage contact inputs for remote control (Remote Enable & Fan Status);
- 2 Alarm relays (event programmable);
- 16 outputs for solenoid valve actuators;

Other features:

- 7 segment 3 digits 0,8" LED display;
- Power supply selectable in hardware for 115-230Vac 50/60Hz or 24Vac-24Vdc;
- Output voltage selectable in hardware and software for 24Vdc, 24Vac, 115Vac, 230Vac;
- Fully configurable cleaning cycle;
- Post cleaning function (PCC) when Fan is OFF, by detection on the "Fan Status" contact input;
- Total and partial hours counter for maintenance;
- Alarm for solenoid valve not operating;
- Alarm for maintenance of filter elements;
- Remote enabling of the Control unit by mean of "Remote Enable" contact input;
- Single solenoid actuator manual activation for system check;



E1T4-16 Control Unit

Electrical Specifications

Power Supply Voltage	115Vac 50/60 Hz ± 10 % 230Vac 50/60 Hz ± 10 % 24Vac 50/60 Hz ± 10 % (on request) 24Vdc ± 10 % (on request)
Power consumption	28 VA @ max Load (on request: 50VA)
Protection fuse	1AT (115Vac - 230Vac models) 3AT (24Vac / 24Vdc models)
Operating Temperature	-10°C ÷ 55°C
Storage Temperature	-20°C ÷ 60°C
Environmental Humidity	0 ÷ 95% Relative (Non Condensing)
Solenoid valve opening Pulse Time	50msec ÷ 9,99sec
Pause Time between solenoid solenoids activations	1sec ÷ 999sec
Output Voltage For Solenoid solenoids	115Vac 50/60 Hz 230Vac 50/60 Hz 24Vac 50/60 Hz 24Vdc
Digital inputs (Not galvanically isolated free-voltage input)	1x FAN OFF detection 1x REMOTE Enable
Digital outputs (free-voltage contacts)	2x SPST FORM A Relay contact
Display	3 digit 0,8" 7 segments LED display
Casing	Base = ABS Transparent cover = Polycarbonate
Protection Degree from water and dust	IP65 DIN EN 60529
Shock Resistance	IK08 (EN62262).
Weight	2,1 Kg

Use and maintenance instructions





Dimensions and Constrains





4-8 Outputs Enclosure Dimensions in mm



12-16 Outputs Enclosure Dimensions in mm



Warning symbols used in this manual

The safety-related indications are highlighted using the symbols:

	Attention - Danger	Warning - Generic
4	Risk – Danger	Electric Current
X	Dispose of in complian and electronic equip	nce with the electrical ment Standard WEEE

Installation regulations and warnings

• Protect the equipment from direct exposure to sunlight.	
• Do not position the equipment near or directly in contact with sources of heat or electromagnetic fields.	
• Fix the Control Unit at a height of at least 60 cm from the ground floor and in a clearly visible place that is easily accessible.	
 Connect the Control Unit to a power supply line other than those used for operati motors or other high-power devices, which could generate network interference c instability. 	ng ir
• The power supply must be protected by a 230Vac 30mA Residual Current Device RCD and a bipolar 230Vac 10A magnet circuit breaker, positioned in a place that is easily accessible.	S
 Before intervening on the equipment to perform any operation, deactivate the magnet circuit breaker switch and check if the environment conditions are safe. 	
• For electric operations, always remove voltage, wait 30 seconds for the internal capacitors to discharge before opening. At the end of the operations, close the equipment before powering up. Before intervening on the equipment to perform any operation, check the conditions of the atmosphere are safe.	4
• The PE (ground terminal/Earth) wire must be Yellow/Green, and it must be the firs to be connected. No other cables different than PE must be with its color.	t
• The terminal block must not be the mechanical anchorage point of the wires.	
 Sealing of the cable glands is guaranteed by the compression of the rubber gaske that tightens on the outer diameter of the cable. 	t 🔨
• The size of cable and cable gland must ensure that power cord traction is not action on the terminal.	ng

Use and maintenance instructions E1T4-16 Control Unit



 Any use not described in this user instruction manual or incorrect use of the device may cause damage to the Control Unit or to the equipment connected to it. Incorrect use or tampering with the equipment may cause injury. 	_ <u>^</u>
• The impermeability of the casing is guaranteed when the cover is closed.	
 Make sure that rigid or flexible ducts used for wiring, do not fill up with water or other liquids. 	Ń
• Switch OFF the power supply immediately if water is found in the casing.	
• Do not make unprotected holes in the container or holes that are protected by accessories with protection rating lower than that of the Control Unit.	
 If the Control Unit is used in ways not specified by the manufacturer, the protection provided by the device may be impaired. 	
 No part with dangerous voltage is normally accessible. 	
• The Control Unit does not release potentially toxic or harmful substances to the health and the environment.	



Do not use the control unit

if you have not read or do not understand this manual.



Electrical wirings

To connect the wires to the Control Unit, remove the lower front panel to access the terminal board, unscrewing the two screws.



Note: If the Control Unit is a +24Vdc power-supplied model, please connect:

Terminal 1	=	+24Vdc IN
Terminal 2	Ш	0Vdc IN
Terminal 3	Π	PE

Use and maintenance instructions

E1T4-16 Control Unit



Terminals Table

Ref.	Cat	Terminal	Marking	Description		
Main	^	1	L	115-230Vac 50/60Hz ±10%	24Vac 50/60Hz ±10%	
Power	A	2	Ν		24Vdc ±10%	
Supply	PE	3	PE	Protective ground terminal (Earl	th)	
				Contact type	1 Form A (1SPST NO)	
Dolay K1		Λ	1 ۸	Ratings	250Vac/30Vdc 5A	
	В	4 E	1A 1D	Max switching voltage	400Vac	
		L.	ID	Dielectric Strength	4000Vac (750Vac contacts)	
				Expected life	10M mechanical, 100K electrical	
				Contact type	1 Form A (1SPST NO)	
Dolov K2		G	2.4	Ratings	250Vac/30Vdc 5A	
Cutput(1)	В	0 7	2A 2B	Max switching voltage	400Vac	
		/	20	Dielectric Strength	4000Vac (750Vac contacts)	
				Expected life	10M mechanical, 100K electrical	
Fan		10		Mode	Free contact (limited to 5mA@5V)	
Status Input(²)	С	12	FANB	Insulation	2KVac main transformer	
Remote		14		Mode	Free contact (limited to 5mA@5V)	
Enable Input(²)	С	14	REMA	Insulation	2KVac main transformer	
Ground	PE	3	PE	Protective ground terminal (Earth)		
Solenoid		20	COM	Ratings	8A	
Common	D	50	COM	Max switching voltage	600VAC	
		31	EV1	Ratings	4A	
		32	EV2	Max switching voltage	600VAC	
Solenoid Valve Output	D	33 34 35 36 37 38 39 40 41 42 43 44 45 46	EV3 EV4 EV5 EV6 EV7 EV8 EV9 EV10 EV11 EV12 EV13 EV14 EV15 EV16			

Note (1): Free-voltage SPST contacts.

Note (²): Free-voltage contacts powered by the main-board. DO NOT provide voltages at these terminals.



DANGER

Risk of electric shock

The input and output terminals, numbered 12 to 15 are safety extra low voltage (SELV) terminals and must only be connected to low voltage circuits.



Recommended cable cross-section

Cat	Cable Cross-section	Approvals	Notes
А	0,75 mm2	IEC60227, IEC60245	No-Flame or flame-retardant cable
В	0,75 mm2	IEC60227, IEC60245	No-Flame or flame-retardant cable
С	0,50 mm2	IEC60227, IEC60245	No-Flame or flame-retardant cable
D	0,75 mm2	IEC60227, IEC60245	No-Flame or flame-retardant cable
PE	0,75 mm2	IEC60227, IEC60245	No-Flame or flame-retardant cable, Yellow/Green cable

Fuse Table & replacing

Voltage	Value
230 Vac	1AT 250V
115 Vac	1AT 250V
24Vac/dc	3AT 60V/250V



DANGER

Risk of electric shock

Before replacing the main Fuse on the board, you MUST remove the main power supply to avoid electrical shocks.

To replace the fuse:

- Remove the lower front panel;
- Unscrew the black fuse-holder cap;
- Remove the fuse cap with the fuse inside;
- Replace the fuse with a new one;
- Insert the fuse in the fuse cap;
- Insert the fuse cap into the fuse-holder;
- Screw the fuse-holder cap;
- Close the lower front panel;
- Power-on the Control Unit.

Use and maintenance instructions





Jumper Configuration for Power Supply Input



In the 24Vac and 24Vdc models JP1 and JP4 jumper are not used.

Jumper Configuration for Output Voltage



The output voltages 115Vac or 230Vac is not available in 24Vdc power input models.

http://www.turbocontrols.eu info@turbocontrols.it +39 0362 574024



Display and pushbuttons

A local user interface made of a large seven segment display and four pushbuttons is available on the Control Unit. The user interface shows the main functionalities and events during a cleaning process.

It is also useful to access to the programming parameters.

At power-on the Control Unit will show the software version mounted for few seconds and then it will be ready to be used.

The Pause Time countdown is the main information shown on display. It will be alternated with some other information like output pulsed and error codes.



The pushbuttons enable the user to perform some operations:

(SET)	Enable the user to access or exit the programming mode.
	Activate a single solenoid during manual test with the related function F06, available in programming mode.
(OK)	Save parameter's value modified during programming mode.
	Reset alarms in main screen.
	Increases the scroll of the parameters in programming mode.
(+)	Increases the value of a selected parameter during programming.
	Displays the total hours counter since the first power-on.
(-)	Decreases the scroll of the parameters in programming mode.
	Decreases the value of a selected parameter during programming.
	Displays the partial hours counter for maintenance.

Accessing the programming menu

Press (SET) pushbutton to access the programming mode. The blinking message "F02" will appear to indicate the first parameter available.

Press (+) or (-) pushbuttons to move at the required parameter.

Press (OK) pushbutton to access the value of the selected parameter.

Press (+) or (-) pushbuttons to change the value of the parameter.

Press (OK) to save the parameter's value.

Press (SET) pushbutton to exit the programming menu and return to the main screen.



Use and maintenance instructions

E1T4-16 Control Unit



List of Parameters

Function	Min Value	Max Value	default Value	
F02 Solenoid activation Time (seconds	0,05	5,00	0,20	
F03 Pause Time between solenoids ac	001 010 (F01=3)	999	20	
F04 Number of solenoids connected	01	16	01	
F05 Output voltage setting (Related to hardware jumpers)	D24= Out 24Vdc A24= Out 24Vac 115= Out 115Vac 230= Out 230Vac	d24	230	A24
F06 Manual Solenoid valve activation	1	F04	1	
F13 Amount of Post Cleaning cycles a	0	99	1	
F14 Pause Time between solenoids va Cleaning cycle (seconds)	1	999	10	
F15 Maintenance Time limit for warnir of hours	1	999	100	
F16 Maintenance Time limit warning (E11)	0=Disabled 1=Enabled	0	1	0
F17 Maintenance Hour counter Reset	0=No Reset 1=Reset Counter	0	1	0
F24 Exclusion of a solenoid in case of short circuit	0=Leave the solenoid 1=Skip the solenoid	0	1	0

Description of the operations

After showing the software version at power-on, the Control Unit shows the message "----", meaning that a diagnostic task is running to check the coherence between settings stored in the microcontroller memory and the hardware jumper's settings.

An error code will appear in case of discrepancies between settings (see Alarms list). Only editing functions will be allowed on the Control Unit. The operator may switch-off the device, check and configure the hardware jumpers in the right manner.

At the end of the diagnostic task, a "0_0" message will appear on the display to indicate that the test was successfully completed.

The Pause Time countdown will appear on the main screen.

A "OFF" message appears if the "Remote EN" contact input (terminals 14-15) is open.

A "-0-" message appears if the "FAN Status" contact input (terminals 12-13) is open when the Control Unit is in Manual mode.











Operating Modes

MANUAL Mode

The Control Unit works as a programmable cycle sequencer.

The solenoids connected at the control unit will be activated sequentially to perform a cleaning cycle, with the timing values configured in the related parameters. After the last activated solenoid valve, the cleaning cycle will continue restarting from the first solenoid valve.

Other functions

POST CLEANING CYCLE (PCC)

This function allows to perform a cleaning cycle after the fan was stopped (OFF state) by the user.

The PCC function is enabled if the value configured in "PCC cleaning cycles" was set with a value different from zero. This parameter determines how many PCC cycles will be performed.

If "Fan detection mode" parameter is set to 0, the PCC function will be performed only if the Fan Status Input contact (terminals 12-13) will be opened.

The PCC Pause Time is available to be set to perform a different Pause Time than in standard cleaning cycle. The Pulse Time (F02) is the same previously set for a standard cleaning cycle.

PCC handled by "FAN OFF" input contact

The number of the PCC to perform can be set with "PCC cleaning cycles" parameter. At the end of the last PCC, the Control Unit will stop all activities until the Fan Status Input contact will be detected as closed. Then, a new standard cleaning can start, if required.

If the Fan Input Contact is detected as closed while a PCC is in progress, a new standard cleaning cycle will be started at the end of PCC, if required.

Number of solenoids connected

The number of solenoids valves connected at the Control Unit can be set. The Control Unit will run the cleaning cycle in order from the first to the last solenoid valve programmed into the parameter. Parameters involved:

	F01	0 (MANUAL)	
	F02 Pulse Time		
F03 Pause Time		Pause Time	

Parameters involved:

F13	PCC cleaning cycles
F14	PCC Pause Time

Parameters involved:

F04 Number of solenoids





Hour Counters

After showing the software version at power-on, the Control Unit An hour counters information is available on the main screen.

The purpose is to show the total operating hours from the first power-on and the maintenance hours.

By pressing the (+) pushbutton the display will show the operating hours from the first power-on. The value can't be reset.

By pressing the (-) pushbutton the display will show the maintenance hours. The parameter F17 can be used to reset the maintenance hours.

The hours are shown on two screens.

The first screen shows the thousands of hours, the second screen shows the units of hours.

Example:

First screen count = 012 Second screen count = 345

Amount of hours = (012 x 1000) + 345 = 12345







Inputs & Outputs

Inputs	Terminals	Description	
Remote ENABLE contact	14-15	It Is used to place the Control Unit in Run or Stand-By mode. When the input contact is open, the Control Unit is placed in stand-By mode. No functions will be executed. When the input contact is closed, the Control Unit is placed in Run mode. All the functions will be executed when needed. The Control Unit is factory set with a wire jumper between the terminals to close the input	
FAN Status contact 12-13		It is used to send to the control unit the state of the fan (Running or Stopped). If the input contact is open, the control unit will detect the fan stopped and then run the Post Cleaning function. The control unit is factory set with a wire jumper between the terminals to close the input.	

Outputs	Terminals	Description
		The relay K1 is factory configured as normally closed contact and opens with multiple error events.
		The contact is also open when the control unit is not powered.
Alarm Relay K1	4-5	
		The alarms events set by default for the relay are:
		E06
		E08.
		Maintenance interval reached.
		The relay K2 is factory configured as normally closed contact and opens with multiple error events.
		The contact is also open when the control unit is not powered.
Alarm Relay K2	6-7	
		The alarms events set by default for the relay are:
		E06
		E08.
		Maintenance interval reached.



Alarms

The control Unit perform some diagnostic check at power-on and during operations.

An alarm event is shown by mean of "Exx" error code. The possible alarms and respective troubleshooting are listed in the below table:

Alarm Event	Description	Action
E01	F05 set to 24Vdc but AC jumper position detected	For 24Vdc, switch the device off and set the AC/DC jumpers to DC. For 24Vac, press OK, then press SET, set the function F05 using (+) and (-), select A24 and press OK to confirm.
E02	F05 set to 24Vac but DC jumper detected	For 24Vac, switch the device off and move the AC/DC jumpers to AC. For 24Vdc, press OK, then press SET, set the function F05 using (+) and (-), select d24 and press OK to confirm.
E03	F05 set to 24Vac or 24Vdc. Voltage Out of Range detected	To use 24V valves, switch the device off and move the output voltage selection jumper to 24V If the jumper is in the correct position, press OK, then SET, select the F05 function with (+) and (-), set 115 or 230 (as jumper) and press OK.
E04	F05 set to 115V. Voltage Out of Range detected	To use 115V valves, switch the device off and move the output voltage selection jumper to 115V If the jumper is in the correct position, press OK, then SET, select the F05 function with (+) and (-), set 115 or 230 (as jumper) and press OK.
E05	F05 set to 230V. Voltage Out of Range detected	To use 230V valves, switch the device off and move the output voltage selection jumper to 230V. If the jumper is in the correct position, press OK, then SET, select the F05 function with (+) and (-), set a24, d24 or 115 (as jumper) and press OK.
E06	Solenoid valve current lower than minimum threshold or disconnected solenoid valve. The error is displayed alternating with solenoid position Uxx failed.	Check correct connection of the solenoid valve and respective data. The alarm is auto-reset if event disappears.
E07	Solenoid valve current higher than maximum threshold. The error is displayed alternating with solenoid position Uxx failed.	Check correct connection of the solenoid valve and respective data. The alarm is auto-reset if event disappears.
E08	Short circuit alarm at output. The error is displayed alternating with solenoid position Uxx failed.	Switch the device off and back on after having checked the solenoid valve system.
E11	Maintenance deadline reached	Carry out maintenance and then reset the error.
E14	Indicates that a valve in short circuit has been excluded from the cycle. The error code E14 alternates with the indication of the failed output that is shown as "Uxx", where xx is the number of the output. An output is considered a short circuit if not responding for 3 following activations.	Switch the device off and back on after having checked the solenoid valve system.

ТИЯВО

Troubleshooting

Fault	Possible Cause	Solution
The display does not light up.	Fuse Blown. Power voltage missing.	Check the protection fuse on the power voltage. Check that the power voltage is provided at power supply terminals and compliant with that required for the device.
The outputs are not activated.	Output voltage. Wiring to solenoid valves.	Check that the solenoid valves output voltage is congruent with hardware jumper settings and programming. Check wiring between Control Unit and solenoid valves.
The cleaning cycle doesn't run	Remote Enable input is open	Check Remote Enable input contact.
Does the device occasionally reset?		Check that there are no unfiltered voltage spikes on the power line (spot welding machines, welding machines, plasma cutters etc.). Install a common-mode line filter between the Control Unit and the power line.
Does post-cleaning start during normal cleaning?	FAN OFF input is closed	Check FAN OFF
Do the alarms fail to activate relay contacts?		The relay contacts must be powered by external voltage A relay contact opens when activated by an alarm event.



Maintenance

The control unit has no parts that can be replaced, except for the fuse.

All repair operations must be carried out by the manufacturer.

To clean dust and dirt from the surfaces, gently rub with cotton or other soft cloth soaked with non-aggressive, non-abrasive detergents, use those used for glass surfaces; do not use solvents or aromatic compounds and do not rub with abrasive sponges.

Disposal

Dispose of properly after use. Dispose of the product according to laws in force for electronic equipment.

This device is for use in a dust collection system and is therefore part of a fixed installation.



Warranty

The warranty has a duration of 2 years. The company will replace any electronic component deemed defective exclusively at our workshop, except in the presence of contrary agreements to be authorized by the company.

Warranty Exclusions

The warranty will be cancelled in case of:

- Signs of unauthorized tampering or repairs.
- Incorrect use of the device not respecting technical data.
- Wrong electrical connections.
- Failure to respect system standards.
- Use not in accordance with EC standards.
- Atmospheric events (lightening, electrostatic discharges,), power surges.
- Obstructed pneumatic connections. Damaged tubes.

APPENDIX B to user's manual - title: "Filtering device UFO-A-N and UFO-A-N/R"



KLIMAWENT S.A. Poland

Chwaszczynska 194 street, 81-571 Gdynia phone: +48 58 629 64 80 fax: +48 58 629 64 19 e-mail: klimawent@klimawent.com.pl website: www.klimawent.com.pl

klimawent@klimawent.com.pl

Copyright © by KLIMAWENT S.A. Gdynia 2023-11-15